

NUMSafe CTMP6900 Logic Terminal

Operating manual

M00033EN-02

Edition 12.2017



The reproduction, distribution and utilization of NUM documents as well as the communication of its contents to others without express authorization are prohibited. Offenders will be held liable for the payment of damages.
All rights reserved in the event of the grant of a patent, utility model or design.

Despite the care taken in the preparation of this document, NUM cannot guarantee the accuracy of the information it contains and cannot be held responsible for any errors therein, nor for any damage which might result from the use or application of the document.

The physical, technical and functional characteristics of the hardware and software products and the services described in this document are subject to modification and cannot under any circumstances be regarded as contractual.

The programming examples described in this manual are intended for guidance only. They must be specially adapted before they can be used in programs with an industrial application, according to the automated system used and the safety levels required.

Summary

1	Foreword	9
1.1	Notes on the manual.....	9
1.1.1	Currentness	9
1.1.2	Product features.....	9
1.1.3	Disclaimer	9
1.1.4	Trademarks	9
1.1.5	Patent Pending.....	9
1.1.6	Copyright.....	10
1.1.7	Delivery conditions.....	10
1.2	Safety instructions	11
1.2.1	Delivery state	11
1.2.2	Operator's obligation to exercise diligence	11
1.2.3	Description of safety symbols	12
1.3	Document revisions	13
1.4	NUM Agencies	13
2	System description	17
2.1	NUM EtherCAT Terminal	17
2.1.1	NUM EtherCAT Gateway	18
2.1.2	NUMSafe Terminals	19
2.1.3	E-bus.....	20
2.1.4	Power contacts	20
2.2	NUMSafe	21
2.2.1	The I/O construction kit is extended safely.....	21
2.2.2	Safety concept.....	21
2.2.3	CTMS1904, CTMS2904 – NUMSafe Terminals with 4 fail-safe inputs or outputs	22
2.2.4	CTMP6900 - NUMSafe Logic Terminal	22
2.2.5	The fail-safe principle (Fail Stop)	22
3	Product description	27
3.1	CTMP6900 - NUMSafe Logic Terminal	27
3.2	Intended use	28
3.3	Technical data	29
3.4	Safety parameters.....	30
3.5	Dimensions	31
4	Operation	35
4.1	Environmental conditions.....	35
4.2	Installation.....	35
4.2.1	Safety instructions	35
4.2.2	Transport / storage.....	35
4.2.3	Mechanical installation.....	36
4.2.3.1	Control cabinet / terminal box	36
4.2.3.2	Installation position and minimum distances	36
4.2.3.3	Example configuration	37
4.2.3.4	Installation on mounting rails	38
4.2.4	Electrical installation	40
4.2.4.1	Connections within a EtherCAT Terminal block.....	40

4.2.4.2	Overvoltage protection	41
4.2.4.3	Wiring.....	42
4.2.4.4	CTMP6900 pin assignment	43
4.2.5	NUMSafe reaction times.....	44
4.2.6	Tested CTMS1904 devices.....	46
4.2.7	Tested CTMS2904 devices.....	46
4.3	Operation in potentially explosive atmospheres (ATEX)	47
4.3.1	Special conditions.....	47
4.3.2	Identification.....	48
4.3.3	Date code and serial number.....	48
4.4	Configuration of CTMP6900 with “CODESYS Safety for EtherCAT Safety Module”	49
4.4.1	Configuration requirements	49
4.4.2	NUM EtherCAT Gateway.....	49
4.4.3	Adding an EtherCAT Master to the device tree	50
4.4.4	Adapting the EtherCAT Master settings.....	50
4.4.5	Adding a CTMP6900	51
4.4.6	Address settings on the NUMSafe EtherCAT terminals.....	52
4.4.7	Entering the NUMSafe addresses in the System Manager.....	53
4.4.8	Adding other NUMSafe terminals	53
4.4.9	Settings of the parameters of the logical I/Os.....	54
4.4.10	Definition of the I/O image of the logical devices	54
4.4.11	Creation of a program (POU).....	55
4.4.12	Setting the group I/Os of the “POU” program.....	56
4.4.13	Addition of logical devices for data exchange	57
4.4.14	Definition of the variables of the exchange objects	58
4.4.15	Addition of global variable lists for the logical exchange	59
4.4.16	“PLC_PRG” program	60
4.4.17	CTMP6900 user and version administration	61
4.4.17.1	Overview of safety access protection.....	61
4.4.17.2	User management in the project.....	61
4.4.17.3	User management – EtherCAT safety module	62
4.4.17.4	Access protection with link to source control.....	62
4.4.18	Loading the project into the CTMP6900	63
4.4.19	CTMP6900 project design limits.....	65
4.5	Diagnostics	66
4.5.1	Diagnostic LEDs	66
4.5.1.1	Diag 1 LED (green)	66
4.5.1.2	Diag 2 LED (red)	66
4.5.1.3	Diag 3 LED (red)	66
4.5.1.4	Diag 4 LED (red) if Diag 3 LED (red) is lit	67
4.5.1.5	Diag 4 LED (red) if Diag 3 LED (red) is not lit	67
4.5.2	Diagnostic object	68
4.5.3	Cycle time of the safety project	69
4.5.4	Status LEDs	70
4.6	Maintenance	71
4.6.1	Cleaning	71
4.7	Service life	72
4.8	Decommissioning	72
4.8.1	Disposal	72
5	Appendix.....	77
5.1	NUM Support and Service.....	77
5.1.1	NUM branches and partner companies NUM Support	77
5.2	Certificates.....	78

Page deliberately empty.

Page deliberately empty.

Summary

1	Foreword	9
1.1	Notes on the manual.....	9
1.1.1	Currentness	9
1.1.2	Product features.....	9
1.1.3	Disclaimer	9
1.1.4	Trademarks	9
1.1.5	Patent Pending.....	9
1.1.6	Copyright.....	10
1.1.7	Delivery conditions.....	10
1.2	Safety instructions	11
1.2.1	Delivery state	11
1.2.2	Operator's obligation to exercise diligence.....	11
1.2.3	Description of safety symbols	12
1.3	Document revisions	13
1.4	NUM Agencies	13

1

2

3

4

5

Page deliberately empty.

1 Foreword

1.1 Notes on the manual

This description is only intended for the use of trained specialists in control and automation technology who are familiar with the applicable national standards. It is essential that the following notes and explanations are followed when installing and commissioning these components.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

1.1.1 Currentness

Please check whether you are using the current and valid version of this document. In case of doubt, please contact NUM Technical Support.

1.1.2 Product features

Only the product features specified in the current user documentation are valid. Further information given on catalogue, brochures, web-site etc. is not authoritative.

1.1.3 Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development. For that reason the documentation is not in every case checked for consistency with performance data, standards or other characteristics.

In the event that it contains technical or editorial errors, we retain the right to make alterations at any time and without warning.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

1.1.4 Trademarks

EtherCAT, Safety over EtherCAT® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

1.1.5 Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, DE102004044764, DE102007017835 with corresponding applications or registrations in various other countries.

1.1.6 Copyright

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.1.7 Delivery conditions

In addition, the general delivery conditions of the company NUM apply.

1.2 Safety instructions

1.2.1 Delivery state

All the components are supplied in particular hardware and software configurations appropriate for the application.

Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of NUM.

1.2.2 Operator's obligation to exercise diligence

The operator must ensure that:

- the NUMSafe products are only used as intended (see chapter Product description).
- the NUMSafe products are only operated in sound condition and in working order.
- the NUMSafe products are operated only by suitably qualified and authorized personnel.
- the personnel is instructed regularly about relevant occupational safety and environmental protection aspects, and is familiar with the operating manual and in particular the safety notes contained herein.
- the instruction manual is in good condition and complete, and always available for reference at the location where the NUMSafe products are used.
- none of the safety and warning notes attached to the NUMSafe products are removed, and all notes remain legible.

1.2.3 Description of safety symbols

The following safety symbols are used in this operating manual. They are intended to alert the reader to the associated safety instructions.

Symbol	Meaning of the symbol
 DANGER	Serious risk of injury! Failure to follow the safety instructions associated with this symbol directly endangers the life and health of persons.
 WARNING	Risk of injury! Failure to follow the safety instructions associated with this symbol endangers the life and health of persons.
 CAUTION	Personal injuries! Failure to follow the safety instructions associated with this symbol can lead to injuries to persons.
 Warning	Damage to the environment or devices Failure to follow the instructions associated with this symbol can lead to damage to the environment or equipment.
 Note	Tip or pointer This symbol indicates information that contributes to better understanding.

1.3 Document revisions

Code	Edition	Evolution Index	Meaning of the major documentation evolution points	See chapter
M00033	05.2013	00	First version of the manual.	-
	11.2017	01	- DIN EN ISO 13849-1:2015 - New Certificate	2.2, 2.2.4, 3.1.1 5.2
	12.2017	02	- Currentness. - Product features. - DIN mounting rail (EN 60715) - DIN EN ISO 13849-1:2015, DIN EN ISO 13849-1:2015. - System limits (Note). - Power supply from SELV/PELV power supply unit (Warning). - Technical data. - Safety parameters. - Environmental conditions. - Example configuration. - Fastening of mounting rails (Note). - NUMSafe reaction times. - NUMSafe address (Note). - Diagnostic object: - Index FA80 _{hex} Internal temperature values. - Index FA100 _{hex} Device Status. - Cycle time of the safety project: - Index 1C32 _{hex} : Cycle Time Measuring. - Decommissioning	1.1.1 1.1.2 2.1 2.2.2 3.2 3.2 3.3 3.4 4.1 4.2.3.3 4.2.3.4 4.2.5 4.4.6 4.5.2 4.5.3 4.8

1.4 NUM Agencies

The list of NUM agencies is given on <http://www.num.com>

Page deliberately empty.

Summary

2	System description	17
2.1	NUM EtherCAT Terminal	17
2.1.1	NUM EtherCAT Gateway	18
2.1.2	NUMSafe Terminals	19
2.1.3	E-bus	20
2.1.4	Power contacts	20
2.2	NUMSafe	21
2.2.1	The I/O construction kit is extended safely	21
2.2.2	Safety concept	21
2.2.3	CTMS1904, CTMS2904 – NUMSafe Terminals with 4 fail-safe inputs or outputs	22
2.2.4	CTMP6900 - NUMSafe Logic Terminal	22
2.2.5	The fail-safe principle (Fail Stop)	22

1

2

3

4

5

Page deliberately empty.

2 System description

2.1 NUM EtherCAT Terminal


The NUM EtherCAT Terminal system is used for decentralized connection of sensors and actuators to a control system.

The NUM EtherCAT Terminal system components are mainly used in industrial automation. In its minimum configuration, a bus station consists of a NUM EtherCAT Gateway or and NUM EtherCAT Terminals connected to it.

The NUM EtherCAT Gateway forms the communication interface to the higher-level controller, and the terminals are the interface to sensors and actuators. The whole bus station is clipped onto a 35mm DIN mounting rail (EN 60715).

The mechanical cross connection of the bus station is established via a slot and key system at the NUM EtherCAT Gateway and the NUM EtherCAT Terminals.

The sensors and actuators are connected with terminals via the screwless (spring-loaded) connection system.




Slot and key system and screwless (spring-loaded) connection system

In order to accommodate the wide range of different communication standards encountered in industrial automation, NUM offers NUM EtherCAT Gateways for a number of common bus systems (e.g. CTMG1100 for EtherCAT).

2.1.1 NUM EtherCAT Gateway

Mechanical data

Mechanical data	NUM EtherCAT Gateway
Material	Polycarbonate, polyamide (PA6.6).
Dimensions (W x H x D)	44mm x 100mm x 68mm
Mounting	On 35mm mounting rail (EN 60715) with lock
Attachable by	Double slot and key connection



NUM EtherCAT Gateway


Connection technology

Connection technology	NUM EtherCAT Gateway
Wiring	spring-loaded system
Connection cross-section	0.08 mm ² ... 2.5 mm ² , stranded wire, solid wire
Fieldbus connection	RJ45
Power contacts	3 spring contacts
Current load	10A
Rated voltage	24VDC

2.1.2 NUMSafe Terminals

Mechanical data

Mechanical data	NUMSafe Terminals
Material	Polycarbonate, polyamide (PA6.6).
Dimensions (W x H x D)	12mm x 100mm x 68mm or 24mm x 100mm x 68mm
Mounting	On 35mm mounting rail (EN 60715) with lock
Attachable by	Double slot and key connection



NUMSafe Terminals

Connection technology

Connection technology	NUMSafe Terminals
Wiring	spring-loaded system
Connection cross-section	0.08mm ² ... 2.5mm ² , stranded wire, solid wire
Fieldbus connection	E-bus
Power contacts	Up to 3 blade/spring contacts
Current load	10A
Rated voltage	Depends on NUMSafe Terminal type

2.1.3 E-bus

The E-bus is the data path within a terminal strip. The E-bus is led through from the NUM EtherCAT Gateway through all the terminals via six contacts on the terminals' side walls.

2.1.4 Power contacts

The operating voltage is passed on to following terminals via three power contacts. Terminal strip can be split into galvanically isolated groups by means of potential feed terminals as required.

The power feed terminals play no part in the control of the terminals, and can be inserted at any locations within the terminal strip.

2.2 NUMSafe

2.2.1 The I/O construction kit is extended safely

With the NUMSafe Terminals, NUM offers the option of simply expanding the proven EtherCAT Terminal system, and to transfer the complete cabling for the safety circuit into the already existing fieldbus cable.

Safe signals can be mixed with standard signals without restriction. This saves design effort, installation and material. Maintenance is simplified significantly through faster diagnosis and simple replacement of only a few components.

The new CTMxx9xx series EtherCAT terminals include three basic functionalities:

- digital inputs CTMS19xx,
- digital outputs CTMS29xx,
- Safe Logic Terminal CTMP6900.

For a large number of applications, all sensors and actuators can be wired on these EtherCAT terminals.

The required logical link of the inputs and the outputs is handled by the CTMP6900. For small to medium-sized configurations, the tasks of a fail-safe PLC can thus be handled within the EtherCAT terminal system.

2.2.2 Safety concept

NUMSafe: Safety and I/O technology in one system

- Extension of the familiar NUM I/Os system with NUMSafe EtherCAT Terminals
- Freely selectable mix of safe and standard signals
- Logical link of the I/Os in the CTMP6900 NUMSafe Logic Terminal
- Safety-relevant networking of machines via bus systems.

NUMSafe protocol (Fail Safe over EtherCAT - FSoE)

- Transfer of safety-relevant data via any media ("genuine black channel")
- IEC 61508 SIL 3 compliant.

Configuring instead of wiring:

- Configuration of the NUMSafe system via "CODESYS Safety for EtherCAT Safety Module" programming system
- System Manager for editing and displaying all bus parameters
- Certified function blocks such as emergency stop, operation mode, etc.
- Simple handling
- Typical function blocks for machine safety.

NUMSafe Logic Terminal CTMP6900

- Link unit between NUMSafe input and output terminals
- Configuration of a simple, flexible, cost-effective, decentralized safety controller
- No safety requirements for higher-level control system
- NUMSafe Logic Terminal enables networks with up to 65535 NUMSafe devices
- NUMSafe Logic Terminal can establish up to 128 connections (NUMSafe connections).
- Several NUMSafe logic terminals are cascadable in a network
- Safety functions such as emergency stop, protective door etc. are already included
- Suitable for applications up to SIL 3 according to IEC 61508 and DIN EN ISO 13849-1:2015 (Cat 4, PL e).

NUMSafe input (CTMS1904) and output terminal (CTMS2904)

- All current safety sensors can be connected
- Operation with a NUMSafe Logic Terminal
- CTMS1904 with 4 fail-safe inputs for sensors (24VDC) with floating contacts
- CTMS2904 with four safe channels for actuators (24VDC, 0.5A per channel)
- conforming to IEC 61508:2010 SIL 3 and DIN EN ISO 13849-1:2015 (Cat 4, PL e) requirements.

2.2.3 CTMS1904, CTMS2904 – NUMSafe Terminals with 4 fail-safe inputs or outputs

The CTMS1904 and CTMS2904 EtherCAT terminals enable connection of common safety sensors and actuators. They are operated with the CTMP6900 NUMSafe Logic Terminal.

The NUMSafe Logic Terminal is the link unit between the NUMSafe input and output terminals. It enables the configuration of a simple, flexible and cost-effective decentralized safety control system.

Therefore, there are no safety requirements for the higher-level controller!
The typical safety functions required for the automation of machines, such as emergency stop, protective door, two-hand etc., are already permanently programmed in the CTMP6900. The user configures the CTMP6900 terminal according to the safety requirements of his application.

2.2.4 CTMP6900 - NUMSafe Logic Terminal

The NUMSafe Logic Terminal is the link unit between the NUMSafe input and output terminals.

The CTMP6900 meets the requirements of IEC 61508:2010 SIL 3, EN 954 Cat. 4 and DIN EN ISO 13849-1:2015 (Cat 4, PL e).

2.2.5 The fail-safe principle (Fail Stop)

The basic rule for a safety system such as NUMSafe is that failure of a part, a system component or the overall system must never lead to a dangerous condition.

The safe state is always the switched off and wattless state.

Page deliberately empty.

1

2

3

4

5

Page deliberately empty.

Summary

3	Product description	27
3.1	CTMP6900 - NUMSafe Logic Terminal	27
3.2	Intended use	28
3.3	Technical data.....	29
3.4	Safety parameters.....	30
3.5	Dimensions	31

1

2

3

4

5

Page deliberately empty.


3 Product description

3.1 CTMP6900 - NUMSafe Logic Terminal

The NUMSafe Logic Terminal is the link unit between the NUMSafe input and output terminals.

The CTMP6900 meets the requirements of IEC 61508:2010 SIL 3, DIN EN ISO 13849-1:2015 (Cat 4, PL e), NRTL, UL508, UL1998 and UL991.

The NUMSafe terminal has the typical design of an EtherCAT terminal.



CTMP6900 - NUMSafe Logic Terminal

3.2 Intended use

 WARNING	Caution – Risk of injury! NUMSafe terminals may only be used for the purposes described below!
 WARNING	System limits The TÜV SÜD certificate applies to the CTMP6900, the function blocks available in it, the documentation and the engineering tool. The permitted engineering tool is “CODESYS Safety for EtherCAT SafetyModule”. Any deviations from the procedures or tools, particularly externally generated xml files for NUMSafe import or externally generated automatic project creation procedures, are not covered by the certificate!

The NUMSafe terminals expand the application range of NUM EtherCAT terminals system with functions that enable them to be used for machine safety applications.

The NUMSafe terminals are designed for machine safety functions and directly associated industrial automation tasks. They are therefore only approved for applications with a defined fail-safe state. This safe state is the wattless state. Fail-safety according to the relevant standards is required.

The NUMSafe terminals enable connection of:

- 24VDC sensors (CTMS1904) such as emergency stop push buttons, pull cord switches, position switches, two-hand switches, safety mats, light curtains, light barriers, laser scanners etc.
- 24VDC actuators (CTMS2904) such as contactors, protective door switches with tumbler, signal lamps, servo drives etc.

 Note	Test pulses When selecting actuators please ensure that the CTMS2904 test pulses do not lead to actuator switching or diagnostic message from the CTMS2904.
---	---

The following modules were developed for these tasks:

- The CTMS1904 is an EtherCAT Terminal with 4 digital fail-safe inputs.
- The CTMS2904 is an EtherCAT Terminal with 4 digital fail-safe outputs.
- The CTMPL6900 is an EtherCAT Terminal with integrated NUMSafe logic.

These modules are suitable for operation with:

- NUM CTMGxxxx series EtherCAT Gateway.

 WARNING	Power supply from SELV/PELV power supply unit! The NUMSafe terminals components must be supplied with 24 VDC by an SELV/PELV power supply unit with an output voltage limit U_{max} of 36 VDC. Failure to observe this can result in a loss of safety.
 CAUTION	Follow the machinery directive! The NUMSafe terminals may only be used in machines according to the Machinery Directive.
 CAUTION	Ensure traceability! The buyer has to ensure the traceability of the device via the serial number.

3.3 Technical data

Product name	CTMP6900
Number of inputs	0
Number of outputs	0
Status display	4 diagnostic LEDs
Minimum cycle time	Approx. 500µs
Error reaction time	≤ watchdog times
Watchdog time	Min. 2ms, max. 60000ms
Input process image	Dynamic according to the NUMSafe configuration in "CODESYS Safety for EtherCAT Safety Module" programming system
Output process image	Dynamic according to the NUMSafe configuration in "CODESYS Safety for EtherCAT Safety Module" programming system
CTMP6900 supply voltage (PELV)	From NUM EtherCAT Gateway CTMG1100
Current consumption from the E-bus	Approx. 188mA
Power dissipation of the terminal	Typically 1W
Dimensions (W x H x D)	12mm x 100mm x 68mm
Weight	Approx. 50 g
Permissible ambient temperature (operation) up to SW 04	0°C to +55°C (see notes in section 4.2.3.2)
Permissible ambient temperature (operation) from SW 05 (week 02/2014)	-25°C to +55°C (see notes in section 4.2.3.2)
Permissible ambient temperature (transport/storage)	-40°C to +70°C
Permissible air humidity	5% to 95%, non-condensing
Permissible air pressure (operation/storage/transport)	750hPa to 1100hPa (this corresponds to a height of approx. -690m to 2450m over sea level assuming an international standard atmosphere)
Climate class according to EN 60721-3-3	3K3 (the deviation from 3K3 is possible only with optimal environmental conditions and also applies only to the technical data which are specified differently in this documentation)
Permissible level of contamination according to EN 60664-1	Contamination level 2 (comply with the chapter Maintenance)
Impermissible operating conditions	NUMSafe terminals must not be used under the following operating conditions: • under the influence of ionizing radiation • in corrosive environments • in an environment that leads to unacceptable soiling of the EtherCAT terminal.
Vibration / shock resistance	Conforms to EN 60068-2-6 / EN 60068-2-27
EMC immunity/emission	Conforms to EN 61000-6-2 / EN 61000-6-4
Shocks	15 g with pulse duration 11 ms in all three axes
Protection class	IP20
Permitted operating environment	Control cabinet or terminal box with minimum protection class IP54 according to IEC 60529
Permissible installation position	See chapter 4.2.3.2 <i>Installation position and minimum distances</i>
Approvals	CE, cULus, ATEX, TÜV SÜD

3.4 Safety parameters

Key figures	CTMP6900
Lifetime [a]	20
Proof test Interval [a]	not required ¹
PFH _D	1.03E-09
%SIL3	1.03%
PFD	8.23E-05
%SIL3	8.23%
MTTF _d	high
DC	high
Performance level	PL e
Category	4
HFT	1
Element classification ²	Type B


¹ Special proof tests are not required during the entire service life of the CTMP6900 EtherCAT terminal.

² Classification according to IEC 61508-2:2010.

The CTMP6900 EtherCAT Terminal can be used for safety-related applications within the meaning of IEC 61508:2010 up to SIL3 and EN ISO 13849-1 up to PL e (Cat4).

For the calculation or estimation of the MTTF_d value from the PFHD value, further information can be found in the NUMSafe application guide or in ISO 13849-1:2015.

3.5 Dimensions



Dimensions of the CTMP6900

1

2

3

4

5

Page deliberately empty.

Summary

4	Operation	35
4.1	Environmental conditions.....	35
4.2	Installation.....	35
4.2.1	Safety instructions	35
4.2.2	Transport / storage.....	35
4.2.3	Mechanical installation.....	36
4.2.3.1	Control cabinet / terminal box	36
4.2.3.2	Installation position and minimum distances	36
4.2.3.3	Example configuration	37
4.2.3.4	Installation on mounting rails	38
4.2.4	Electrical installation	40
4.2.4.1	Connections within a EtherCAT Terminal block.....	40
4.2.4.2	Overvoltage protection	41
4.2.4.3	Wiring.....	42
4.2.4.4	CTMP6900 pin assignment	43
4.2.5	NUMSafe reaction times.....	44
4.2.6	Tested CTMS1904 devices.....	46
4.2.7	Tested CTMS2904 devices.....	46
4.3	Operation in potentially explosive atmospheres (ATEX)	47
4.3.1	Special conditions.....	47
4.3.2	Identification.....	48
4.3.3	Date code and serial number.....	48
4.4	Configuration of CTMP6900 with “CODESYS Safety for EtherCAT Safety Module”	49
4.4.1	Configuration requirements	49
4.4.2	NUM EtherCAT Gateway	49
4.4.3	Adding an EtherCAT Master to the device tree	50
4.4.4	Adapting the EtherCAT Master settings.....	50
4.4.5	Adding a CTMP6900	51
4.4.6	Address settings on the NUMSafe EtherCAT terminals	52
4.4.7	Entering the NUMSafe addresses in the System Manager.....	53
4.4.8	Adding other NUMSafe terminals	53
4.4.9	Settings of the parameters of the logical I/Os.....	54
4.4.10	Definition of the I/O image of the logical devices	54
4.4.11	Creation of a program (POU).....	55
4.4.12	Setting the group I/Os of the “POU” program.....	56
4.4.13	Addition of logical devices for data exchange	57
4.4.14	Definition of the variables of the exchange objects	58
4.4.15	Addition of global variable lists for the logical exchange	59
4.4.16	“PLC_PRG” program	60
4.4.17	CTMP6900 user and version administration	61
4.4.17.1	Overview of safety access protection.....	61
4.4.17.2	User management in the project.....	61
4.4.17.3	User management – EtherCAT safety module	62
4.4.17.4	Access protection with link to source control.....	62
4.4.18	Loading the project into the CTMP6900	63
4.4.19	CTMP6900 project design limits.....	65
4.5	Diagnostics	66
4.5.1	Diagnostic LEDs	66
4.5.1.1	Diag 1 LED (green)	66
4.5.1.2	Diag 2 LED (red)	66
4.5.1.3	Diag 3 LED (red)	66

4.5.1.4	Diag 4 LED (red) if Diag 3 LED (red) is lit	67
4.5.1.5	Diag 4 LED (red) if Diag 3 LED (red) is not lit	67
4.5.2	Diagnostic object	68
4.5.3	Cycle time of the safety project	69
4.5.4	Status LEDs	70
4.6	Maintenance	71
4.6.1	Cleaning	71
4.7	Service life	72
4.8	Decommissioning	72
4.8.1	Disposal	72

4 Operation

4.1 Environmental conditions

Please ensure that the NUMSafe terminals are only transported, stored and operated under the specified conditions (see technical data)!

 WARNING	Risk of injury! The NUMSafe terminals must not be used under the following operating conditions: • under the influence of ionizing radiation (that exceeds the level of the natural environmental radiation) • in corrosive environments • in an environment that leads to unacceptable soiling of the EtherCAT terminal.
 CAUTION	Electromagnetic compatibility The NUMSafe components comply with the current standards on electromagnetic compatibility with regard to spurious radiation and immunity to interference in particular. However, in cases where devices such as mobile phones, radio equipment, transmitters or high-frequency systems that exceed the interference emissions limits specified in the standards are operated near NUMSafe components, the function of the NUMSafe components may be impaired:

4.2 Installation

4.2.1 Safety instructions

Before installing and commissioning the NUMSafe terminals please read the safety notes in the foreword of this documentation.

4.2.2 Transport / storage

Use the original packaging in which the components were delivered for transporting and storing the NUMSafe terminals.

 CAUTION	Note the specified environmental conditions Please ensure that the digital NUMSafe terminals are only transported and stored under the specified environmental conditions (see technical data).
---	---

4.2.3 Mechanical installation

	Risk of injury! Bring the bus system into a safe, de-energized state before starting installation, disassembly or wiring of the devices!
---	--


4.2.3.1 Control cabinet / terminal box

The NUMSafe terminals must be installed in a control cabinet or terminal box with IP54 protection class according to IEC 60529 as a minimum.

4.2.3.2 Installation position and minimum distances

For the prescribed installation position the mounting rail is installed horizontally and the mating surfaces of the CTMxxx terminals point toward the front (see illustration below).

The terminals are ventilated from below, which enables optimum cooling of the electronics through convection. The direction indication “down” corresponds to the direction of positive acceleration due to gravity.



Installation position and minimum distances

In order to ensure optimum convection cooling, the distances to neighboring devices and to control cabinet walls must not be smaller than those shown in the diagram.

4.2.3.3 Example configuration



Example configuration for temperature measurement

The example configuration for the temperature measurement consists of an CTMT1100 EtherCAT coupler with connected terminals that match the typical distribution of digital and analog signal types at a machine.

On the CTMP6900 a safety project is active, which reads safe inputs and enables all 4 safe outputs during the measurement.



Note

External heat sources / radiant heat / impaired convection


The maximum permissible ambient temperature of 55°C was checked with the above example configuration. Impaired convection, an unfavorable location near heat sources or an unfavorable configuration of the EtherCAT Terminals may result in overheating of the terminals.

The key parameter is always the maximum permitted internally measured temperature of 95°C, above which the NUMSafe terminals switch to safe state and report an error. The internal temperature can be read from the NUMSafe components via CoE (see chapter Diagnose).

4.2.3.4 Installation on mounting rails

Mounting

The NUM EtherCAT Gateway and the NUM EtherCAT Terminals are attached to commercially available 35mm mounting rails (according to EN 60715) by applying slight pressure:




Installation on the mounting rail

1. First attach the EtherCAT Gateway to the mounting rail.
2. The EtherCAT Terminals are now attached on the right-hand side of the EtherCAT Gateway. Join the components with slot and key and push the terminals against the mounting rail, until the lock clicks onto the mounting rail.
If the terminals are clipped onto the mounting rail first and then pushed together without slot and key, the connection will not be operational!
When correctly assembled, no significant gap should be visible between the housings.



Fastening of mounting rails

The locking mechanism of the terminals and couplers protrudes into the profile of the mounting rail.
When installing the components, make sure that the locking mechanism doesn't come into conflict with the fixing bolts of the mounting rail.
For fastening mounting rails with a height of 7.5 mm under the terminals and couplers, use flat fastening components such as countersunk head screws or blind rivets.

Removal*Removal of mounting rails*

1. Carefully pull the orange-colored lugs approximately 1cm out of the disassembled terminal, until they protrude loosely. The lock with the mounting rail is now released for this terminal, and the terminal can be pulled from the mounting rail without excessive force.
2. Grasp the released terminal with thumb and index finger simultaneous at the upper and lower grooved housing surfaces and pull the terminal away from the mounting rail.

1

2

3

4

5

4.2.4 Electrical installation

4.2.4.1 Connections within a EtherCAT Terminal block

The electric connections between the EtherCAT Gateway and the EtherCAT Terminals are automatically realized by joining the components:

Spring contacts (E-bus)

- The six spring contacts of the E-bus deal with the transfer of the data and the supply of the EtherCAT Terminals electronics.



Note

Observe the E-bus current

Observe the maximum current that your EtherCAT Gateway can supply to the E-bus! Use the CTMT9410 Power supply terminal if the current consumption of your terminals exceeds the maximum current that your EtherCAT Gateway can feed to the E-bus supply.

Power contacts

- The power contacts deal with the supply for the field electronics and thus represent a supply rail within the EtherCAT Terminal block.
The power contacts are supplied via terminals on the EtherCAT Gateway.




Note

Note the connection of the power contacts

During the design of a EtherCAT Terminal block, the pin assignment of the individual EtherCAT Terminals must be taken account of, since some types (e.g. analog EtherCAT Terminals or digital 4-channel EtherCAT Terminals) do not or not fully loop through the power contacts.
Power Feed Terminals (CTMT91xx) interrupt the power contacts and thus represent the start of a new supply rail.

PE power contact

The power contact labelled PE can be used as a protective earth. For safety reasons this contact mates first when plugging together, and can ground short-circuit currents of up to 125A.



PE power contact



CAUTION

Insulation tests

Note that, for reasons of electromagnetic compatibility, the PE contacts are capacitatively coupled to the mounting rail. This may lead to incorrect results during insulation testing or to damage on the terminal (e.g. disruptive discharge to the PE line during insulation testing of a consumer with a rated voltage of 230V).

For insulation testing, disconnect the PE supply line at the EtherCAT Gateway or the Power Feed Terminal! In order to decouple further feed points for testing, these Power Feed Terminals can be released and pulled at least 10mm from the group of terminals.



DANGER


Serious risk of injury!

The PE power contact must not be used for other potentials!

4.2.4.2 Overvoltage protection

If protection against overvoltage is necessary in your plant, provide a surge filter for the voltage supply to the EtherCAT Terminal blocks and the NUMSafe terminals.

4.2.4.3 Wiring



Connection of a cable to a terminal point


Up to eight connections enable the connection of solid or finely stranded cables to the EtherCAT Terminals. The terminals are implemented in spring force technology.

Connect the cables as follows:

1. Open a spring-loaded terminal by slightly pushing with a screwdriver or a rod into the square opening above the terminal.
2. The wire can now be inserted into the round terminal opening without any force.
3. The terminal closes automatically when the pressure is released, holding the wire safely and permanently.

Wire cross section	0.08 ... 2.5mm ²
Strip length	8 ...9mm

4.2.4.4 CTMP6900 pin assignment



CTMP6900 pin assignment

Terminal point	Output	Signal
1	-	Not used, no function
2		Not used, no function
3	-	Not used, no function
4		Not used, no function
5	-	Not used, no function
6		Not used, no function
7	-	Not used, no function
8		Not used, no function


4.2.5 NUMSafe reaction times

NUMSafe form a modular safety system that exchanges safety-oriented data via the Safety-over-EtherCAT protocol.

This chapter is intended to help you determine the system's reaction time from the change of signal at the sensor to the reaction at the actuator.

Typical reaction time

The typical reaction time is the time that is required to transmit information from the sensor to the actuator, if the overall system is working without error in normal operation.



Definition	Description
RTSensor	Reaction time of the sensor until the signal is provided at the interface. Typically supplied by the sensor manufacturer.
RTInput	Reaction time of the safe input, such as CTMS1904. This time can be found in the technical data. In the case of the CTMS1904 it is 4 ms.
RTComm	Reaction time of the communication This is typically 3x the EtherCAT cycle time, because new data can only be sent in a new Safety-over-EtherCAT telegram. These times depend directly on the higher-level standard controller (cycle time of the PLC/NC).
RTLogic	Reaction time of the logic terminal. This is the cycle time of the logic terminal and typically ranges from 500 µs to 10 ms for the CTMP6900, depending on the size of the safety project. The actual cycle time can be read from the terminal.
RTOutput	Reaction time of the output terminal. This typically lies within the range of 2 to 3 ms.
RTActor	Reaction time of the actuator. This information is typically supplied by the actuator manufacturer.
WDComm	Watchdog time of the communication.

This results in the following equation for the typical reaction time:


$$ReactionTime_{typ} = RT_{Sensor} + RT_{Input} + 3 * RT_{Comm} + RT_{Logic} + 3 * RT_{Comm} + RT_{output} + RT_{Actor}$$

with, for example

$$ReactionTime_{typ} = 5ms + 4ms + 3 * 1ms + 10ms + 3 * 1ms + 3ms + 20ms = 48ms$$

Worst-case reaction time

The worst case reaction time is the maximum time required to switch off the actuator in the case of an error.



Worst-case reaction time

This assumes that a signal change occurs at the sensor and is transmitted to the input.

A communication error occurs at precisely the moment when the signal is to be transferred to the communication interface. This is detected by the logic following the watchdog time of the communication link.

This information should then be transferred to the output, but a further communication error occurs here. This error is detected at the output following the expiry of the watchdog time and leads to the switch-off.

This results in the following equation for the worst-case reaction:

$$ReactionTime_{max} = WD_{Comm} + WD_{Comm} + RT_{Actor}$$

with, for example

$$ReactionTime_{max} = 2 * 15ms + 20ms = 50ms$$

1

2

3

4

5

4.2.6 Tested CTMS1904 devices

The following list contains devices that were tested together with the CTMS1904 NUMSafe Terminal. The results only apply for the current device hardware version at the time of testing.

The tests were carried out in a laboratory environment. Modifications of these products cannot be considered here. If you are unsure please test the hardware together with the NUMSafe Terminal.

Manufacturer	Type	Comment
SICK	C4000	Safety light curtain
SICK	S3000	Safety laser scanner
Wenglor	SG2-14ISO45C1	Safety light grids
Leuze	lumiflex ROBUST 42/43/44	Safety light barriers
Schmersal	BNS250-11ZG	Safety switch
ifm	GM701S	Inductive safety sensor
Keyence	SL-V (with PNP cable set)	Safety light curtain

The tests were carried out as function tests only. The information provided in the respective manufacturer documentation remains valid.

4.2.7 Tested CTMS2904 devices

The following list contains devices that were tested together with the CTMS2904 NUMSafe Terminal. The results only apply for the current device hardware version at the time of testing.

The tests were carried out in a laboratory environment. Modifications of these products cannot be considered here. If you are unsure please test the hardware together with the NUMSafe Terminal.

Manufacturer	Type	Comment
Siemens	SIRIUS series S00 3RT1016-1BB42	Contactor
Telemecanique	LP1K09	Contactor

The tests were carried out as function tests only. The information provided in the respective manufacturer documentation remains valid.



Recommended protective circuits

We recommend R/C or diode-based protective circuits for these devices.
Varistor-based protective circuits should not be used.

4.3 Operation in potentially explosive atmospheres (ATEX)

4.3.1 Special conditions

 WARNING	Observe the special conditions for the intended use of NUM fieldbus components in potentially explosive areas (directive 94/9/EU)! • The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN60529! The environmental conditions during use are thereby to be taken into account! • If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values! • Observe the permissible ambient temperature range of 0 to 55 °C when using NUM fieldbus components in potentially explosive atmospheres! • Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages! • The individual terminals may only be unplugged or removed from the EtherCAT terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured! • The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured! • Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
---	--

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- **EN 60079-0: 2006**
- **EN 60079-15: 2005**

4.3.2 Identification

NUM fieldbus components that are certified for use in potentially explosive atmospheres bear one of the following markings:



II 3 G Ex nA II T4

KEMA 10ATEX0075 X Ta: 0 - 55°C

or



II 3 G Ex nA nC IIC T4

KEMA 10ATEX0075 X Ta: 0 - 55°C

4.3.3 Date code and serial number

The NUMSafe terminals bear a date code, which is composed as follows:

Date code: CW YY SW HW

Legend

CW: Calendar week of manufacture

YY: Year of manufacture

SW: Software version

HW: Hardware version

Example: Date code 29 10 02 01

Calendar week: 29

Year: 2010

Software version: 02

Hardware version: 01

In addition the NUMSafe terminals bear a unique serial number.

4.4 Configuration of CTMP6900 with “CODESYS Safety for EtherCAT Safety Module”



Do not change the register values!

Do not change any of the CoE objects in the NUMSafe terminals. Any modifications (e.g. via “CODESYS Safety for EtherCAT Safety Module”) of the CoE objects would permanently set the terminals to the Fail-Stop state.

4.4.1 Configuration requirements

The following system requirements apply to smaller “CODESYS Safety for EtherCAT Safety Module” projects with a maximum of 100 blocks, a maximum of 10 visualisations and a maximum of 8 fieldbus devices:

- 1 GB RAM
- 1 GHz Pentium
- 1 GB free hard disc space
- Screen resolution 1024 x 768.

The “CODESYS Safety for EtherCAT Safety Module” programming system is approved only for the following operating systems:


- Windows 7 (32/64 bit).

4.4.2 NUM EtherCAT Gateway

See NUM EtherCAT terminals CTMG and CTMT Operating manual M00032.

4.4.3 Adding an EtherCAT Master to the device tree


A right-click on the controller opens the context menu, from which the “Add device...” command is selected. The “EtherCAT Master” device is then selected in the following dialog.



Inserting an EtherCAT Master

4.4.4 Adapting the EtherCAT Master settings


A double-click on the “EtherCAT Master” device in the device tree opens the associated editor for setting the parameters. In this example the desired network adaptor is selected and the dialog is quit with “OK”.



EtherCAT Master - settings


4.4.5 Adding a CTMP6900

A right-click on the NUMEtherCAT gateway (CTMG1100) opens the context menu, from which the “Add device...” command is selected. The “CTMP6900” device is then selected in the following dialog.



Adding a CTMP6900

4.4.6 **Address settings on the NUMSafe EtherCAT terminals**



Address settings on NUMSafe terminals with 1023 possible addresses

The EtherCAT terminal address of the terminal is set via the 10-way DIP switch on the left-hand side of the EtherCAT terminal. NUMSafe addresses between 1 and 1023 are available.

DIP switch										Address
1	2	3	4	5	6	7	8	9	10	
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	0
ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	1
OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	2
ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	3
OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	4
ON	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	5
OFF	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	6
ON	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	7
...	...	...	...	...	...	...	...	...	...	...
ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	1023




NUMSafe address

Each NUMSafe address may only be used once within a network / a configuration!The address 0 is not a valid NUMSafe address!

4.4.7 Entering the NUMSafe addresses in the System Manager

The NUMSafe address set at the DIP switch must also be entered under the Safety Parameter tab.




Entering NUMSafe addresses

4.4.8 Adding other NUMSafe terminals

Using the same method applied for the CTMP6900, other NUMSafe terminals (CTMS1904 and CTMS2904) can be added as well and the FSoE address is also set in the same manner.

4.4.9 Settings of the parameters of the logical I/Os

In the next step the addresses of the logical devices are set. To this end the FSoE address “2” is set for the “CTMS1904” module and the address “3” for “CTMS2904”.



Logical I/Os - settings

4.4.10 Definition of the I/O image of the logical devices

Variables can be assigned to the individual channels of the module on the second tab of the editor. This is defined for the two modules as shown below:

Safe configuration I/O mapping Information					
In work					
Variable	Channel	Type	Unit	Description	
	Input	SA...TE			
in1	bit0	SA...OL			
in2	bit1	SA...OL			
in3	bit2	SA...OL			
in4	bit3	SA...OL			


CTMS1904 logical I/Os - I/O mapping

Safe configuration I/O mapping Information					
In work					
Variable	Channel	Type	Unit	Description	
	Output	SAFE BYTE			
out1	bit0	SAFE BOOL			
out2	bit1	SAFE BOOL			
	bit2	SAFE BOOL			
	bit3	SAFE BOOL			

CTMS2904 logical I/Os - I/O mapping


4.4.11 Creation of a program (POU)

A POU is added via the SafetyApp context menu or via the menu command “Project » Add Object » POU (EtherCAT Safety)”



Addition of a POU

The “FB_TWOHAND” function block is inserted in the editor of the added POU – this is done by selecting the FB in the Tools overview and moving it to the “Start here” field on the desktop by drag&drop.




Addition of the “FB_TWOHAND” FB

The inputs and outputs of the function block are connected with variables according to the diagram above.

4.4.12 Setting the group I/Os of the “POU” program

The group I/Os are set in the properties of the newly created POU (right-click on the POU in the device tree - “Properties”). These variables control the state of the POU and can signal errors.



POU - Properties

NUMSafe group inputs


Name	Permitted type	Description	
RUN	FB-Out Standard-In	TRUE:	The function blocks assigned to the NUMSafe group are executed. When the input is not linked it is in the TRUE state.
		FALSE:	All of the NUMSafe group assigned function blocks are at a STOP state and thus all associated outputs are in a safe state.
ERR Ack	FB-Out Standard-In	All pending errors in the assigned function blocks and in the NUMSafe connections are acknowledged by the FALSE->TRUE->FALSE signal sequence.	

NUMSafe group outputs

Name	Permitted type	Description	
FB ERR	NUMSafe-Out FB-In Standard-Out	TRUE:	At least one assigned function block has an error.
		FALSE:	All assigned function blocks have no errors.
COM ERR	NUMSafe-Out FB-In Standard-Out	TRUE:	At least one NUMSafe connection of NUMSafe group has an error.
		FALSE:	All NUMSafe connections of the NUMSafe group have no errors.
OUT ERR	NUMSafe-Out FB-In Standard-Out	FALSE:	Always FALSE, since the CTMP6900 has no local outputs.


4.4.13 Addition of logical devices for data exchange

Now further logical devices are added which will handle the exchange of data with the standard controller later on. To do this the “Add logical device” dialog is called (“context menu of logical I/Os → Add Object → Logical Device”).



Addition of a logical device

The device “8 bits exchange object from CTMP6900 to PLC” is selected from the dialog and is given the name “CTMP6900_to_PLC”.




Addition of a logical device – exchange device

In a similar way a logical device “8 bits exchange object from PLC to CTMP6900” is created with the name “PLC_To_CTMP6900”.


4.4.14 Definition of the variables of the exchange objects

Double-clicking on the newly added logical devices opens the associated editor. The variables are entered here as shown below. These variables are subsequently connected with a global variable list of the standard controller.



Variable	Channel	Type	Unit	Description
	Output	BYTE		Output
FbErr	bit0	BOOL		
ComErr	bit1	BOOL		
OutErr	bit2	BOOL		
	bit3	BOOL		
	bit4	BOOL		
	bit5	BOOL		
	bit6	BOOL		
	bit7	BOOL		

Logical device CTMP6900 --> PLC: variable definition




Variable	Channel	Type	Unit	Description
	Input	BYTE		Input
ErrAck	bit0	BOOL		
	bit1	BOOL		
	bit2	BOOL		
	bit3	BOOL		
	bit4	BOOL		

Logical device PLC --> CTMP6900: variable definition


4.4.15 Addition of global variable lists for the logical exchange

Now GVLs for the logical exchange are added to the device tree ("context menu of the application" → *Add Object* → *GVL for logical exchange*).



Addition of a GVL for logical exchange

The new GVL (with the name "fromCTM") is added to the device tree. A double-click opens its editor. The variables of the logical device "CTMP6900_To_PLC" are now mapped to this GVL in the lower section of the editor.




GVL - Assignment of the logical I/Os

The GVL "toCTM" is created in a similar way and connected with the logical I/Os of "CTMP6900_To_PLC".

4.4.16 “PLC_PRG” program

The variables of the safety application are read and written via the “PLC_PRG” program. The FbErr, ComErr and OutErr variables were inserted so that the states can be monitored. If bAutostart is set, the ErrAck flag is set for one cycle in the case of an error in the safety block (recognised via ComErr) so that the error is acknowledged in the safety controller.



PLC_PRG program

4.4.17 CTMP6900 user and version administration

4.4.17.1 Overview of safety access protection

Rights can be assigned in such a way in the project user management that safety objects of a project can be created or modified only by certain user groups ("Safety Developer"). The entire access protection of "CODESYS Safety for EtherCAT Safety Module" safety applications is realised by the user management in the project.



Note

It is urgently recommended to configure a user management with safe access protection for each project!
Without user management in the project, each person who collaborates in the project possesses all rights to the standard and safety applications in the project!.

4.4.17.2 User management in the project



Note

In a project without user management each user possesses **all rights**. The project manager must ensure that the safety application is worked on only by persons qualified to do so.

Creation of a new project without a user management template

If a new project is created as an "*empty project*", then the project manager must create a suitable user management for the safety application of the project. Refer to the Standard CODESYS online help for the exact procedure and detailed information on the creation of this user management in the project.

In order to facilitate the selection of the safety specific commands for the developer, "*Safe*" or "*Safety*" is placed in front of the commands that are relevant for the safety developer when assigning rights. In the rights objects the safety objects are easily recognisable by the suffix "*(Safety)*" after the object.




Note

If the developer does not have the rights for a particular operation, he can logon during the operation using a user name with more rights.

4.4.17.3 User management – EtherCAT safety module

In addition to the standard user management of CODESYS, the safety controller offers its own user management. This allows users to be setup with the associated passwords. These data must be entered during “Project Download”. Before changes are made to this user management, the current version of the user management must be loaded from the safety controller into the CODESYS project (“Upload” button in the “User Administration” section).



User management – EtherCAT safety modules

- “Upload” : Transfer of the current user management of the safety controller into CODESYS for display and editing.
- “Add user...” : The creation of a new user.
The input of the administrator password is necessary for this.
- “Delete user...” : The deletion of the selected user.
The input of the administrator password is necessary for this.
- “Change password...” : The current password must be entered before a new password can be defined.
- “Version history” : After the execution of the command the version history is read from the safety controller.

User name	Time stamp	Version number	Project CRC
Administrator	18.09.2012 14:46:21	1	16#B013
Administrator	25.09.2012 11:40:30	1	16#12CB
Administrator	26.09.2012 10:47:31	1	16#12CB
Administrator	26.09.2012 11:52:10	1	16#7536
Administrator	27.09.2012 12:09:08	1	16#12CB
User1	28.09.2012 09:51:20	1	16#12CB
User1	28.09.2012 09:52:22	2	16#12CB
Administrator	28.09.2012 09:54:31	2	16#12CB

Safety module version history

4.4.17.4 Access protection with link to source control




If a source control is used, then a user management corresponding to the user management in the project must also be set up in the source control.

4.4.18 Loading the project into the CTMP6900

selected, the «Administrator» user will be used. The download procedure is actuated from the «Safety parameters» tab of the editor for the node of the EtherCAT safety controller.


The user password and the serial number of the terminal must be entered in order for the data record to be accepted by the terminal.



Login dialog

A re-translation takes place automatically after the download of the application in order to check the generated code. To do this the translated code is decompiled again and compared at source code level. By means of this diverse method the function of the compiler is checked at each download. Both random and systematic errors are thereby determined.


The result of the comparison (same or different) is displayed to the user. The number of function blocks and networks compared is also indicated. If equality is determined the download is valid and can be confirmed by the user via the offered dialog box.



Dialog: Comparison result = "same projects"


If equality is determined the download is valid and can be confirmed by the user. After entering the user name and password again the enabling data record is loaded to the controller. Afterwards the controller is ready to start. The application must be started from the user program.

This is done by a rising edge of the variables defined in the group I/Os.



Dialog for loading the enabling data record

If a difference is found the download is not valid and cannot be confirmed. The corresponding confirmation dialog is not offered to the user in this case. Instead, the user is shown where (in which block or network, IO image or parameter) the discrepancy occurred.



Dialog: Comparison result = "different projects"

4.4.19 CTMP6900 project design limits

NUMSafe connections	Maximum. 128 (with 1 or 2 bytes safe user data per connection) maximum. 50 connections per NUMSafe group. Only 16 connections of an CTMP6900 can be slave connections.
Supported hardware for CTMP6900 NUMSafe connections	CTMS1904 CTMS2904 NUM-SAMX
Safe data per connection	Up to 14 bytes safe user data (correspondingly lower total number of connections)
NUMSafe blocks	Maximum 255
NUMSafe groups	Maximum 32
Standard PLC inputs	Dynamic up to 255 bit
Standard PLC outputs	Dynamic up to 255 bit

 Note	NUMSafe connection Only one NUMSafe connection between two NUMSafe EtherCAT terminals is possible. Between two CTMP6900 logic terminals a connection can be set up that may contain up to 14 bytes safe user data.
--	--

1

2

3


4

5

4.5 Diagnostics

4.5.1 Diagnostic LEDs

The LEDs Diag 1 to Diag 4 display diagnostic information for the CTMP6900.



CTMP6900 diagnostic LEDs

4.5.1.1 Diag 1 LED (green)

The Diag 1 LED is currently always on when a project is loaded into the terminal.

Display	Meaning
Lit	A project is stored in the terminal.

4.5.1.2 Diag 2 LED (red)

The Diag 2 LED indicates internal process variable errors (in preparation).

Display	Meaning
in preparation	

4.5.1.3 Diag 3 LED (red)

The Diag 3 LED provides further details for the Diag 4 LED (see next page).

4.5.1.4 Diag 4 LED (red) if Diag 3 LED (red) is lit

If the Diag 3 LED is lit, the Diag 4 LED indicates internal terminal errors.

Diag 3 LED	Diag 4 LED	Source of error
Lit	flashing	μC1
Lit	off	μC2



Note

Returning the terminal

These errors lead to shutdown of the terminal (Global Fault). The terminal must be checked by NUMspa.

4.5.1.5 Diag 4 LED (red) if Diag 3 LED (red) is not lit

If the Diag 3 LED is not lit, the Diag 4 LED indicates the state of the NUMSafe terminal.

Diag 3 LED	Diag 4 LED: Flashing Code	Meaning
off	1 flash pulse (uniform flashing)	Function block error in one of the NUMSafe groups.
off	2 flash pulses (2 pulses with longer pause in between)	Communication error in one of the NUMSafe groups.
off	3 flash pulses (3 pulses with longer pause in between)	Function block and communication error in one of the NUMSafe groups.
off	Steadily lit	Supply voltage or internal temperature of the terminal outside the permissible range. The diagnostic object FA00 _{hex} provides you with more detailed information.

4.5.2 Diagnostic object



Do not change CoE objects!

Do not make any modifications to the CoE objects in the NUMSafe terminals. Any modifications (e.g. via EtherCAT Safety Module" programming system) of the CoE objects would permanently set the terminals to the Fail-Stop state.

Index FA80_{hex}: Internal temperature values

The CoE objects FA80_{hex} indicate the current internal temperature values of the CTMP6900.

Index	Name	Meaning	Flags	Default
FA80:01	Temperature Primary MC	Temperature measurement 1.	RO	0 _{bin}
FA80:02	Temperature Secondary MC	Temperature measurement 2.	RO	0 _{bin}

Index FA00_{hex}: Diagnostic object

The CoE object FA00_{hex} displays further diagnostic information.

Index	Name	Meaning	Flags	Default
FA00:0	Diag	The following sub indices contain detailed diagnostic information.	RO	
FA00:03	Temperature error	0005 _{hex}	RO	0000 _{hex}
		0006 _{hex}		
		0007 _{hex}		
	Supply error	0101 _{hex}		
		0102 _{hex}		
		0103 _{hex}		
		0104 _{hex}		



Differing diagnostic messages possible

Due to the variable order or execution of the test series, diagnostic messages differing from those given in the table above are possible.

Index FA100_{hex} : Device Status

This CoE object is also mapped to the CTMP6900 process image under DEVICE Inputs.

Index	Name	Meaning	Flags	Default
F100:01	Safety Project State	State of the Safety Logic Project.	BIT3	RO
		0 OFFLINE Safety Project not loaded.		
		1 RUN Safety Project is executed, EtherCAT is in SAFEOP or OP state.		
		2 STOP Safety Project is loaded, but is stopped, due to a logged in user.		
		3 START Safety Project is loaded, EtherCAT is in INIT or PREOP state.		
		4 RESTORE When RESTORE Mode is configured: Project CRC is read from the FSoE Slaves.		
		7 FAULT The CTMP6900 has switched off due to a severe fault. A safety project can not be loaded or started.		
F100:08	Login Active	A user is logged in to the CTMP6900.	BOOLEAN	RO
F100:09	Input Size Mismatch	The length of the input data does not match the input data length calculated from the safety Logic.	BOOLEAN	RO
F100:0A	Output Size Mismatch	The length of the output data does not match the output data length calculated from the safety Logic.	BOOLEAN	RO
F100:0F	TxPDO State	This bit is set, when the Safety Project State is unequal to RUN.	BOOLEAN	RO
F100:10	TxPDO Toggle	This bit is toggled each time the EtherCAT input data is updated for the first time after it has been read by the EtherCAT master.	BOOLEAN	RO


4.5.3 Cycle time of the safety project

Index 1C32_{hex} : Cycle Time Measuring

Index	Name	Meaning	Flags	Default
1C32:05	Minimum cycle time	Minimum cycle time in ns that should be set by EtherCAT. Corresponds to the maximum program running time of the CTMP6900.	RO	00000000 _{hex}
1C32:08	Command	Cycle time measurement is activated by setting the command to 0001hex. This value should be reset to 0 once the cycle time has been determined.	RW	0000 _{hex}

4.5.4 Status LEDs

The LEDs State 1 to State 4 indicate the current status of the CTMP6900.



EL6900 status LEDs

State 1	State 2	State 3	State 4	Meaning
off	off	off	lit	No project present on the terminal
off	off	lit	lit	- Project present on the terminal - EtherCAT status: Pre-Operational (Pre-OP)
lit	lit	lit	lit	- Project present on the terminal - EtherCAT status: Operational (OP)

4.6 Maintenance

The NUMSafe terminals are maintenance-free!.

 WARNING	Observe the specified environmental conditions! Please ensure that the NUMSafe terminals are only stored and operated under the specified conditions (see technical data).
--	--

If the terminal is operated outside the permitted temperature range it will switch to *Global Shutdown* state.

4.6.1 Cleaning

Protect the NUMSafe terminal from unacceptable soiling during operation and storage!

If the NUMSafe Bus Terminals were subjected to unacceptable soiling they may no longer be operated!

 WARNING	Have soiled terminals checked! Cleaning of the NUMSafe terminal by the user is not permitted! Please send soiled terminals to the manufacturer for inspection and cleaning!
---	--

4.7 Service life

The NUMSafe terminals are designed for a service life of 20 years.

Due to the high diagnostic coverage within the lifecycle no special proof tests are required.

4.8 Decommissioning

	Serious risk of injury! Bring the bus system into a safe, de-energized state before starting disassembly of the EtherCAT Terminals!
---	--

4.8.1 Disposal

In order to dispose of the device, it must be removed and fully dismantled.

- Housing components (polycarbonate, polyamide (PA6.6) are suitable for plastic recycling.
- Metal parts can be sent for metal recycling.
- Electronic parts such as disk drives and circuit boards must be disposed of in accordance with national electronics scrap regulations.

Page deliberately empty.

1

2

3

4

5

Page deliberately empty.

Summary

5	Appendix.....	77
5.1	NUM Support and Service.....	77
5.1.1	NUM branches and partner companies NUM Support	77
5.2	Certificates.....	78

1

2

3

4

5

Page deliberately empty.

5 Appendix

5.1 NUM Support and Service

NUM and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to NUM products and system solutions.

5.1.1 NUM branches and partner companies NUM Support

Please contact your NUM branch office or partner company for local support and service on NUM products!

The contact addresses for your country can be found in the list of NUM branches and partner companies: www.num.com. You will also find further documentation for NUM components there.

ZERTIFIKAT ♦ CERTIFICATE ♦ 認証証書 ♦ CERTIFICADO ♦ CERTIFICAT



Product Service

CERTIFICATE

No. Z10 17 10 83009 005

Holder of Certificate:

Factory(ies):

Certification Mark:

NUM AG
 Battenhusstrasse 16
 9053 Teufen
 SWITZERLAND

62386



Product:

Model(s):

Parameters:

Safety components

CTMP6900

Supply voltage: 24VDC (-15%...+20%)
 Power dissipation: 2W
 Protection class: IP20

with "CODESYS Safety for EtherCAT Safety Module".
 Note: "CODESYS Safety for EtherCAT Safety Module"
 is developed in accordance with EN 61508:2010.

Tested according to:

2006/42/EC
 EN 61508-1:2010 (SIL1-3)
 EN 61508-2:2010 (SIL1-3)
 EN 61508-3:2010 (SIL1-3)
 EN ISO 13849-1:2015 (Cat 4, PL e)
 EN 81-22:2014
 EN 81-20:2014
 EN 81-50:2014
 EN 13243:2015
 DIN EN 61000-6-2:2006
 DIN EN 61000-6-4:2007

The product was tested on a voluntary basis and complies with the essential requirements. The certification mark shown above can be affixed on the product. It is not permitted to alter the certification mark in any way. In addition the certification holder must not transfer the certificate to third parties. See also notes overleaf.

Test report no.:

Valid until:

BV82168T

2022-10-15

Date, 2017-10-18

Page 1 of 1



(Günter Greil)



TÜV SÜD Product Service GmbH · Zertifizierstelle · Ridlerstraße 65 · 80339 München · Germany

TÜV®

Page deliberately empty.

1

2

3

4

5

Page deliberately empty.

Published by NUM Spa

Via F. Somma 62
20012 Cuggiono (MI) (Italy)
Tel. : +39 02 979 691
website: www.num.com

Printed December 2017