

NUM-SAMX

Safety module for NUM DrivePro



Instruction manual

(sw release 1.3.0/ 2.3.0/ 4.3.0 – 1.4.0/ 2.4.0/ 4.4.0)

For NUM-SAMX revision 16#000000D

M00069EN-03

Edition 01.2026



The reproduction, distribution and utilization of NUM documents as well as the communication of its contents to others without express authorization are prohibited. Offenders will be held liable for the payment of damages.
All rights reserved in the event of the grant of a patent, utility model or design.

Despite the care taken in the preparation of this document, NUM cannot guarantee the accuracy of the information it contains and cannot be held responsible for any errors therein, nor for any damage which might result from the use or application of the document.

The physical, technical and functional characteristics of the hardware and software products and the services described in this document are subject to modification and cannot under any circumstances be regarded as contractual.

The programming examples described in this manual are intended for guidance only. They must be specially adapted before they can be used in programs with an industrial application, according to the automated system used and the safety levels required.

Summary

1	Foreword	11
1.1	Notes on the manual.....	11
1.1.1	Disclaimer	11
1.1.2	Trademarks	11
1.1.3	Patent Pending	11
1.1.4	Copyright.....	11
1.1.5	Delivery conditions.....	11
1.1.6	Description rules	11
1.2	Safety instructions	12
1.2.1	Safety Rules.....	12
1.2.2	Disclaimer	12
1.2.3	Personnel Qualification.....	12
1.2.4	Description of safety symbols	12
1.3	Abbreviations and definitions	13
1.4	Document revisions	14
1.5	How to read the manual.....	15
1.6	NUM Agencies.....	16
2	General warnings on product use	21
2.1	NUM DrivePro with NUM-SAMX - User's informations	21
2.2	NUM DrivePro with NUM-SAMX unpacking inspection	21
2.3	General drives installation warnings instructions	22
2.4	Drive switched on condition general warnings	23
2.5	View of the hazardous areas around MDLUF units.....	24
3	Introduction	29
3.1	NUMSafe architecture	29
3.2	NUMSafe system components connection	30
3.3	NUM-SAMX safety module utilisation	31
3.4	Safety functions	32
3.4.1	Automatic mode	34
3.4.2	Other monitoring functions.....	34
3.4.3	Safety Function Priority.....	34
3.4.4	Muting and suspension of safety functions.....	35
3.4.5	Alarm queue managing.....	35
4	Machine safety and related standards.....	39
4.1	Introduction.....	39
4.2	Risk analysis and risk reduction	40
4.3	Contribution to the risk reduction by the electrical control system	41
5	Relevant standards and intended use	47
5.1	NUM-SAMX Functional safety reliability data	47
5.2	Fault Exclusion	48

5.3	Environmental conditions	48
5.4	MDLUF and NUM-SAMX installation and connections.....	48
5.5	Inter operations.....	49
5.5.1	Compatible feedback sensor	49
5.5.2	System's SIL / PFH calculation in case of using compatible feedback sensors.....	50
5.5.3	Reliability data with NUM sensors	51
6	FSoE I/O, Parameters and Operating modes.....	55
6.1	FSoE I/O for NUM-SAMX Mono-Axis	55
6.1.1	FSoE Input (NUM-SAMX Logical Output)	55
6.1.2	FSoE Output (NUM-SAMX Logical Input)	56
6.2	FSoE I/O for NUM-SAMX Bi-Axes and Quad-Axes	57
6.2.1	FSoE Input (NUM-SAMX Logical Output)	57
6.2.2	FSoE Output (NUM-SAMX Logical Input)	58
6.3	Parameters	59
6.3.1	General list.....	59
6.3.2	FSoE Address.....	60
S2	FSoE Address	60
6.3.3	NUM-SAMX configuration	61
S5	Operational modes.....	61
6.3.3.1	STO mode.....	64
6.3.3.2	Sensorless motor managed in V/f mode.....	64
6.3.4	Sensor configuration	65
S6	Period by turn (V360).....	65
S7	Absolute resolution by turn S1 sensor (V361).....	65
6.3.4.1	Example of NUM sensor configurations	65
S8	MULTI Coefficient (V306).....	66
S9	DIVI Coefficient (V307)	66
6.3.5	Motor poles pairs number	67
S10	Motor pole pairs number (V257)	67
6.3.6	Speed Limit	68
S11	SLS1 Speed limit.....	68
S12	SLS2 Speed limit.....	68
S13	SLS3 Speed limit.....	69
S14	SLS4 Speed limit.....	69
S15	Automatic mode speed limit.....	69
6.3.6.1	Calculation of Speed Limit in function of the kinematic chain	70
6.3.7	Motor zero speed threshold	71
S16	Motor standstill threshold	71
6.3.8	Ramp parameters	72
S17	Ramp on E-Stop monitoring delay	72
S18	Ramp on alarm monitoring delay	72
S19	CutOff Delay.....	72
6.3.8.1	SS2 following an E-Stop command diagram	73
6.3.8.2	Calculation of the deceleration parameters in function of the kinematic chain	74
6.3.9	Position displacement threshold	75
S20	Encoder disalignment threshold.....	75
S21	Position disalignment threshold for SOS and safe homing.....	75
S22	Safe homing positon	76
S23	Deceleration ramp.....	76
S24	SSM Speed limit.....	76

6.3.10	Position parameters	77
	S32 to S63 Safe position n lower / upper limit.....	77
6.4	Operating mode	78
6.4.1	Operating mode and transitions diagram.....	78
6.4.2	Automatic Mode	79
6.4.3	Safely-Limited Speed (SLS) - Common rules.....	80
6.4.3.1	Safely-Limited Speed (SLS) and S5.20 ... 23 = 0	81
6.4.3.2	Safely-Limited Speed (SLS) and S5.20 ... 23 = 1	81
6.4.3.3	Safely-Limited Speed (SLS) and S5.19 = 0	81
6.4.3.4	Safely-Limited Speed (SLS) and S5.19 = 1	81
6.4.4	Safe Direction (SDI)	82
6.4.5	Safe Homing	82
6.4.6	Safe Cams (SCA).....	82
6.4.6.1	Safe Cams (SCA) functional mode description	83
6.4.7	Safely-Limited Position (SLP)	84
6.4.8	Safe Stop 2 (SS2)	87
6.4.9	Braking ramp overview	88
6.4.9.1	E-Stop managing	88
6.4.9.2	E-Stop managing failure case.....	89
6.4.9.3	Generic NUM-SAMX Safety Failure case	90
6.4.9.4	CNC duplicated or synchronized axes.....	91
6.4.9.5	DRIVE tandem application (AP03,AP04,AP05)	91
6.4.9.6	Check of the braking ramp profile (MPX1)	93
6.4.10	Safe Stop 1 (SS1).....	98
6.4.11	Safe Operating Stop (SOS).....	99
6.4.12	Safe Torque Off (STO)	99
6.4.13	InterlockOut management	99
6.5	NUM-SAMX Logical Output behaviour	100
6.5.1	Standard mode S5.16 = 0 and S5.17 = 0	100
6.5.2	STO mode S5.16 = 1	100
6.5.3	V/f mode S5.17 = 1	101
6.5.4	Not admitted mode S5.16 = 1 and S5.17 = 1	101
6.6	Application example	102
6.6.1	NUM-SAMX Logical Input management with CNC duplicated or synchronized axes	102
6.6.2	NUM-SAMX Logical Input management with DRIVE tandem application	103
6.6.3	NUM-SAMX Logical Input management with CNC synchronized axes and DRIVE tandem application.....	104
6.6.4	NUM-SAMX Logical Input management with DRIVE in parking	105
7	Integration in a FlexiumPro project.....	109
7.1	Adding and addressing devices in a FlexiumPro project.....	109
7.1.1	Adding an EtherCAT Master to the device tree.....	109
7.1.2	Adapting the EtherCAT Master settings.....	110
7.1.3	Adding an EtherCAT gateway (CTMG1100).....	110
7.1.4	Adding a CTMP6900 (or CTMS1904 or CTMS2904)	111
7.1.5	Adding a NUM-SAMX	112
7.1.6	Address settings of the NUM-SAMX	113
7.1.7	Adding other NUMSafe terminals and NUM DrivePro devices.	114
7.2	Adding a NUM-SAMX Parameters folder.....	115
7.2.1	General setting page.....	116
7.2.2	NUM-SAMX Device association.....	117
7.2.3	NUM-SAMX Parameters editor in OFFLINE mode	119
7.2.4	NUM-SAMX Parameters editor in ONLINE mode	120
7.2.5	Export NUM-SAMX Parameter to a *.samxProParam file.....	121
7.2.6	Import NUM-SAMX parameter from a *.samxProParam file	122
7.2.7	NUM-SAMX Diagnostic in ONLINE mode.....	123
7.2.7.1	NUM-SAMX Test points in ONLINE mode	124

8	NUM-SAMX Measure point MPX list	129
8.1	MPX21 meanings	130
9	Diagnostics and Maintenance	135
9.1	Status of EtherCAT connector S8, S9 LEDs	135
9.2	NUM-SAMX alarms and alarms extension and trouble shooting.....	136
	Alarm 60 Safety Module class 0	136
	Alarm 61 Safety Module class 1.....	137
	Alarm 62 Safety Module class 2.....	139
	Alarm 63 Safety Module class 3	140
	Alarm 64 Safety Module class 4	141
9.3	Fault reaction and Response time	144
9.3.1	PDS fault reaction	144
9.4	State of being maintained	145
9.4.1	Maintenance.....	145
9.5	Service life	145

Page deliberately empty

Page deliberately empty

Summary

1	Foreword	11
1.1	Notes on the manual.....	11
1.1.1	Disclaimer	11
1.1.2	Trademarks	11
1.1.3	Patent Pending	11
1.1.4	Copyright.....	11
1.1.5	Delivery conditions.....	11
1.1.6	Description rules	11
1.2	Safety instructions	12
1.2.1	Safety Rules.....	12
1.2.2	Disclaimer	12
1.2.3	Personnel Qualification.....	12
1.2.4	Description of safety symbols	12
1.3	Abbreviations and definitions	13
1.4	Document revisions	14
1.5	How to read the manual.....	15
1.6	NUM Agencies	16

1

2

3

4

5

6

7

8

9

Page deliberately empty

1 Foreword

1.1 Notes on the manual

This description is only intended for the use of trained specialists in control and automation technology who are familiar with the applicable national standards. It is essential that the following notes and explanations are followed when installing and commissioning these components.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

1.1.1 Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development. For that reason the documentation is not in every case checked for consistency with performance data, standards or other characteristics.

In the event that it contains technical or editorial errors, we retain the right to make alterations at any time and without warning.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

1.1.2 Trademarks

EtherCAT® and Safety over EtherCAT® are registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

1.1.3 Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702 with corresponding applications or registrations in various other countries.

1.1.4 Copyright

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.1.5 Delivery conditions

In addition, the general delivery conditions of the company NUM apply.

1.1.6 Description rules

In the descriptions, when the parameter number is printed with sloped characters, it means that we refer to value stored into the parameter.

1.2 Safety instructions

1.2.1 Safety Rules

Consider the following safety instructions and descriptions!

Product specific safety instructions are to be found on the following pages or in the areas mounting, wiring, commissioning etc.

1.2.2 Disclaimer

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of NUM.

1.2.3 Personnel Qualification

This description is only intended for the use of trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

1.2.4 Description of safety symbols

The following safety symbols are used in this operating manual. They are intended to alert the reader to the associated safety instructions.

Symbol	Meaning of the symbol
	The information “ i ” icon indicates notes on product use.
	The STOP icon indicates a wrong operation which may damage the product or indicates important notes on product use .
	The TRIANGLE icon indicates hazard for human beings and this information is referring to personal damage! Whenever one of these icons appear, please beware, use and apply adequate precautions to avoid hazards or damage situations during the drive installation and commissioning operations! Please beware, consult chapter 2.5 Please beware! Prevent and safety instruction against accidental contact with electrical components.

1.3 Abbreviations and definitions

Abbreviations	Meaning
Bi-Axes	Drive for two motors control
BHX, BPX, SHX, SPX BPH, BPG	NUM axis motor range
CNC IU	CNC Internal Unit: 0.001mm, 0.01mm, 0.1mm, 0.0001mm etc. See CNC parameter P4N2 on Parameter Manual M00068
CTMG1100 and CTMTx	NUMEtherCAT Gateway and modules (see Installation manual M00032)
CTMP6900	NUMSafe PLC (see Installation manual M00033)
CTMS1904	NUMSafe input terminal (see Installation manual M00034)
CTMS2904	NUMSafe output terminal (see Installation manual M00035)
EtherCAT	Digital bus communication type
EMC	Electromagnetic Compatibility
EPS	Electrical Positions Synchronization
E-Stop	Emergency Stop
EU	European Union
FSoE	Fail Safe over EtherCAT
M	Motor
MASTER	NUM DrivePro module for TANDEM application
MDLL3	Power Supply module
MDLUF	NUM digital drive
Mono-Axis	Drive for one motor control
NUM DrivePro	Digital drive module (Power + Control Units)
NUM over EtherCAT	MDLUF digital bus communication type
NUM-STOX	Safe Torque Off certified SIL 2 module
NUM-SAMX	NUM-Safety certified SIL 3 module
PDS	Power Drive System (line filter + power cable + power supply + drives + power cables + motors)
Quad-Axes	Drive for four motor control
RJ11/ RJ45	Type of connector
RTK	Real Time Kernel
Size x	Module width (50mm, 100mm, 200mm or 400mm)
SDM	Safe Direction Monitoring
SLS	Safely Limited Speed
SLP	Safe Limited Position
SOS	Safe Operating Stop
SP	Drive Standard Performance version
SRP/ECS	Safety-Related Part Electrical Control System
SS1	Safe Stop 1
SS2	Safe Stop 2
SSM	Safe Speed Monitor
STO	Safe Torque Off
Safety Failure	In case a safety limit is disobeyed (for example a Safe Limited Speed is not respected) NUM-SAMX trigger a Safety Failure. The drive reaction depends on the Safety Failure class and the drive parameter setting. See chapter 6.4.9
Internal diagnostic failure	It's an internal NUM-SAMX fault that can be due to hardware, software, noise etc.

1.4 Document revisions

Edition	Evolution Index	Meaning of the major documentation evolution points	See chapter
12.2024	00	Compliance with Software version 1.00 / 2.00 / 4.00 Document creation: NUM-SAMX Safety module for NUM DrivePro	-
03.2025	01	Compliance with Software version 1.2.0 / 2.2.0 / 4.2.0	-
07.2025	02	Correction of NUM SAMX revision index	Cover
01.2026	03	Conversion rule for linear motor parameters S6	6.3.1 6.3.4

1.5 How to read the manual

This manual is structured and divided into 11 main sections as indicated here below. We suggest to follow these indicated manual sections.

1	Foreword This first section introduces the general notes, the use of the manual about safety instructions and definitions of abbreviations mentioned in the manual.
2	General warnings on product use This chapter will contain general warnings on the installation and use of the product, in particular on the dangerous areas around the units that compose it. The safety conditions for switching on the unit will also be indicated.
3	Introduction This chapter schematically represents the typical configurations, including the safety devices and modules, which constitute the system architecture, describing the use of the functions.
4	Machine safety and related standards This chapter will indicate the reference regulatory standards on machinery safety and, in particular, risk analysis and risk reduction will be described.
5	Relevant standards and intended use In this chapter, the relevant standards and their intended use will be indicated as well as the functional safety reliability data of the NUM_SAMX board.
6	FSoE I/O, Parameters and Operating modes In this chapter you can consult the general list of parameters and their operating modes, FSoE I/O, in the NUM-SAMX Mono-Axis, Bi-Axis configurations.
7	Integration in a FlexiumPro project This chapter will describe adding and addressing devices in a FlexiumPro project and how to add a NUM-SAMX parameter folder.
8	NUM-SAMX Measure point MPX list In this chapter the NUM-SAMX Measure points will be listed. It will also explain the meaning of MPX21 which is used to store a value that could be used to better understand the root cause of a safety alarm that has occurred.
9	Diagnostics and Maintenance In this last chapter, concerning diagnostics and maintenance, the Status of EtherCAT connector S8, S9 LEDs will be described.

1.6 NUM Agencies

The list of NUM agencies is given on <https://www.num.com>

Page deliberately empty

1

2

3

4

5

6

7

8

9

Page deliberately empty

Summary

2	General warnings on product use	21
2.1	NUM DrivePro with NUM-SAMX - User's informations	21
2.2	NUM DrivePro with NUM-SAMX unpacking inspection	21
2.3	General drives installation warnings instructions	22
2.4	Drive switched on condition general warnings	23
2.5	View of the hazardous areas around MDLUF units.....	24

1

2

3

4

5

6

7

8

9

Page deliberately empty

2 General warnings on product use

2.1 NUM DrivePro with NUM-SAMX - User's informations

Before connecting, operating or adjusting these products, please read the following User's software information:

NUM DrivePro minimum software release version is 1.2.0 / 2.2.0 / 4.2.0

- NUM-SAMX software release version for Mono-Axis drive is 1.1.0.
- NUM-SAMX software release version for Bi-Axes drive is 2.1.0.
- NUM-SAMX software release version for Quad-Axes drive is 4.1.0.
- The NUM DrivePro reaction to the alarms described in this manual could be defined in NUM DrivePro Parameter Manual M00066 for their setup.



NUM declines all responsibility for injury or damage to persons or objects due to incorrect use of this product.



As described in the present document, NUM-SAMX deals with functional safety (as per EN 61800-5-2).

None of the NUM-SAMX safety functions is related to electrical safety; NUM-SAMX does not guarantee electrical insulation.

Even the Safe Torque Off (STO) function does not remove the electrical connection between drive and motor.

Before any intervention on the drive system, and/or connected motors and devices, the system must be powered-off.

After power off, wait at least 5 minutes before carrying out any operation; It's the time needed to discharge the capacitors of the intermediate circuit.

2.2 NUM DrivePro with NUM-SAMX unpacking inspection

You are advised to check that you have all the equipment before starting to install the drive. Please always control the item reference on the package label.



Do not operate if you have recognized a transport damage. In this case contact immediately NUM.




- All the international, state, regional and local standards must be complied with during the installation and during the use of this product. Only properly qualified personnel having extensive knowledge in servo drive system should install, commission and/or maintain the product.
- To comply with current safety regulations, all wiring and connections must be made in accordance with the electrical diagrams shown in this manual.
NUM declines all responsibility for injury or damage to persons or objects due to incorrect use of this product.
- During the servomotor installation, always make sure that the connection cable used is the one established in NUM DrivePro Installation manual M00067.
The use of an incorrect cable leads to the violation of the international standards.
- NUM drives operate correctly only by distribution systems such as “TN, TT”.
- NUM drives to operate correctly must always be equipped with a line filter.
Please refer to NUM DrivePro Installation manual M00067.
- All the components (PDS, CNC, filter, etc.) must be correctly connected to the cabinet structure. The PDS must be mounted on a earthed unvarnished plate.
For more detailed information please refer to M00067 or M00027 manuals.
- Use only original NUM cables. The original NUM cables have special characteristics.
- The total length of the power cables used in each PDS must be <400m at 5kHz PWM and < 200m at 10kHz PWM.
- The total length of the cable for the drive digital bus interconnections must comply Ethernet 100Base-TX cabling specification.
- The external braking resistor frame may reach high temperatures in the case of a particularly heavy duty. We therefore suggest to place the braking resistors where they will not be accidentally touched by personnel.
- The line filter frame may reach high temperatures. Therefore to facilitate sufficient air circulation and ensure an adequate heat exchange it is recommended that a minimum clearance of 30mm is left when installing the filter in the electrical cabinet.
We therefore suggest to place them where they will not be accidentally touched by personnel.
- The line choke frame may reach high temperatures.
We also suggest to place them where they will not be accidentally touched by personnel.
To prevent eventual electromagnetic disturbances emitted from the inductance, we suggest that it is placed at least 500mm far from particularly sensitive apparatus, from the digital bus flat cable interconnections or from sensor cables.

2.4 Drive switched on condition general warnings



- Before switch on the System cover the energized parts in order to avoid them being touched. Do not touch the electrical components while the system is ON.
- When the drive is switched on, the power components, such as the connectors or braking resistor, are connected to the mains power supply. Be very careful not to touch these components.
- The drive must always be switched off before handling. Wait at least 5 minutes before carrying out any operation, i.e. The time needed for the intermediate circuit capacitors to discharge. (Standard EN60204-1).
A clear warning must be placed on the modules in the relevant language of the country where the equipment is shipped. (Including discharge time)
- During operation, the motor can be stopped by disabled or by the start of speed reference control circuits, whilst the drive remains enabled. To avoid sudden restarting of the system and ensure the safety of operating personnel, ensure that the current is cut off directly on the power circuit.
- In the event of an alarm, the drive is fitted with safety devices which can cause the drive or the motor to stop in the following circumstances: mechanical locking of the motor, voltage variations, break in power supply.
- Elimination of the cause of a stoppage can cause sudden, unexpected restarting of the system which can constitute a hazard in certain conditions, in particular for machines or installations which must comply to EN 60204-1, relating to the safety of electrical machines.

It is therefore important, in these cases, for users to protect themselves against the possibility of sudden restarting by proceeding as indicated above.



NUM declines all responsibility for injury or damage to persons or objects due to incorrect use of this product.

Page deliberately empty

1

2

3

4

5

6

7

8

9

Page deliberately empty

Summary

3	Introduction.....	29
3.1	NUMSafe architecture	29
3.2	NUMSafe system components connection	30
3.3	NUM-SAMX safety module utilisation	31
3.4	Safety functions	32
3.4.1	Automatic mode	34
3.4.2	Other monitoring functions	34
3.4.3	Safety Function Priority	34
3.4.4	Muting and suspension of safety functions	35
3.4.5	Alarm queue managing	35

1

2

3

4

5

6

7

8

9


Page deliberately empty

3 Introduction

3.1 NUMSafe architecture

NUMSafe architecture is typically composed by the following devices:

- FlexiumPro RTK where runs the Flexium PLC and EtherCAT master
- EtherCAT gateway (CTMG1100)
- Safe PLC (CTMP6900 or CTMP1960-2600)
- Safe I/Os (CTMS1904, CTMS2904 and CTMS2912)
- MDLUF with NUM-SAMX option (MDLUF----E-FN01)
- Synchronous and asynchronous motors with and without (sensorless) feedback sensor.



NUMSafe architecture

3.2 NUMSafe system components connection

The following system components can be connected to the system through the safe I/Os:

- Emergency Stop control devices
- Push button for unblocking the power amplifier
- Safety guard position switches or outputs of a optical protection device (e.g. Light curtain)
- Push button for safety guard confirmation
- Operating mode switch for selecting setup mode
- Enabling devices for enabling motor movements in setup mode
- Power contacts for switching external loads, if necessary with linked contacts
- Electromechanical safety guard interlocking.

All safety related information are transmitted over the standard EtherCAT connection (FSoE), together with safety related data.

The wiring is reduced to the minimum and the flexibility and scalability is maximized.

3.3 NUM-SAMX safety module utilisation

The NUM-SAMX safety module can be used to integrate safety functions for personal protection against dangerous movements into the MDLUF drive positioning controllers. (See note hereunder)

The safety module offers various operating modes for:

- safe monitoring of the motor movement and
- safe removal of the motor power supply.

Thanks to the motion monitoring functions it is possible to leave the motor under power, even with the safety door open or the protective devices deactivated. The usual switch off the power is not required. Time-consuming restart procedures are thus not required. This reduces downtime.

This becomes more important the more frequently entry to the danger area is required.


These safety functions enable the more stringent safety requirements for setup mode required by the machine directive to be met.

The components required in conventional safety engineering can be replaced with the NUM Safe devices. These components include:

- Additional position sensors (one per axis)
- Stop position and speed monitor (one per axis)
- Safety relays (Emergency Stop relays)
- Motor power contactors.



NUM-SAMX module requires the connection of the motor sensor onto the P1...P6 connector MDLUF unit (Refer to M00067 manual for detailed information). This reduces the costs for components, installation and also the space required for the system. (See figure)



External versus without NUM-SAMX safety engineering.

3.4 Safety functions

Safety function	Description	Response time	Applicable for synchronous motors with feedback sensor	Applicable for asynchronous motors with feedback sensor	Applicable for sensorless motors
Safe Torque Off (STO)	When the STO function is activated NUM-SAMX module removes power to the motor, that can cause dangerous rotation (or motion in the case of a linear motor). NUM DrivePro will not provide energy to the motor which can generate torque (or force in the case of a linear motor). The activation of the function is performed by means of the NUM-SAMX Logical Input named TorqueEn (False = STO). This function has the highest priority and is performed with the delay defined in parameter <i>S19</i> , if value $\neq 0$.	< 50µs	●	●	●
Safe Stop 2 (SS2)	The SS2 function monitors the motor deceleration rate within set limit (defined by the parameter <i>S23</i>) and initiates the Safe Operating Stop (SOS) monitoring function, when the motor speed is below a specified limit (<i>S16</i>). SS2 is triggered by: An Emergency stop request (NUM-SAMX Logical Input <i>nEstop</i> = 0) or safety function (SLS, SLP, SDI) disobeying. The monitoring of the braking ramp can be delayed by means of the parameter <i>S17</i> or <i>S18</i> .	< 10ms	●	●	
Safe Stop 1 (SS1)	The SS1 function is obtained by enabling STO once the SS2 function is terminated, or initiates the motor deceleration (if configured into drive parameter with <i>V30.5</i> = 1) and initiates the STO function after an application specific time delay (<i>S17</i> or <i>S18</i>). See chapter 6.4.10 for details	< 10ms	●	●	
		(1)			●
Safe Operating Stop (SOS)	The SOS function prevents the motor from deviating more than a defined amount from the stopped position. The NUM DrivePro provides energy to the motor in order to resist to external forces. SOS function is activated automatically at the end of a safe stop (SS2) with safety guard opened or activated opening the safety guard. The safety guard interlock (NUM-SAMX Logical Output InterlockOut) is released when the motor speed is below specified limit (parameter <i>S16</i>).	< 10ms	●		
Safe Speed Monitor (SSM)	The SSM function provides a safe output signal (NUM-SAMX Logical Output Speed) to indicate whether the motor speed is below a specified limit <i>S24</i> . This threshold limit doesn't have relation with the Speed Limits active.	< 10ms	●	●	
		(1)			●
Safely-Limited Speed (SLS)	The SLS function prevents the motor from exceeding specified speed limits. SLS is activated by: - in Automatic Mode if NUM-SAMX parameter <i>S15</i> is different from 0 - with safety guards opened (NUM-SAMX Logical Input GuardCisd = 0) and enabling the NUM-SAMX Logical Input EnablingDevice = 1 and selecting one of 4 speed limits (NUM-SAMX parameter <i>S11</i>...<i>S14</i>) by means of NUM-SAMX Logical Input SpdLm1, SpdLm2, SpdLm3, SpdLm4. - whenever the SLS monitoring functions is disobeyed NUM-SAMX generates a Safety Failure and the SS2 function is triggered (for details see chapter 6.4.8).	< 10ms	●	●	
		(1)			●

Safety function	Description	Response time	Applicable for synchronous motors with feedback sensor	Applicable for asynchronous motors with feedback sensor	Applicable for sensorless motors
Safely-Limited Position (SLP)	The SLP function prevents the axes from exceeding specified position limit(s). SLP is activated with NUM-SAMX Logical Input SfPosition n (n= 0...15) and the specified limits are set by means of the parameter S32...S63. Necessary condition before the activation of the SLP is the execution of the Safe Homing Position. Whenever the SLP functions is disobeyed NUM-SAMX generates a Safety Failure and the SS2 function is triggered (for details see 6.4.8). SLP function is foreseen for linear and rotary limited excursion axes application, it is not foreseen for rotary endless application (rotary axes modulo or spindle). In case of use of absolute measure system, the axis travel must not pass through the 0 absolute position of the measure system.	< 10ms	●		
Safe Direction (SDM)	Safety function SDM (safe direction monitoring) is equivalent to safety function SDI of EN 61800-5-2:2007, with direction monitoring. Whenever the SDM functions is disobeyed NUM-SAMX generates a Safety Failure and the SS2 function is triggered (for details see chapter 6.4.8).	< 10ms	●		
Safe Cams (SCA)	The SCA function offers FSoE Inputs that safely report axis position ranges. This function is automatically disposable when Safe Homing has been completed (SfHomDone = TRUE). Any fault reaction is foreseen from this function. SCA function is foreseen for linear and rotary limited excursion axes application, it is not foreseen for rotary endless application (rotary axes modulo or spindle). In case of use of absolute measure system, the axis travel must not pass through the 0 absolute position of the measure system.	< 10ms	●		

(1) Response time:

- < 100ms on Mono-Axis Drive
- < 150ms on Bi-Axes Drive
- < 200ms on Quad-Axes Drive



Position related safety functions (SLP, SCA and SOS), Safe Stop functions (SS2) and Safe Direction functions (SDI) **are NOT safely supported** for asynchronous motors.



For asynchronous motors, at any transition from higher Speed to lower Speed assuming an Encoder Fault, a time-out value must be calculated.
The motor in free running mode must reach the lower speed within the time-out value. To calculate the value the maximum [motor speed], the inertia and the brake distance must be considered.

3.4.1 Automatic mode

Automatic mode	In Automatic mode the Safe Speed Monitor (SSM) could be enabled. If the Automatic Mode Speed Limit parameter <i>S15</i> is defined > 0, NUM-SAMX in Automatic mode implements the Safe Speed Monitor (SSM) function. When the Automatic Mode Speed Limit <i>S15</i> is disobeyed, NUM-SAMX generates a Safety Failure and the SS2 function is triggered In case <i>S15</i> = 0 the Safe Speed Monitor function is disabled.
-----------------------	--

3.4.2 Other monitoring functions

Temperature monitoring	The temperature of the NUM-SAMX module is monitored. If the temperature exceeds or falls below the permissible operating range, an Alarm is issued to the Drive Controller. The power amplifier is not disabled and the fault reaction under stays the Drive failure reaction setting.
-------------------------------	--

3.4.3 Safety Function Priority

The NUM-SAMX monitors the parameters of the activated safety functions which has been requested by the Safe PLC. In case of parameter violation a Safety Failure is generated and the SS2 function is triggered.

If the braking ramp is not respected NUM-SAMX triggers STO safety function.

The Safe Torque Off has the highest priority. The other safety functions have the same priority: that means that the NUM-SAMX when requested, or as a consequence to system failures, activates the STO function independently by every other safety function activated before.

3.4.4 Muting and suspension of safety functions



It is not possible to exclude the safety functions whenever are activated.

3.4.5 Alarm queue managing

NUM-SAMX manages a queue of 3 alarms that could happens as consequence of an alarm condition. The queued alarms are emitted one at time after cancellation of the previous by means of CNC reset command.

Page deliberately empty

Summary

4	Machine safety and related standards	39
4.1	Introduction	39
4.2	Risk analysis and risk reduction	40
4.3	Contribution to the risk reduction by the electrical control system	41

1

2

3

4

5

6

7

8

9

Page deliberately empty

4 Machine safety and related standards

4.1 Introduction

As a result of automation, demand for increased production and reduced operator physical effort, safety-related part of control system (SRP/CS) of machines play an increasing role in the achievement of overall machine safety.

There are many situations on machines where (SRP/ECS) are employed as part of safety measures that have been provided to achieve risk reduction.

A typical case is the use of an interlocking guard that, when it is opened to allow access to the danger zone, signals the electrical control system to stop hazardous machine operation.

1

2

3

4

5

6

7

8

9

4.2 Risk analysis and risk reduction

The SRP/CS shall be designed and constructed so that the principles of EN ISO 12100:2010 and EN ISO 14121-1:2007 are fully taken into account (see Figures 1 and 3).

All intended use and reasonable foreseeable measure shall be considered.




Figure 1 - Overview of the risk assessment/risk reduction (Taken from EN ISO 13849-1:2015)

The strategy for risk reduction at the machine is given in EN ISO 12100-1:2003/A1:2009. This strategy covers the whole life cycle of the machine.

The hazard analysis and risk reduction process for a machine requires that hazards are eliminated or reduced through a hierarchy of measures:

- hazard elimination or risk reduction by design (see EN ISO 12100-2:2003/A1:2009);
- risk reduction by safeguarding and possibly complementary protective measures (see EN ISO 12100-2:2003/A1:2009);
- risk reduction by the provision of information for use about the residual risk (see EN ISO 12100-2:2003/A1:2009).

4.3 Contribution to the risk reduction by the electrical control system

The design of the SRP/ECS to provide the required risk reduction is an integral subset of the overall design procedure for the machine. The SRP/ECS provides safety function(s) at a PL which achieves the required risk reduction.

In providing safety function(s), either as an inherently safe part of the design or as a control for a safeguard or protective device, the design of the SRP/ECS is a part of the strategy for risk reduction. EN ISO 13849-1:2015 defines the performance levels in terms of probability of dangerous failure per hour.

Five performance levels (a to e) are set out, with defined ranges of probability of a dangerous failure per hour (see Table 3).

Table 3 - Performance levels (PL)

PL	Average probability of dangerous failure per hour 1/h
a	$\geq 10^{-5}$ to $< 10^{-4}$
b	$\geq 3 \times 10^{-6}$ to $< 10^{-5}$
c	$\geq 10^{-6}$ to $< 3 \times 10^{-6}$
d	$\geq 10^{-7}$ to $< 10^{-6}$
e	$\geq 10^{-8}$ to $< 10^{-7}$
Note. Besides the average probability of dangerous failure per hour other measure are also necessary to achieve the PL.	

From the risk assessment (see EN ISO 14121-1:2007) at the machine, the machine builder shall decide the contribution to the reduction of risk which needs to be provided by each relevant safety function which is carried out by the SRP/ECS(s).

This contribution does not cover the overall risk of the machinery under control, e.g. not the overall risk of a mechanical press, or washing machine is considered, but that part of risk reduced by the application of particular safety functions.

Examples of such functions are the stopping function initiated by using an electro-sensitive protective device on a press or the door-locking function of a washing machine.




Figure 3 - Iterative process for design of safety-related parts of control systems (SRP/CS).

Taken from EN ISO 13849-1:2015.



As well being responsible for the risk analysis the machine builder is responsible for validating.

Page deliberately empty

1

2

3

4

5

6

7

8

9

Page deliberately empty

Summary

5	Relevant standards and intended use	47
5.1	NUM-SAMX Functional safety reliability data	47
5.2	Fault Exclusion	48
5.3	Environmental conditions	48
5.4	MDLUF and NUM-SAMX installation and connections.....	48
5.5	Inter operations.....	49
5.5.1	Compatible feedback sensor.....	49
5.5.2	System's SIL / PFH calculation in case of using compatible feedback sensors	50
5.5.3	Reliability data with NUM sensors.....	51

1

2

3

4

5

6

7

8

9

Page deliberately empty

5 Relevant standards and intended use

EN ISO 13849-1:2015	Safety of machinery Safety-related parts of control systems Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery Safety-related parts of control systems Part 2: Validation
EN 60204-1:2018	Safety of machinery Electrical equipment of machines Part 1: General requirements
EN 61800-5-2:2007	Adjustable speed electrical power drive systems Functional Part 5-2: Safety requirements Functional
EN 61800-3:2004/A1:2012	Adjustable speed electrical power drive systems Part 3: EMC requirements and specific test methods
EN 61800-5-1:2007/A11:2021	Adjustable speed electrical power drive systems Part 5-1: Safety requirements - Electrical, thermal and energy
EN 60529:1991/A2:2013/AC:2019-02	Degrees of protection provided by enclosures (IP Code)

5.1 NUM-SAMX Functional safety reliability data

NUM-SAMX is applicable for all applications with synchronous and asynchronous motors for machines where the risk assessment requires additional safety devices.

The reliability parameters of the complete NUM DrivePro power drive system with NUM-SAMX safety module according to IEC/EN 61800-5-2 and EN ISO13849-1/2 are:

Safety reliability data		
Parameter	Value	Measuring unit
Type (according to IEC/EN 61800-5-2)	B	-
Category (according to EN ISO 13849-1/2)	3	-
Architecture (according to IEC/EN 61800-5-2)	1002 (D)	-
HFT (according to IEC/EN 61800-5-2)	1	-
MTTFd (of each channel) (according to EN ISO 13849-1/2)	> 100	Years
DC _{agv} (according to EN ISO 13849-1/2)	> 99	%
SFF (according to IEC/EN 61800-5-2)	> 99	%
PFH / PFH _D	1.48E-09	1/h
CCF	65	-
β factor	2	%
PL (according to EN ISO 13849-1/2)	e	-
SIL (according to IEC/EN 61800-5-2)	3	-

The system is suitable for High demand application. The function can be used during normal machine operation with a daily frequency. The Hardware fault-tolerance is equal to 1, because of the 1oo2 (one out of two) architecture.

Since the safety module contains 2 redundant channels, a single failure does not inhibit the safety function.



The use of the safety module for vertical axis is not permitted without additional means.

5.2 Fault Exclusion



None

5.3 Environmental conditions



Please refer to NUM DrivePro Installation manual M00067 for more detailed informations.



Whenever the safety module is used, the Drive has to be used in a protected environment (min. IP54). The Electrical Cabinet may be applicable for this.

NUM DrivePro must be installed in conformity with the Installation manual M00067.

5.4 MDLUF and NUM-SAMX installation and connections



Please refer to NUM DrivePro Installation manual M00067 for more detailed informations.

5.5 Inter operations

NUM-SAMX safety module can only be used integrated in NUM DrivePro (MDLUF) Power Drive Systems (PDS). It requires external Safe PLC, input modules and it may require external safe output modules (interlock etc); the communication between such external safe devices is realized by means of FSoE.

NUM DrivePro with NUM-SAMX inter operates with the following devices:

- CNC system: FlexiumPro
- Safe PLC: NUMSafe PLC (CTMP6900, CTMP1960-2600)
- Safe input: NUMSafe input terminal (CTMS1904)
- Safe output: NUMSafe output terminal (CTMS2904, CTMS2912)
- EtherCAT Gateway: NUMEtherCAT Gateway (CTMG1100)
- Safe PLC programming tool: "CODESYS Safety for EtherCAT Safety Module"
- Synchronous and Asynchronous motors with a feedback sensor.
- Synchronous and Asynchronous motors without feedback sensor but with some safety function only.

NUM-SAMX is available for Mono-Axis, Bi-Axes and Quad-Axes MDLUF drives.

5.5.1 Compatible feedback sensor

Incremental signal sensor:

- TTL encoder
- sin/cos encoder
- Sick Hiperface encoder with sin/cos signals
- Heidenhain EnDat 2.1 and 2.2 encoder with sin/cos signals
- NUM encoder types: "P", "Q", "J", "K"

Digital sensor:

- Heidenhain EnDat 2.2 encoder without sin/cos signals
- Fagor and Renishaw BISS-C encoder
- Sick Hiperface DSL encoder
- NUM encoder types: "I", "L", "3", "4", "Y", "Z"

For the system's SIL calculation the MTTF declared by the encoder manufacturer has to be taken into account. Please refer to chapter [5.5.2](#)

In case of using Safe encoders, the calculation of the system's PFH is done by adding the encoder PFH to the NUM-SAMX one.

5.5.2 System's SIL / PFH calculation in case of using compatible feedback sensors

$$MTTF_{d(encoder)} = 2 * MTTF_{encoder} \quad (\text{Use encoder manufacturer declared data})$$

$$PFH_{encoder} [1/h] = 1 / MTTF_{d(encoder)} [h]$$

$$PFH_{NUM-SAMX} [1/h] = 1.28 \cdot 10^{-9}$$

$$PFH_{tot} = PFH_{NUM-SAMX} + PFH_{encoder}$$

From PFH_{tot} the associated SIL / PL can be directly determined.
(Please refer to chapter [4.3](#) - Table 3 - Performance levels (PL))



The calculation must be done considering the motor encoder's MTTF.
Additional direct measure sensor are not involved in the calculation.



Position related safety functions (SLP and SOS), Safe Stop functions (SS2) and Safe Direction functions (SDM) **are NOT safely supported** for asynchronous motors.



For asynchronous motors, at any transition from higher Speed to lower Speed assuming an Encoder Fault, a time-out value must be calculated.
The motor in free running mode must reach the lower speed within the time-out value. To calculate the value the maximum motor speed, the inertia and the brake distance must be considered.

5.5.3 Reliability data with NUM sensors

NUM sensor type	MTTF encoder [h]	MTTFd encoder [h]	PFH encoder [1/h]	PFH NUM-SAMX [1/h]	PFH total [1/h]	PL total	Category
P	2.17E+06	4.34E+06	2.30E-07	1.28E-09	2.32E-07	d	3
Q	2.48E+06	4.96E+06	2.02E-07	1.28E-09	2.03E-07	d	3
J	1.58E+06	3.15E+06	3.17E-07	1.28E-09	3.19E-07	d	3
K	1.70E+06	3.40E+06	2.94E-07	1.28E-09	2.96E-07	d	3
I	1.28E+06	2.56E+06	3.91E-07	1.28E-09	3.93E-07	d	3
L	1.38E+06	2.75E+06	3.64E-07	1.28E-09	3.65E-07	d	3
3	Safe encoder	Safe encoder	4.00E-08	1.28E-09	4.17E-08	d	3
4	Safe encoder	Safe encoder	4.00E-08	1.28E-09	4.17E-08	d	3
Y	1.27E+06	2.54E+06	3.94E-07	1.28E-09	3.95E-07	d	3
Z	1.27E+06	2.54E+06	3.94E-07	1.28E-09	3.95E-07	d	3

Page deliberately empty

Summary

6	FSoE I/O, Parameters and Operating modes	55
6.1	FSoE I/O for NUM-SAMX Mono-Axis	55
6.1.1	FSoE Input (NUM-SAMX Logical Output)	55
6.1.2	FSoE Output (NUM-SAMX Logical Input)	56
6.2	FSoE I/O for NUM-SAMX Bi-Axes and Quad-Axes	57
6.2.1	FSoE Input (NUM-SAMX Logical Output)	57
6.2.2	FSoE Output (NUM-SAMX Logical Input)	58
6.3	Parameters	59
6.3.1	General list	59
6.3.2	FSoE Address	60
S2	FSoE Address	60
6.3.3	NUM-SAMX configuration	61
S5	Operational modes	61
6.3.3.1	STO mode	64
6.3.3.2	Sensorless motor managed in V/f mode	64
6.3.4	Sensor configuration	65
S6	Period by turn (V360)	65
S7	Absolute resolution by turn S1 sensor (V361)	65
6.3.4.1	Example of NUM sensor configurations	65
S8	MULTI Coefficient (V306)	66
S9	DIVI Coefficient (V307)	66
6.3.5	Motor poles pairs number	67
S10	Motor pole pairs number (V257)	67
6.3.6	Speed Limit	68
S11	SLS1 Speed limit	68
S12	SLS2 Speed limit	68
S13	SLS3 Speed limit	69
S14	SLS4 Speed limit	69
S15	Automatic mode speed limit	69
6.3.6.1	Calculation of Speed Limit in function of the kinematic chain	70
6.3.7	Motor zero speed threshold	71
S16	Motor standstill threshold	71
6.3.8	Ramp parameters	72
S17	Ramp on E-Stop monitoring delay	72
S18	Ramp on alarm monitoring delay	72
S19	CutOff Delay	72
6.3.8.1	SS2 following an E-Stop command diagram	73
6.3.8.2	Calculation of the deceleration parameters in function of the kinematic chain	74
6.3.9	Position displacement threshold	75
S20	Encoder disalignment threshold	75
S21	Position disalignment threshold for SOS and safe homing	75

S22	Safe homing position	76
S23	Deceleration ramp	76
S24	SSM Speed limit	76
6.3.10	Position parameters.....	77
S32 to S63	Safe position n lower / upper limit	77
6.4	Operating mode	78
6.4.1	Operating mode and transitions diagram	78
6.4.2	Automatic Mode.....	79
6.4.3	Safely-Limited Speed (SLS) - Common rules	80
6.4.3.1	Safely-Limited Speed (SLS) and S5.20 ... 23 = 0	81
6.4.3.2	Safely-Limited Speed (SLS) and S5.20 ... 23 = 1	81
6.4.3.3	Safely-Limited Speed (SLS) and S5.19 = 0.....	81
6.4.3.4	Safely-Limited Speed (SLS) and S5.19 = 1.....	81
6.4.4	Safe Direction (SDI).....	82
6.4.5	Safe Homing	82
6.4.6	Safe Cams (SCA)	82
6.4.6.1	Safe Cams (SCA) functional mode description.....	83
6.4.7	Safely-Limited Position (SLP).....	84
6.4.8	Safe Stop 2 (SS2).....	87
6.4.9	Braking ramp overview	88
6.4.9.1	E-Stop managing	88
6.4.9.2	E-Stop managing failure case.....	89
6.4.9.3	Generic NUM-SAMX Safety Failure case.....	90
6.4.9.4	CNC duplicated or synchronized axes.....	91
6.4.9.5	DRIVE tandem application (AP03,AP04,AP05)	91
6.4.9.6	Check of the braking ramp profile (MPX1)	93
6.4.10	Safe Stop 1 (SS1)	98
6.4.11	Safe Operating Stop (SOS)	99
6.4.12	Safe Torque Off (STO)	99
6.4.13	InterlockOut management	99
6.5	NUM-SAMX Logical Output behaviour	100
6.5.1	Standard mode S5.16 = 0 and S5.17 = 0.....	100
6.5.2	STO mode S5.16 = 1	100
6.5.3	V/f mode S5.17 = 1	101
6.5.4	Not admitted mode S5.16 = 1 and S5.17 = 1	101
6.6	Application example	102
6.6.1	NUM-SAMX Logical Input management with CNC duplicated or synchronized axes	102
6.6.2	NUM-SAMX Logical Input management with DRIVE tandem application	103
6.6.3	NUM-SAMX Logical Input management with CNC synchronized axes and DRIVE tandem application	104
6.6.4	NUM-SAMX Logical Input management with DRIVE in parking.....	105

6 FSoE I/O, Parameters and Operating modes

6.1 FSoE I/O for NUM-SAMX Mono-Axis

6.1.1 FSoE Input (NUM-SAMX Logical Output)

Type	[Bit]	Bit name	Description
Input	[0]	StandStill	See chapter 6.5
	[1]	CutOff	0= STO disabled 1= STO enabled (see chapter 6.5)
	[2]	InterlockOut	0= safety guard opening not allowed 1= safety guard opening allowed (see chapter 6.5)
	[3]	Speed	See chapter 6.5
	[4]	SfPosActive	0= Safe Position Monitoring not active 1= Safe Position Monitoring active
	[5]	TestReqrd	Foreseen for future application
	[6]	SfHomDone	0= Safe homing not yet done 1= Safe homing done
	[7]	SfCam0	0= Axis position outside of safe path 0 limit 1= Axis position inside of safe path 0 limit
Input	[0]	SfCam1	0= Axis position outside of safe path 1 limit 1= Axis position inside of safe path 1 limit
	[1]	SfCam2	0= Axis position outside of safe path 2 limit 1= Axis position inside of safe path 2 limit
	[2]	SfCam3	0= Axis position outside of safe path 3 limit 1= Axis position inside of safe path 3 limit
	[3]	SfCam4	0= Axis position outside of safe path 4 limit 1= Axis position inside of safe path 4 limit
	[4]	SfCam5	0= Axis position outside of safe path 5 limit 1= Axis position inside of safe path 5 limit
	[5]	SfCam6	0= Axis position outside of safe path 6 limit 1= Axis position inside of safe path 6 limit
	[6]	SfCam7	0= Axis position outside of safe path 7 limit 1= Axis position inside of safe path 7 limit
	[7]	SfCam8	0= Axis position outside of safe path 8 limit 1= Axis position inside of safe path 8 limit
Input	[0]	SfCam9	0= Axis position outside of safe path 9 limit 1= Axis position inside of safe path 9 limit
	[1]	SfCam10	0= Axis position outside of safe path 10 limit 1= Axis position inside of safe path 10 limit
	[2]	SfCam11	0= Axis position outside of safe path 11 limit 1= Axis position inside of safe path 11 limit
	[3]	SfCam12	0= Axis position outside of safe path 12 limit 1= Axis position inside of safe path 12 limit
	[4]	SfCam13	0= Axis position outside of safe path 13 limit 1= Axis position inside of safe path 13 limit
	[5]	SfCam14	0= Axis position outside of safe path 14 limit 1= Axis position inside of safe path 14 limit
	[6]	SfCam15	0= Axis position outside of safe path 15 limit 1= Axis position inside of safe path 15 limit
	[7]	Unused	



SfCamx inputs are enabled when **SfHomDone** = 1.

6.1.2 FSoE Output (NUM-SAMX Logical Input)

Type	[Bit]	Bit name	Description
Output	[0]	TorqueEn	0= STO enabled 1= STO disabled
	[1]	nE-Stop	0= E-Stop enabled → SS2 functions is triggered 1= E-Stop disabled
	[2]	GuardClsd	0= Safety guard open 1= Safety guard closed → Automatic Mode
	[3]	EnablingDevice	1= Jog movements are possible at limited Speed
	[4]	SpdLm1	1= Speed limit 1 (S11) selected
	[5]	SpdLm2	1= Speed limit 2 (S12) selected
	[6]	SpdLm3	1= Speed limit 3 (S13) selected
	[7]	SpdLm4	1= Speed limit 4 (S14) selected
Output	[0]	SfPosition0	0= Safe position 0 disabled 1= Safe position 0 enabled
	[1]	SfHoming	1 = Safe homing position reached
	[2]	SfDirPlus	1= Movements in position increment direction are allowed
	[3]	SfDirMinus	1= Movements in position decrement direction are allowed
	[4]	SfPosition1	0= Safe position 1 disabled 1= Safe position 1 enabled
	[5]	SfPosition2	0= Safe position 2 disabled 1= Safe position 2 enabled
	[6]	SfPosition3	0= Safe position 3 disabled 1= Safe position 3 enabled
	[7]	SfPosition4	0= Safe position 4 disabled 1= Safe position 4 enabled
Output	[0]	SfPosition5	0= Safe position 5 disabled 1= Safe position 5 enabled
	[1]	SfPosition6	0= Safe position 6 disabled 1= Safe position 6 enabled
	[2]	SfPosition7	0= Safe position 7 disabled 1= Safe position 7 enabled
	[3]	SfPosition8	0= Safe position 8 disabled 1= Safe position 8 enabled
	[4]	SfPosition9	0= Safe position 9 disabled 1= Safe position 9 enabled
	[5]	SfPosition10	0= Safe position 10 disabled 1= Safe position 10 enabled
	[6]	SfPosition11	0= Safe position 11 disabled 1= Safe position 11 enabled
	[7]	SfPosition12	0= Safe position 12 disabled 1= Safe position 12 enabled
Output	[0]	SfPosition13	0= Safe position 13 disabled 1= Safe position 13 enabled
	[1]	SfPosition14	0= Safe position 14 disabled 1= Safe position 14 enabled
	[2]	SfPosition15	0= Safe position 15 disabled 1= Safe position 15 enabled
	[3,4,5,6,7] Unused		

6.2 FSoE I/O for NUM-SAMX Bi-Axes and Quad-Axes

6.2.1 FSoE Input (NUM-SAMX Logical Output)

Type	[Bit]	Bit name	Description
Input	[0]	Axn_StandStill	See chapter 6.5
	[1]	Axn_CutOff	0= STO disabled 1= STO enabled (See chapter 6.5)
	[2]	Axn_InterlockOut	0= safety guard opening not allowed 1= safety guard opening allowed (See chapter 6.5)
	[3]	Axn_Speed	See chapter 6.5
	[4]	Axn_SfPosActive	0= Safe Position Monitoring not active 1= Safe position Monitoring active
	[5]	TestReqrd	Foreseen for future application
	[6]	Axn_SfHomDone	0= Safe homing not yet done 1= Safe homing done
	[7]	Axn_SfCam0	0= Axis position outside of safe path 0 limit 1= Axis position inside of safe path 0 limit
Input	[0]	Axn_SfCam1	0= Axis position outside of safe path 1 limit 1= Axis position inside of safe path 1 limit
	[1]	Axn_SfCam2	0= Axis position outside of safe path 2 limit 1= Axis position inside of safe path 2 limit
	[2]	Axn_SfCam3	0= Axis position outside of safe path 3 limit 1= Axis position inside of safe path 3 limit
	[3]	Axn_SfCam4	0= Axis position outside of safe path 4 limit 1= Axis position inside of safe path 4 limit
	[4]	Axn_SfCam5	0= Axis position outside of safe path 5 limit 1= Axis position inside of safe path 5 limit
	[5]	Axn_SfCam6	0= Axis position outside of safe path 6 limit 1= Axis position inside of safe path 6 limit
	[6]	Axn_SfCam7	0= Axis position outside of safe path 7 limit 1= Axis position inside of safe path 7 limit
	[7]	Axn_SfCam8	0= Axis position outside of safe path 8 limit 1= Axis position inside of safe path 8 limit
Input	[0]	Axn_SfCam9	0= Axis position outside of safe path 9 limit 1= Axis position inside of safe path 9 limit
	[1]	Axn_SfCam10	0= Axis position outside of safe path 10 limit 1= Axis position inside of safe path 10 limit
	[2]	Axn_SfCam11	0= Axis position outside of safe path 11 limit 1= Axis position inside of safe path 11 limit
	[3]	Axn_SfCam12	0= Axis position outside of safe path 12 limit 1= Axis position inside of safe path 12 limit
	[4]	Axn_SfCam13	0= Axis position outside of safe path 13 limit 1= Axis position inside of safe path 13 limit
	[5]	Axn_SfCam14	0= Axis position outside of safe path 14 limit 1= Axis position inside of safe path 14 limit
	[6]	Axn_SfCam15	0= Axis position outside of safe path 15 limit 1= Axis position inside of safe path 15 limit
	[7]	Unused	-



Axn_ means **Ax1_** : axis 1 or **Ax2_** : axis 2 or **Ax3_** : axis 3 or **Ax4_** : axis 4.

Axn_SfCamx are enabled when **Axn_SfHomDone** = 1.

6.2.2 FSoE Output (NUM-SAMX Logical Input)

Type	[Bit]	Bit name	Description
Output	[0]	Axn_TorqueEn	0= STO enabled 1= STO disabled
	[1]	Axn_nE-Stop	0= E-Stop enabled → SS2 functions is triggered 1= E-Stop disabled
	[2]	Axn_GuardClsd	0= Safety guard open 1= Safety guard closed → Automatic Mode
	[3]	Axn_EnablingDevice	1= Jog movements are possible at limited Speed
	[4]	Axn_SpdLm1	1= Speed limit 1 (S11) selected
	[5]	Axn_SpdLm2	1= Speed limit 2 (S12) selected
	[6]	Axn_SpdLm3	1= Speed limit 3 (S13) selected
	[7]	Axn_SpdLm4	1= Speed limit 4 (S14) selected
Output	[0]	Axn_SfPosition0	0= Safe position 0 disabled 1= Safe position 0 enabled
	[1]	Axn_SfHoming	1 = Safe homing position reached
	[2]	Axn_SfDirPlus	1= Movements in position increment direction are allowed
	[3]	Axn_SfDirMinus	1= Movements in position decrement direction are allowed
	[4]	Axn_SfPosition1	0= Safe position 1 disabled 1= Safe position 1 enabled
	[5]	Axn_SfPosition2	0= Safe position 2 disabled 1= Safe position 2 enabled
	[6]	Axn_SfPosition3	0= Safe position 3 disabled 1= Safe position 3 enabled
	[7]	Axn_SfPosition4	0= Safe position 4 disabled 1= Safe position 4 enabled
Output	[0]	Axn_SfPosition5	0= Safe position 5 disabled 1= Safe position 5 enabled
	[1]	Axn_SfPosition6	0= Safe position 6 disabled 1= Safe position 6 enabled
	[2]	Axn_SfPosition7	0= Safe position 7 disabled 1= Safe position 7 enabled
	[3]	Axn_SfPosition8	0= Safe position 8 disabled 1= Safe position 8 enabled
	[4]	Axn_SfPosition9	0= Safe position 9 disabled 1= Safe position 9 enabled
	[5]	Axn_SfPosition10	0= Safe position 10 disabled 1= Safe position 10 enabled
	[6]	Axn_SfPosition11	0= Safe position 11 disabled 1= Safe position 11 enabled
	[7]	Axn_SfPosition12	0= Safe position 12 disabled 1= Safe position 12 enabled
Output	[0]	Axn_SfPosition13	0= Safe position 13 disabled 1= Safe position 13 enabled
	[1]	Axn_SfPosition14	0= Safe position 14 disabled 1= Safe position 14 enabled
	[2]	Axn_SfPosition15	0= Safe position 15 disabled 1= Safe position 15 enabled
	[3,4,5,6,7] Unused		



Axn_ means **Ax1_** : axis 1 or **Ax2_** : axis 2 or **Ax3_** : axis 3 or **Ax4_** : axis 4.

6.3 Parameters

6.3.1 General list

Parameter number	Parameter name	Description	Unit	Range of values	Default value
S2	FSoE Address	Fail Safe over EtherCAT Field Bus address	[]	0 ÷ 65535	0 (Set to invalid by default)
S5	Operational modes	General Configuration See chapter 6.3.3	[]	0h ÷ FFFFFFFFh	0h
S6	Period by turn (V360)	= V360 for Rotary motor ⁽¹⁾ = V259 • 2000000 / V380 for Linear motor ⁽¹⁾	[]	0 ÷ 4294967295	128
S7	Absolute resolution by turn (V361)	= V361 for Rotary motor ⁽¹⁾ = V259 • 2000000 / V381 for Linear motor ⁽¹⁾	[]	0 ÷ 4294967295	1048576
S8	MULTI Coefficient (V306)	Sensor MULTI coefficient	[]	-2147483647 ÷ +2147483647	10000
S9	DIVI Coefficient (V307)	Sensor DIVI coefficient	[]	0 ÷ 4294967295	512
S10	Motor pole pairs number (V257)	= V257 for sensorless Rotary motor	[]	0 ÷ 4294967295	5
S11	SLS1 Speed limit	Safely Limited Speed #1	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	1000
S12	SLS2 Speed limit	Safely Limited Speed #2	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	2000
S13	SLS3 Speed limit	Safely Limited Speed #3	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	3000
S14	SLS4 Speed limit	Safely Limited Speed #4	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	4000
S15	Automatic mode speed limit	Safely Limited Speed in Automatic Mode	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	10000
S16	Motor standstill threshold	Motor Standstill threshold	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	100
S17	Ramp on E-Stop monitoring delay	Delay time for ramp monitoring in case of E-Stop	ms	0 ÷ 65535	150
S18	Ramp on alarm monitoring delay	Delay time for ramp monitoring in case of Safety Failure.	ms	0 ÷ 65535	150
S19	Cutoff delay	Delay time for power stage/motor torque disabled.	ms	0 ÷ 65535	0

Parameter number	Parameter name	Description	Unit	Range of values	Default value
S20	Encoder disalignment threshold	Maximum allowed difference between: - NUM DrivePro sensor counter and NUM-SAMX sensor counter for synchronous motor. - NUM DrivePro motor speed and NUM-SAMX motor speed for asynchronous motor.	[1 motor turn = 65536] for Synchronous motor [1 /10 rpm] for Asynchronous motor	0 ÷ 4294967295	1000
S21	Position disalignment threshold for SOS and safe homing	Position deviation after transition from any mode to Safe Operating Stop (SOS).	CNC IU	0 ÷ 4294967295	100
S22	Safe homing position	Definition of Safe Homing position	CNC IU	-2147483647 ÷ +2147483647	0
S23	Deceleration ramp	Definition of Safe Deceleration ramp	$\left[\frac{rpm}{s} \right]$ or $\left[\frac{2 \cdot Polepitch}{min \cdot s} \right]$	0 ÷ 4294967295	5000
S24	SSM Speed limit	Safe Speed Limit threshold used to manage NUM-SAMX Logical Output Speed (Axxn_Speed)	$\left[\frac{1}{10} rpm \right]$ or $\left[\frac{1}{10} \frac{2 \cdot Polepitch}{min} \right]$	0 ÷ 4294967295	0
S32 to S63	Safe position n lower / upper limit	Definition of lower / upper limit position n (n = 0...15)	CNC IU	-2147483647 ÷ +2147483647	0
⁽¹⁾ Vxxx are NUM DrivePro parameters. Please refer to NUM DrivePro Parameters manual M00066.					

6.3.2 FSoE Address

S2 FSoE Address

General	Unit	Range of values	Default value
	[]	0 ÷ 65535	0 (Set to invalid by default).
Description	Fail Safe over EtherCAT Field Bus address. As well as the drive physical address defined by the dip-switches, each NUM-SAMX must be uniquely identified with a FSoE address. Such address create the link with the Safe PLC master of the FSoE protocol. If the NUM-SAMX is installed on a Bi-axes or Quad-Axes drive each axis must have own FSoE address. The FSoE address must be set also in the NUM-SAMX device inside the FlexiumPro Tools (see chapter 7) .		
Note	Address 0 not allowed.		

6.3.3 NUM-SAMX configuration

S5 Operational modes

General	Unit	Range of values	Default value																																																																																																																																				
	[]	0h ÷ FFFFFFFFh	0h																																																																																																																																				
Description	General Configuration.																																																																																																																																						
Note	S5 Operational modes ☒ Unit ☒ Description ☒ Min ☒ Max ☒ Default <table> <tr> <th>Bit</th><th>Value</th><th>Description</th><th>Def...</th></tr> <tr><td>0</td><td>☐</td><td>Synchronous motor (V255 = 0)</td><td>☐</td></tr> <tr><td>1</td><td>☐</td><td>Asynchronous motor (V255 = 1)</td><td>☐</td></tr> <tr><td>2</td><td>☐</td><td>Linear motor (V255 = 2)</td><td>☐</td></tr> <tr><td>3</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>4</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>5</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>6</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>7</td><td>☐</td><td>Sinus / Cosinus</td><td>☐</td></tr> <tr><td>8</td><td>☐</td><td>Fast serial singleturn</td><td>☐</td></tr> <tr><td>9</td><td>☐</td><td>Fast serial multibiturn</td><td>☐</td></tr> <tr><td>10</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>11</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>12</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>13</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>14</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>15</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>16</td><td>☐</td><td>STO mode</td><td>☐</td></tr> <tr><td>17</td><td>☐</td><td>Sensorless V/F mode (V481.1)</td><td>☐</td></tr> <tr><td>18</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>19</td><td>☐</td><td>Enabling device release starts SS2 monitoring ramp</td><td>☐</td></tr> <tr><td>20</td><td>☐</td><td>STO after SLS1 trip</td><td>☐</td></tr> <tr><td>21</td><td>☐</td><td>STO after SLS2 trip</td><td>☐</td></tr> <tr><td>22</td><td>☐</td><td>STO after SLS3 trip</td><td>☐</td></tr> <tr><td>23</td><td>☐</td><td>STO after SLS4 trip</td><td>☐</td></tr> <tr><td>24</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>25</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>26</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>27</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>28</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>29</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>30</td><td>☐</td><td>unused</td><td>☐</td></tr> <tr><td>31</td><td>☐</td><td>unused</td><td>☐</td></tr> </table>			Bit	Value	Description	Def...	0	☐	Synchronous motor (V255 = 0)	☐	1	☐	Asynchronous motor (V255 = 1)	☐	2	☐	Linear motor (V255 = 2)	☐	3	☐	unused	☐	4	☐	unused	☐	5	☐	unused	☐	6	☐	unused	☐	7	☐	Sinus / Cosinus	☐	8	☐	Fast serial singleturn	☐	9	☐	Fast serial multibiturn	☐	10	☐	unused	☐	11	☐	unused	☐	12	☐	unused	☐	13	☐	unused	☐	14	☐	unused	☐	15	☐	unused	☐	16	☐	STO mode	☐	17	☐	Sensorless V/F mode (V481.1)	☐	18	☐	unused	☐	19	☐	Enabling device release starts SS2 monitoring ramp	☐	20	☐	STO after SLS1 trip	☐	21	☐	STO after SLS2 trip	☐	22	☐	STO after SLS3 trip	☐	23	☐	STO after SLS4 trip	☐	24	☐	unused	☐	25	☐	unused	☐	26	☐	unused	☐	27	☐	unused	☐	28	☐	unused	☐	29	☐	unused	☐	30	☐	unused	☐	31	☐	unused	☐
Bit	Value	Description	Def...																																																																																																																																				
0	☐	Synchronous motor (V255 = 0)	☐																																																																																																																																				
1	☐	Asynchronous motor (V255 = 1)	☐																																																																																																																																				
2	☐	Linear motor (V255 = 2)	☐																																																																																																																																				
3	☐	unused	☐																																																																																																																																				
4	☐	unused	☐																																																																																																																																				
5	☐	unused	☐																																																																																																																																				
6	☐	unused	☐																																																																																																																																				
7	☐	Sinus / Cosinus	☐																																																																																																																																				
8	☐	Fast serial singleturn	☐																																																																																																																																				
9	☐	Fast serial multibiturn	☐																																																																																																																																				
10	☐	unused	☐																																																																																																																																				
11	☐	unused	☐																																																																																																																																				
12	☐	unused	☐																																																																																																																																				
13	☐	unused	☐																																																																																																																																				
14	☐	unused	☐																																																																																																																																				
15	☐	unused	☐																																																																																																																																				
16	☐	STO mode	☐																																																																																																																																				
17	☐	Sensorless V/F mode (V481.1)	☐																																																																																																																																				
18	☐	unused	☐																																																																																																																																				
19	☐	Enabling device release starts SS2 monitoring ramp	☐																																																																																																																																				
20	☐	STO after SLS1 trip	☐																																																																																																																																				
21	☐	STO after SLS2 trip	☐																																																																																																																																				
22	☐	STO after SLS3 trip	☐																																																																																																																																				
23	☐	STO after SLS4 trip	☐																																																																																																																																				
24	☐	unused	☐																																																																																																																																				
25	☐	unused	☐																																																																																																																																				
26	☐	unused	☐																																																																																																																																				
27	☐	unused	☐																																																																																																																																				
28	☐	unused	☐																																																																																																																																				
29	☐	unused	☐																																																																																																																																				
30	☐	unused	☐																																																																																																																																				
31	☐	unused	☐																																																																																																																																				

Bit	Bit function	Bit value = 0	Bit value = 1
0	Synchronous motor (V255 = 0)	(1)	Define that the monitored motor is a rotary motor.
1	Asynchronous motor (V255 = 1)	(1)	Define that the monitored motor is an asynchronous motor.
2	Linear motor (V255 = 2)	(1)	Define that the monitored motor is a linear motor.
3	Unused		
4	Unused		
5	Unused		
6	Unused		

Bit	Bit function	Bit value = 0	Bit value = 1
7	Sinus / Cosinus	(2)	Define that the monitored motor is equipped with a sensor with incremental traces (MDLUF parameter V320.2 = 1 or V320.4 = 1) ⁽⁴⁾
8	Fast serial singleturn	(2)	Define that the monitored motor is equipped with a sensor with Fast Serial communication (MDLUF parameter V320.3 = 1 and V365 = 1) ⁽⁴⁾
9	Fast serial multiturn	(2)	Define that the monitored motor is equipped with a sensor with Fast Serial communication (MDLUF parameter V320.3 = 1) multi-turn (MDLUF parameter V365 > 1) ⁽⁴⁾
10	Unused		
11	Unused		
12	Unused		
13	Unused		
14	Unused		
15	Unused		
16	STO mode	All the NUM-SAMX Logical Input are managed to activate the various safety function.	See chapter 6.3.3.1 for details. ⁽³⁾
17	Sensorless V/F mode (V481.1) ⁽⁴⁾ - available only on axis 1		The motor is not equipped with feedback sensor (sensorless). See chapter 6.3.3.2 for details. ⁽³⁾
18	Unused		
19	Enabling device release starts SS2 monitoring ramp	With Safe Limited Speed (SLS) function active, when "Enabling device" is released, if motor speed > S16, SS2 monitor braking is activated and Alarm 61 Ext 10 (or Ext 110) is issued.	With Safe Limited Speed (SLS) function active, when "Enabling device" is released, if motor speed > S16, SS2 monitor braking is activated but no Alarm is issued as for E-Stop managing. S17 E-Stop Ramp Monitoring Delay is used in such case. See chapter 6.4.9.1 for details.
20	STO after SLS1 trip	With SLS1 active, the motor speed goes over S11 value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and SS2 braking monitoring is activated.	With SLS1 active, the motor speed goes over S11 value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and STO function is immediately activated. see chapter 6.4.3 for details.
21	STO after SLS2 trip	With SLS2 active, the motor speed goes over S12 value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and SS2 braking monitoring is activated.	With SLS2 active, the motor speed goes over S12 value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and STO function is immediately activated. see chapter 6.4.3 for details.

Bit	Bit function	Bit value = 0	Bit value = 1
22	STO after SLS3 trip	With SLS2 active, the motor speed goes over <i>S13</i> value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and SS2 braking monitoring is activated.	With SLS3 active, the motor speed goes over <i>S13</i> value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and STO function is immediately activated. see chapter 6.4.3 for details.
23	STO after SLS4 trip	With SLS4 active, the motor speed goes over <i>S14</i> value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and SS2 braking monitoring is activated.	With SLS4 active, the motor speed goes over <i>S14</i> value, NUM-SAMX goes in Alarm 61 Ext 2 (or Ext 102) and STO function is immediately activated. see chapter 6.4.3 for details.
24	Unused		
25	Unused		
26	Unused		
27	Unused		
28	Unused		
29	Unused		
30	Unused		
31	Unused		
⁽¹⁾ One and only one of the bits 0,1,2 must be set otherwise Alarm 64 Ext 70 (or Ext 170) ⁽²⁾ One and only one of the bits 7,8,9 must be set otherwise Alarm 64 Ext 71 (or Ext 171) ⁽³⁾ One and only one of the bits 16,17 could be set. If both bits are set Alarm 64 Ext 72 (or Ext 172) is issued. ⁽⁴⁾ Vxxx are NUM DrivePro parameters. Please refer to NUM DrivePro Parameters manual M00066.			

1

2

3

4

5

6

7

8

9

6.3.3.1 STO mode

S5 = 10000h

It is useful with sensorless motors.

NUM-SAMX manages only the Logical Input: **TorqueEn**.

If one of the Logical Inputs **GuardClsd** or **nE-Stop** becomes = 0

or one of the Logical Inputs: **SfHoming**, **SfDirPlus**, **SfDirMinus**, **SpdLmn** becomes = 1

the NUM-SAMX goes in STO mode and an alarm will issue

- Safe Position function is not allowed
- Safe Direction Monitoring function is not allowed
- Logical Output **SfCamx** are disabled,
- Logical Output **StandStill** and **Speed** are now static always FALSE,
- Automatic Mode speed control must be disabled with S15 = 0 otherwise Alarm 64 Ext 40 (or Ext 140)
- Safe limited speed (SLS) is not allowed.
- Standstill control must be disabled with S16 = 0 otherwise Alarm 64 Ext 33 (or Ext 133)

It behaves like a Safe Torque Off board without axis position and speed surveillance

Using parameters S17 and S18, the user can configure the braking delay in case of Emergency Stop or Alarm to trigger an emergency braking procedure (not supervised) before activating the Safe Torque Off function.

Setting S17=0 and S18=0 will cause an immediate Safe Torque Off in case of Emergency Stop or Alarm.

6.3.3.2 Sensorless motor managed in V/f mode

The sensorless V/f mode is only available on motor M1 on Bi-axes or Quad-Axes drive.

When the management of a sensorless motor in V/f mode is activated by means of S5.17 = 1, only SLS, SSM and STO function are available.

The request of activation of other functions will issue alarms:

- Safe Position function is not allowed;
- Safe Direction Monitoring function is not allowed;
- Logical Output SfCamx are disabled (always false);
- Standstill control must be disabled with S16 = 0 otherwise Alarm 64 Ext 33 (or Ext 133).

The status of the logical outputs is described on chapter [6.5.3](#)

Due to the delay on motor speed computation in NUM-SAMX, this fact must be taken into account in S17 and S18 value definition to avoid unexpected Alarm 61 Ext 11 (or Ext 111).



In case of Bi-Axes or Quad-Axes drive the activation of the sensorless motor management could be done on motor M1 only, otherwise Alarm 64 Ext 30 (or Ext 130) will issue.

6.3.4 Sensor configuration

S6 Period by turn (V360)

General	Unit	Range of values	Default value
	[]	0 ÷ 4294967295	128
Description	The value of this parameter must be: = V360 for Rotary motor ⁽¹⁾ = V259 • 2000000 / V380 for Linear motor ⁽¹⁾		
Note	⁽¹⁾ Vxxx are NUM DrivePro parameters. Please refer to NUM DrivePro Parameters manual M00066		

S7 Absolute resolution by turn S1 sensor (V361)

General	Unit	Range of values	Default value
	[]	0 ÷ 4294967295	1048576
Description	The value of this parameter must be: = V361 for Rotary motor ⁽¹⁾ = V259 • 2000000 / V381 for Linear motor ⁽¹⁾ .		
Note	⁽¹⁾ Vxxx are NUM DrivePro parameters. Please refer to NUM DrivePro Parameters manual M00066.		

6.3.4.1 Example of NUM sensor configurations

Encoder type	Parameter number / value
- Encoder type 3 Hiperface DSL SIL2 - Encoder type 4 Hiperface DSL SIL2 - Encoder type L Hiperface DSL - Encoder type I Hiperface DSL	S5 bit 7 = 0, bit 8 = 1, bit 9 = 0 (type 4, L) S5 bit 7 = 0, bit 8 = 0, bit 9 = 1 (type 3, I) S6 = 128 S7 = 1048576
- Encoder type Z Hiperface DSL - Encoder type Y Hiperface DSL	S5 bit 7 = 0, bit 8 = 1, bit 9 = 0 (type Z) S5 bit 7 = 0, bit 8 = 0, bit 9 = 1 (type Y) S6 = 2048 S7 = 16777216
- Encoder type P Hiperface SIN/COS - Encoder type Q Hiperface SIN/COS	S5 bit 7 = 1, bit 8 = 0, bit 9 = 0 S6 = 1024 S7 = 32768
- Encoder type J Hiperface SIN/COS - Encoder type K Hiperface SIN/COS	S5 bit 7 = 1, bit 8 = 0, bit 9 = 0 S6 = 128 S7 = 4096

S8 **MULTI Coefficient (V306)**

General	Unit	Range of values	Default value
	[]	-2147483647 ÷ +2147483647	10000
Description	Sensor MULTI coefficient.		
Note	-		

S9 **DIVI Coefficient (V307)**

General	Unit	Range of values	Default value
	[]	0 ÷ 4294967295	512
Description	Sensor DIVI coefficient		
Note	-		

6.3.5 Motor poles pairs number

S10 Motor pole pairs number (V257)

General	Unit	Range of values	Default value
	[]	0 ÷ 4294967295	5
Description	This parameter define the motor pair pole number. It must be equal to NUM DrivePro parameter V257. This parameter is relevant only in case of sensorless motor (S5.17 = 1) managing.		
Note	-		

6.3.6 Speed Limit

The selection of the Safe Limited Speed values ("Speed Limit 1" ... "Speed Limit 4") is done by means of the NUM-SAMX Logical Input **SpdLm1 ... SpdLm4 (A_{xn}_SpdLm1 ... A_{xn}_SpdLm4)** respectively.

The activation of the selected Safe Limited Speed (SLS) is done when NUM-SAMX Logical Input **GuardClsd = 0 (A_{xn}_GuardClsd = 0)** and NUM-SAMX Logical Input **EnablingDevice = 1 (A_{xn}_EnablingDevice = 1)**

When activation of the Safe Limited Speed is required

in case:

all NUM-SAMX Logical Input **SpdLmn (A_{xn}_SpdLmn)** are = 0

or

more then one NUM-SAMX Logical Input **SpdLmn (A_{xn}_SpdLmn)** is = 1

or

the value of the selected speed limit is = 0,

NUM-SAMX will release a Safety Alarm 62 Ext 1.

Once SLS monitoring function is activated the |motor speed| cannot exceed the limit defined in the parameter Speed Limit n selected, otherwise Alarm 61 Ext 2 (or 102) will release.

NUM-SAMX offers the possibility to monitor the speed also during Automatic Mode when $S15 \neq 0$.

When $S15 = 0$ no speed monitoring in Automatic Mode is performed.

When speed monitoring is active in Automatic Mode, the |motor speed| cannot exceed the limit defined in $S15$, otherwise Alarm 61 Ext 1 (or 101) will release.

The basic calculation formulas to define the speed limit in function of the kinematic chain is explained in chapter [6.3.6.1](#)

S11 SLS1 Speed limit

General	Unit	Range of values	Default value
	$\left[\frac{1}{10} \text{ rpm} \right] \text{ or } \left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	1000
Description	Safely Limited Speed #1		
Note	Must be $S11 > S16$ In case of sensorless motor managing ($S5.17 = 1$), must be $S11 \geq 6000 / S10$, otherwise Alarm 64 Ext 32 (or Ext 132) will be issued.		

S12 SLS2 Speed limit

General	Unit	Range of values	Default value
	$\left[\frac{1}{10} \text{ rpm} \right] \text{ or } \left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	2000
Description	Safely Limited Speed #2		
Note	Must be $S12 > S16$ In case of sensorless motor managing ($S5.17 = 1$), must be $S12 \geq 6000 / S10$, otherwise Alarm 64 Ext 32 (or Ext 132) will be issued.		

S13 SLS3 Speed limit

General	Unit	Range of values	Default value
	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	3000
Description	Safely Limited Speed #3		
Note	Must be S13 > S16 In case of sensorless motor managing (S5.17 = 1), must be S13 ≥ 6000 / S10, otherwise Alarm 64 Ext 32 (or Ext 132) will be issued.		

S14 SLS4 Speed limit


General	Unit	Range of values	Default value
	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	4000
Description	Safely Limited Speed #4.		
Note	Must be S14 > S16 In case of sensorless motor managing (S5.17 = 1), must be S14 ≥ 6000 / S10, otherwise Alarm 64 Ext 32 (or Ext 132) will be issued.		

S15 Automatic mode speed limit

General	Unit	Range of values	Default value
	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	32767
Description	Safely Speed Monitor enabled in Automatic Mode if S15 > 0		
Note	Must be S15 > S16 In case of sensorless motor managing (S5.17 = 1), must be S15 ≥ 6000 / S10, otherwise Alarm 64 Ext 32 (or Ext 132) will be issued. S15=0 -> no speed monitor in Automatic Mode		

6.3.6.1 Calculation of Speed Limit in function of the kinematic chain


Case 1) Linear axis with ball screw



$$Z_{gear} = \frac{Z_2}{Z_1}$$

$$Speed\ Limit\ n\ [1/10\ rpm] = LinearAxisSpeed\ \left[\frac{m}{min} \right] \cdot \frac{Z_{gear}}{ScrewPitch\ \left[\frac{mm}{rev} \right]} \cdot 10000$$


Case 2) Rotary axis



$$Z_{gear} = \frac{Z_2}{Z_1}$$

$$Speed\ Limit\ n\ [1/10\ rpm] = RotaryAxisSpeed\ [rpm] \cdot Z_{gear} \cdot 10$$

$$Speed\ Limit\ n\ [1/10\ rpm] = RotaryAxisSpeed\ [^\circ/min] \cdot Z_{gear} \cdot 10/360$$

Case 3) Linear axis with linear motor

Polepitch = linear motor pole pitch [mm] (= V259 NUM DrivePro parameter)

$$\text{Speed Limit } n \left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right] = \frac{\text{LinearAxisSpeed} \left[\frac{\text{m}}{\text{min}} \right]}{2 \cdot \text{Polepitch}} \cdot 10000$$

6.3.7 Motor zero speed threshold**S16 Motor standstill threshold**

General	Unit	Range of values	Default value
	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	0 ÷ 4294967295	100
Description	Motor standstill threshold. When motor speed is lower than S16 the NUM-SAMX StandStill Logical output bit becomes TRUE. In case of STO or sensorless motor managing (S5.16 = 1 or S5.17 = 1) the NUM-SAMX StandStill Logical output bit is always FALSE.		
Note	Such threshold is also used to trigger the SOS function following a safe deceleration process. The basic calculation formulas in function of the kinematic chain are identical to the ones defined in the chapter 6.3.6. In case of STO or sensorless motor managing (S5.16 = 1 or S5.17 = 1), must be S16 = 0, otherwise Alarm 64 Ext 33 (or Ext 133) will be issued.		

S17 Ramp on E-Stop monitoring delay

General	Unit	Range of values	Default value
	[ms]	0 ÷ 65535	10
Description	Delay time before ramp monitoring in case of E-Stop or S5.19 = 1 and SLS active and EnablingDevice released		
Note	By means of the S17 it is defined the delay time between the triggering of the stopping process in case of E-Stop activation and the start of the deceleration's monitoring. Used to take into account PLC/CNC response time and NUM-SAMX speed analysis. In case of sensorless motor managing (S5.17 = 1) the suggested value of S17 it should not be less then 140ms for Mono-Axis drive , 190ms for Bi-Axes drive and 250ms for Quad-Axes drive. See chapter 6.3.8.1 In case of STO mode managing (S5.16 = 1) it's the time that must elapse before applying the Safet Torque Off function. During the time the axis can actuate a braking procedure (not monitored).		

S18 Ramp on alarm monitoring delay

General	Unit	Range of values	Default value
	[ms]	0 ÷ 65535	150
Description	Delay time for ramp monitoring in case of Safety Failure.		
Note	By means of the S18 it is defined the delay time between the triggering of the stopping process in case of NUM-SAMX alarm condition activation and the start of the deceleration's monitoring. Used to take into account Drive response time or NUM-SAMX speed analysis. In case of sensorless motor managing (S5.17 = 1) the suggested value of S18 it should not be less then 140ms for Mono-Axis drive, 190ms for Bi-Axes drive and 250ms for Quad-Axes drive. In case of STO mode managing (S5.16 = 1) it's the time that must elapse before applying the Safet Torque Off function. During the time the axis can actuate a braking procedure (not monitored).		

S19 CutOff Delay

General	Unit	Range of values	Default value
	[ms]	0 ÷ 65535	150
Description	Delay time for power stage/motor torque disabled.		
Note	In case of motor brake managed by the drive this delay must be higher then V137 NUM DrivePro parameter to enable the brake locking with the motor with torque.		




The deceleration ramp starting point is calculated considering as starting point the real |motor speed| at the E-Stop or NUM-SAMX alarm condition event.

See drawing example of SS2 following an E-Stop command on [6.3.8.1](#).

The value assigned to S17, S18 and S19 must be checked by the customer during machine safe test certification.

6.3.8.1 SS2 following an E-Stop command diagram



Following an E-Stop an automatic re-start cannot happen. The NUMSafe PLC has got a predefined function block (called FB_E-Stop) for the correct handling of the procedure.

The parameter S23 has to be consistent (or in general lower than) with the FlexiumPro and/or NUM DrivePro deceleration ramps.

6.3.8.2 Calculation of the deceleration parameters in function of the kinematic chain

Case 1) Linear axis with ball screw (See figure chapter 6.3.6.1)

$$S23 \text{ (Brake Ramp)} \left[\frac{rpm}{s} \right] = P32^{(1)} \left[\frac{mm}{s^2} \right] \cdot \frac{Z_{gear}}{ScrewPitch \left[\frac{mm}{rev} \right]} \cdot 60$$

or

$$S23 \text{ (Brake Ramp)} \left[\frac{rpm}{s} \right] = V91^{(2)} \left[\frac{rpm}{s} \right]$$

Case 2) Rotary axis (See figure chapter 6.3.6.1)

$$S23 \text{ (Brake Ramp)} \left[\frac{rpm}{s} \right] = P32^{(1)} \left[\frac{deg}{s^2} \right] \cdot \frac{Z_{gear}}{360} \cdot 60$$

or

$$S23 \text{ (Brake Ramp)} \left[\frac{rpm}{s} \right] = V91^{(2)} \left[\frac{rpm}{s} \right]$$

Case 3) Linear axis with linear motor (See figure chapter 6.3.6.1)

$$S23 \text{ (Brake Ramp)} \left[\frac{2 \cdot Polepitch}{min \cdot s} \right] = P32^{(1)} \left[\frac{mm}{s^2} \right] \cdot \frac{30}{V259}$$

or

$$S23 \text{ (Brake Ramp)} \left[\frac{2 \cdot Polepitch}{min \cdot s} \right] = V93^{(2)} \left[\frac{mm}{s^2} \right] \cdot \frac{30}{V259}$$

⁽¹⁾ S23 (Brake ramp) using CNC ramp.

⁽²⁾ S23 (Brake ramp) using NUM DrivePro ramp.

6.3.9 Position displacement threshold

S20 Encoder disalignment threshold

General	Unit	Range of values	Default value
	[1 motor turn = 65536] for Synchronous or Linear. [1 /10 rpm] for Asynchronous or Sensorless V/f.	0 ÷ 4294967295	1000
Description	Maximum allowed difference between: - NUM DrivePro sensor counter and NUM-SAMX sensor counter for synchronous or linear motor - NUM DrivePro motor speed and NUM-SAMX motor speed for asynchronous motor or Sensorless V/f.  S20 should be tuned during the setup using NUM-SAMX measure point MPX6. Setting S20 to 0 (the check of Alarm 63 Ext 1, Alarm 63 Ext 2, Alarm 63 Ext 101, Alarm 63 Ext 102, Alarm 64 Ext 22, Alarm 64 Ext 122 are disabled) and setting S15 to 0 (the check Alarm 61 Ext 1, Alarm 61 Ext 101 are disabled) to allow tuning. Running the motor at maximum speed in MPX6 is latched the maximum value for S20. The NUM-SAMX measure point value can be read by means of MP401 or MP402 of NUM DrivePro. Transferring the highest value read from CPU1 or CPU2 +10% to S20, the system should run in all operating condition without alarm. In case of Bi-Axes or Quad-Axes drive, the tuning of S20 must be done after the configuration of all axes. In case of Sensorless V/f application (S5.17 = 1), we suggest to make test running the motor from +max to -max rpm will be used on the machine and viceversa. The reset of the value stored into MPX6 is executed when the transition 0->1 of the signal FlexiumPro_NCK.RCNC.Axis[n].SAMX.TorqueEnabled is performed.		
Note	Used to trigger Alarm 63 Ext 1, Alarm 63 Ext 2, Alarm 63 Ext 101, Alarm 63 Ext 102, Alarm 64 Ext 22, Alarm 64 Ext 122.		

S21 Position disalignment threshold for SOS and safe homing

General	Unit	Range of values	Default value
	CNC IU	0 ÷ 4294967295	100
Description	When the SOS function is activated (for example following a safe deceleration, see chapter 6.3.8.1) the motor position is stored and after monitored. In case difference, between the actual motor position and the motor position stored when SOS function has activated, exceeded the threshold define by the parameter S21 an alarm 61 Ext 12 (Alarm 61 Ext 112) is issued and the STO function is activated.		
Note	This parameter is not relevant in case of asynchronous motor management.		

S22 Safe homing positon

General	Unit	Range of values	Default value
	CNC IU	-2147483647 ÷ +2147483647	0
Description	This parameter is used to define the Safe Homing position.		
Note			

S23 Deceleration ramp

General	Unit	Range of values	Default value
	$\left[\frac{rpm}{s} \right]$ or $\left[\frac{2 \cdot Polepitch}{min \cdot s} \right]$	0 ÷ 4294967295	5000
Description	Definition of Safe Deceleration ramp.		
Note	The parameter S23 is used to monitor the motor deceleration (SS2). The violation of the deceleration ramp, by the motor, generates the activation of the STO function.		

S24 SSM Speed limit

General	Unit	Range of values	Default value
	$\left[\frac{1}{10} rpm \right]$ or $\left[\frac{1}{10} \frac{2 \cdot Polepitch}{min} \right]$	0 ÷ 4294967295	0
Description	Safe Speed Limit threshold used to manage NUM-SAMX Logical Output Speed (A_{xn}_Speed)		
Note	If Motor speed < S24 > 0, NUM-SAMX Logical Output Speed (A_{xn}_Speed) = TRUE (See chapter 6.5.4) Motor speed could be read using NUM-SAMX measure point MPX0 from CPU1 and MPX100 from CPU2 on NUM-SAMX by means of MP401 or MP402 on MDLUF drive.		

6.3.10 Position parameters

S32 to S63 Safe position n lower / upper limit

General	Unit	Range of values	Default value
	CNC IU	-2147483647 ÷ +2147483647	0
Description	These parameters are used to define lower / upper position limits for Safe Limited Position n and Safe Cam n (n=0...15).		
Note			

Once SLP monitoring function is activated the axis position cannot exceed the limit defined in the related couple of Safe Limits Position:

- Position n lower limit ≤ Safe axes position ≤ Position n upper limit.

Please refer chapter [6.4.7](#).




All Positions Limit and Homing Position are defined respect to the Machine Origin 'OM' (See FlexiumPro Programming manual M00073)

6.4 Operating mode

6.4.1 Operating mode and transitions diagram




Please refer to the table on chapter 3.4 to control the available Safety functions.



6.4.2 Automatic Mode

The Automatic Mode is the mode where no safety functions are enabled.

In case $S15 \neq 0$ NUM-SAMX implements a motor Safety Speed Limit monitor (see also 6.3.6).



Where: Speed = motor speed

6.4.3 Safely-Limited Speed (SLS) - Common rules

The FSoE output bits are set as follows (pre-conditions):

- **GuardClsd** = 0
- **EnablingDevice** = 1
- **nE-Stop** = 1
- **TorqueEn** = 1
- **SpdLm1** = 1 or **SpdLm2** = 1 or **SpdLm3** = 1 or **SpdLm4** = 1.


In setup mode with movement at least one safe limited speed must be defined at parameter level.

During activation of the **EnablingDevice** FSoE Output through the SafePLC, one of the 4 safe limited speed must be selected.

If

- more than one safe limited speed is selected or
 - no safe limited speed is selected
- a Safety Failure is triggered.

Below the behaviour flow chart when SLS function is active.



Where: Speed = motor speed

6.4.3.1 Safely-Limited Speed (SLS) and S5.20 ... 23 = 0

When a SLS is active and

SpdLm1= 1 and S5.20 = 0 or

SpdLm2= 1 and S5.21 = 0 or

SpdLm3= 1 and S5.22 = 0 or

SpdLm4= 1 and S5.23 = 0,

and the |motor speed| goes over the selected safe limited speed a Safety Failure is triggered.

6.4.3.2 Safely-Limited Speed (SLS) and S5.20 ... 23 = 1

When a SLS is active and

SpdLm1= 1 and S5.20 = 1 or

SpdLm2= 1 and S5.21 = 1 or

SpdLm3= 1 and S5.22 = 1 or

SpdLm4= 1 and S5.23 = 1,

and the |motor speed| goes over the selected safe limited speed the NUM-SAMX goes in alarm and activate immediately the STO function.

6.4.3.3 Safely-Limited Speed (SLS) and S5.19 = 0

When a SLS is active, if the axis is not in standstill condition (speed is higher than S16) and the **EnablingDevice** is released (bit set to zero) a Safety Failure is activated.

6.4.3.4 Safely-Limited Speed (SLS) and S5.19 = 1

When a SLS is active, when the **EnablingDevice** is released (bit set to zero), after the delay S17, the SS2 braking monitoring is activated. No Safety Failure is activated, if the braking monitoring is not violated.

6.4.4 Safe Direction (SDI)

This function is activated through the FSoE output bit **SfDirPlus** or **SfDirMinus**.

When the motor is not at standstill ($|Motor\ speed| > S16$) and the direction is opposite to the admitted the Safety Failure is activated.

6.4.5 Safe Homing

The safe homing requires 2 different and independent position sources.

One source is the Drive and it's homing switch or Absolute encoder (of the motor), the other is the NUM-SAMX sensor position together with a secondary homing switch connected to the Safe input of the Safe PLC (see also chapter [6.3.10](#)).

The safe homing procedure task could be activated, after having recognized NCK homing done.

The safe homing acknowledgment bit (**SfHomDone**) is reset at each power off / on or in case of drive alarm whose require a new homing procedure.

The permitted accuracy and operating limit before homing is one motor turn x PLC cycle.

The below procedure assures the Safe Homing Position management:

- FlexiumPro is homed (by a homing procedure or automatically in case of absolute encoders).
- FlexiumPro and NUM DrivePro communicate the unsafe homed position to NUM-SAMX.
- Move the axis to the safe homing position.
- The operator must confirm, by means of a safe button, that the axis it's located in a certain pre-defined position of the axis travel. The information of the human interaction is passed through the safe PLC to NUM-SAMX using the FSoE bit **SfHoming**.
- Such pre-defined position must be consistent with the S22 parameter +/- S21, if such condition is satisfied the **SfHomDone** bit is set, the **SfCam** are activated and the **SfPosition** could be activated.

6.4.6 Safe Cams (SCA)

The Safe Cams monitoring is a parallel operating mode and under stays the Safe Homing procedure defined in chapter [6.4.5](#).

The Safe Cams (SCA) are automatically enabled when the Safe Homing procedure has been performed with positive result defined by **SfHomDone** = TRUE.

In absence of this acknowledgement bit the Safe Cams are not active.

When SCA are enabled, all the cams are monitored.

The limits used to define the Cams path are the same used to define the SLP.

The SCA, when enabled, are active in any mode (Automatic, Safe Limited Speed,...).


The SCA management doesn't foreseen any Safety Failure reaction by NUM-SAMX, they are signals that could be used into the Safe PLC program to create reaction defined by OEM.

The accuracy of the boundary limits of the Safe Cams compared to the NCK position depends from the accuracy of the Safe Homing procedure and the sensor resolution.

The Safe Cam's hysteresis is not linked to the parameter S21, but has fixed value (500 CNC IU while travelling OUT the Safe Cam zone, 100 CNC IU while travelling IN the Safe Cam zone).

6.4.6.1 Safe Cams (SCA) functional mode description

The Safe Cams functions are showed in the below diagram:



	S32	S34	S33	S35	S36	S37				
SfCam0 path										
SfCam1 path										
SfCam2 path							SfCam0 Output	SfCam1 Output	SfCam2 Output	Safe Homing Done
	X						FALSE	FALSE	FALSE	FALSE
	X						TRUE	FALSE	FALSE	TRUE
		X					TRUE	TRUE	FALSE	TRUE
				X			FALSE	TRUE	FALSE	TRUE
							FALSE	FALSE	FALSE	TRUE
					X		FALSE	FALSE	TRUE	TRUE
X = Axis Position										



SCA function is foreseen for linear and rotary limited excursion axes applications, it is not foreseen for rotary endless applications (rotary axes modulo or spindle). In case of use of absolute measure system, the axis travel must not pass through the 0 absolute position of the measure system.

6.4.7 Safely-Limited Position (SLP)

The Safely-Limited Position is a parallel function and under stays the Safe Homing procedure defined in chapter 6.4.5.

The Safely-Limited Position (SLP) is only accepted by the NUM-SAMX (acknowledgement via FSoE input: **SfPosActive**), if a Safe Homing procedure has been performed with positive result defined by **SfHomDone** = TRUE.

In absence of this acknowledgement bit the safe position function is not active and the Safe PLC program should provide an interlock to the function.

SLP is activated by means of the FSoE Output bits **SfPosition** n (n= 0..15)

More than one **SfPosition** n could be simultaneously activated and their pathes could overlap.

The SLP can be activated in any mode (Automatic, Safely-Limited Speed,...) NUM-SAMX dynamically monitors the direction of motion and issues an alarm if the position hits the defined thresholds (Position n lower limit <= Safe position n <= Position n higher limit), reduced by the brake distance.


In case of Position limit violation NUM-SAMX issue the Safety Failure reaction.

Since the violation of the software limits defined in the parameters can depend only on Software or programming errors of the PLC/CNC and not to H/W failures of Drive or NUM-SAMX, NUM-SAMX will not disable Power (CufOff = false) to permit NUM DrivePro to Stop the Motor.

See diagram on next page.



SLP function is foreseen for linear and rotary limited excursion axes applications, it is not foreseen for rotary endless applications (rotary axes modulo or spindle). In case of use of absolute measure system, the axis travel must not pass through the 0 absolute position of the measure system.



Where:

BD = Brake Distance

Position = Axis position

Speed = |motor speed|

S32 = example of Lower Limit position

S33 = example of Upper Limit position

More than one Safe Limited Position could be activate at the same time and switched on/off during the axis movement. If the safe path defined by the Safe Limited Position limits overlap, they are treated as only one Safe Limited Position path.

SfPosition0 = TRUE	SfPosition1 = TRUE	SfPosition2 = TRUE		S32	S34	S33	S35	S36	S37						
			SfCam0 path												
			SfCam1 path												
			SfCam2 path												
										SfCam0 Output	SfCam1 Output	SfCam2 Output	Safe Ho-ming Done	Safe Position Active	Alarm
.	.	.		X						FALSE	FALSE	FALSE	FALSE	FALSE	NO
.	.	.				X				FALSE	FALSE	FALSE	FALSE	FALSE	NO
.	.	.							X	FALSE	FALSE	FALSE	FALSE	FALSE	NO
.				X						TRUE	FALSE	FALSE	TRUE	TRUE	NO
.					X					TRUE	TRUE	FALSE	TRUE	TRUE	NO
.	.				X					TRUE	TRUE	FALSE	TRUE	TRUE	NO
.	.	.					X			FALSE	TRUE	FALSE	TRUE	TRUE	NO
.		.					X			FALSE	TRUE	FALSE	TRUE	TRUE	YES
.	.	.								FALSE	FALSE	FALSE	TRUE	TRUE	YES
.	.	.							X	FALSE	FALSE	TRUE	TRUE	TRUE	NO
.	.								X	FALSE	FALSE	TRUE	TRUE	TRUE	YES
X = Axis position															

6.4.9 Braking ramp overview

In chapter 6.4.8 we see how NUM-SAMX monitors the motor braking phase, but how the braking phase is managed by the system CNC + NUM DrivePro it depends from the NUM DrivePro parameter configuration.

6.4.9.1 E-Stop managing

It is activated by NUM-SAMX Logical Input **nE-Stop** = 0.

NUM-SAMX informs directly NUM DrivePro that emergency stop as been requested.

The drive reacts based on V31.8 and V31.9 configuration.

In the same time NUM-SAMX jump into State 5, stores the actual |motor speed| and wait *S17* time expiration before to move in State 11 where the braking ramp is checked in agreement with *S23* value.

Case *S5.17* = 0 (motor with sensor feedback)

If the braking ramp is respected, the monitoring of the braking ramp stops when |motor speed| is below *S16* and NUM-SAMX moves in State 6 (SOS), memorize the actual motor (axis) position and starts the monitoring of the motor (axis) position deviation from the previous memorized value.

This deviation must be $\leq S21$.

If this condition has disobeyed the NUM-SAMX moves in State 9 (Safety Failure) (see chapter 6.4.9.3)

If no failure condition happens, the emergency stop request does not create any alarm to the CNC.

Case *S5.17* = 1 (motor V/f sensorless)

If the braking ramp is respected, the monitoring of the braking ramp stops when |motor speed| is below *S16* and NUM-SAMX moves in State 6 (SOS), and after the expiration of the *S19* delay, NUM-SAMX will activate PWM **CutOff** (STO condition).

This delay is useful to allow the motor brake de-energizing if present, before cutting the motor torque.

Case *S5.17* = 1 (STO mode)

If parameter *S17* is set to a value greater than zero, NUM-SAMX will let the braking procedure be executed but not monitored, and after the time set in *S17* is expired, it will execute the Safe Torque Off function.

The parameter *S17* it's dedicated to E-Stop procedure, because G75 CNC function could be needed by the machine application, in this case the requested delay could be longer respect a NUM-SAMX standard braking monitoring delay (*S18*) in case of failure.

- With drive parameter V31.9 = 0
the drive reacts to E-Stop, depending on V31.8 configuration (V31.9 configuration has priority respect V31.8).
 - With drive parameter V31.8 = 0
the drive brakes following the V30.5 configuration, so if V30.5 = 1 the drive will use braking ramp V91 (see M00066 manual for more detailed information)

The drive status signal FlexiumPro_NCK.RCNC.Axis[x].SAMX.EmergencyQuickStop will be put on TRUE by E-Stop procedure activation.

In this case we suggest to put FlexiumPro_NCK.WCNC.Channel[n].EmergencyReq:= FlexiumPro_NCK.RCNC.Axis[x].SAMX.EmergencyQuickStop to avoid following error alarm from CNC or end of movement with axis not position. (See manual M00044 for more detailed information about FlexiumPro_NCK.WCNC.Channel[n].EmergencyReq signal).
 - With drive parameter V31.8 = 1

the drive does not react to E-Stop and follows the reference coming from the CNC.

If the reaction foreseen by means of CNC will not match the configured NUM-SAMX brake ramp definition, the NUM-SAMX will go in State 9 (Safety Failure) (see chapter 6.4.9.3).

The drive status signal FlexiumPro_NCK.RCNC.Axis[x].SAMX.EmergencyQuickStop will be put on TRUE by E-Stop procedure activation.

- With drive parameter V31.9 = 1
the drive informs directly The CNC to activate the G75 function in the channel to which the axis belongs at that time.
If G75 was not foreseen in the part program execution the CNC will react with own alarm.
The external parameter E11022, in the channel to which the axis belongs at that time, is make = 2 to inform that the G75 function is request by NUM-SAMX, the drive follows the reference coming from the CNC.

If the reaction foreseen by means of CNC will not match the configured NUM-SAMX brake ramp definition, the NUM-SAMX will go in State 9 (Safety Failure) (see chapter 6.4.9.3)
The drive status signal FlexiumPro_NCK.RCNC.Axis[x].SAMX.EmergencyStopStatus will be put on TRUE by E-Stop procedure activation.

The drive command signals

FlexiumPro_NCK.WCNC.Axis[x].SAMX.TorqueEnable

and

FlexiumPro_NCK.WCNC.Axis[x].SAMX.ReferenceEnable

have priority respect E-Stop procedure configuration.

6.4.9.2 E-Stop managing failure case

1. During the initial phase, when the function is waiting for S17 delay expiration, if the motor exceeds the selected speed limit ($S15 < 0$ or $S11...S14$ if selected), as consequence NUM-SAMX goes in in State 9 (Safety Failure) and the Alarm 61 Ext 11 (or Alarm 61 Ext 111) is created.
From Safety Failure trigger time, NUM-SAMX switches on waiting for S18 delay expiration, then monitors the braking ramp defined by S23.
The drive brakes the motor following the drive parameter V30.5 rule.
2. During the braking phase monitoring, then after the S17 delay expired, if the |motor speed| is higher then value computed by the braking profile of NUM-SAMX, the NUM-SAMX goes in State 9 (Safety Failure) and the Alarm 61 Ext 11 (or Alarm 61 Ext 111) is created.
After the expiration of the S19 delay, NUM-SAMX will activate PWM **CutOff** (STO condition). This delay is useful to allow the motor brake de-energizing if present, before cutting the motor torque.
The NUM-SAMX before cutting the PWM sends an information to the drive so it can de-energize the motor brake in case, it is managed by the drive itself. The drive de-energize immediately the motor brake and after the drive parameter V137 delay removes the torque to the motor. To agree to this management $S19 > V137$.

6.4.9.3 Generic NUM-SAMX Safety Failure case

The NUM-SAMX goes in Safety Failure State 9 when any monitored parameter has exceeded: motor speed, moving with gate opened without enabling condition active, safe direction, safe limited position, etc. and the related alarm number and extension number is issued.

In this case the braking monitor delay *S18* is used.

The drive brakes the motor following the drive parameter V30.5 rule.

If the braking ramp profile is respected:

Case *S5.17* = 0 (motor with sensor feedback)

If the braking ramp is respected, the monitoring of the braking ramp stops when |motor speed| is below *S16* and NUM-SAMX moves in State 6 (SOS), memorize the actual motor (axis) position and starts the monitoring of the motor (axis) position deviation from the previous memorized value.

This deviation must be $\leq S21$.

If this condition has disobeyed the Alarm 61 Ext 12 (or Alarm 61 Ext 112) is created.

After the expiration of the *S19* delay, NUM-SAMX will activate PWM **CutOff** (STO condition).

This delay is useful to allow the motor brake de-energizing if present, before cutting the motor torque.

Case *S5.17* = 1 (motor V/f sensorless)

If the braking ramp is respected, the monitoring of the braking ramp stops when |motor speed| is below *S16* and NUM-SAMX moves in State 6 (SOS), and after the expiration of the *S19* delay, NUM-SAMX will activate PWM **CutOff** (STO condition).

This delay is useful to allow the motor brake de-energizing if present, before cutting the motor torque.

Case *S5.17* = 1 (STO mode)

If parameter *S18* is set to a value greater than zero, NUM-SAMX will let the braking procedure be executed but not monitored, and after the time set in *S18* is expired, it will execute the Safe Torque Off function.

If the braking ramp profile is disobeyed, the Alarm 61 Ext 11 (or Alarm 61 Ext 111) is created. After the expiration of the *S19* delay, NUM-SAMX will activate PWM **CutOff** (STO condition).

This delay is useful to allow the motor brake de-energizing if present, before cutting the motor torque.

The NUM-SAMX before cutting the PWM sends an information to the drive so it can de-energize the motor brake in case, it is managed by the drive itself. The drive de-energize immediately the motor brake and after the drive parameter V137 delay removes the torque to the motor.

To agree to this management *S19* > V137.

6.4.9.4 CNC duplicated or synchronized axes

In this case we have two or more axes managed by the CNC and for those axes we can configure drive and NUM-SAMX as described in chapters 6.4.9.1, 6.4.9.2, 6.4.9.3, but all the NUM-SAMX involved in such application must be parametrized with the same parameter values.

About the NUM-SAMX Logical Input management, because the axes involved into the application, moves under the same condition, this rule must be taken into account for managing the NUM-SAMX Logical input as showed in chapter 6.6.1.

6.4.9.5 DRIVE tandem application (AP03,AP04,AP05)

In this case we have one axis managed by the CNC and two or more drives and motors used to move the axis. Then we can speak of Drive **Master** and Drive/Drives **Slave**.

We can configure Drive **Master** and NUM-SAMX as described in chapters 6.4.9.1, 6.4.9.2, 6.4.9.3. The Drives **Slave** must be parametrized remembering that the Drives **Slave** are managed by the Drive **Master**.

Knowing if the braking has to be handled by CNC (via G75) or by the drive himself, we will have:

1) if **CNC handles the emergency braking via G75**

then

on Drive **Master**

```
set V30 bit 4 "Acceleration-deceleration ramp (Master) [1=ON]" = 0
set V30 bit 5 "Ramp on braking alarm/reference disable (Master) [1=ON]" = 0
set V31 bit 8 "Braking on Emergency Stop [1=Disabled]" = 0
set V31 bit 9 "Emergency Stop G75 request [1=Enabled]" = 1
set V32 bit 2 "A8: Local link" = 1
set V32 bit 11 "A52: Anti-backlash function" = 1
set V32 bit 13 "A61: Safety Module class 1" = 1
set V32 bit 14 "A62: Safety Module class 2" = 1
```

on Drive **Slave**

```
set V31 bit 1 "Braking when torque disabled [1=Brake]" = 0
set V30 bit 4 "Acceleration-deceleration ramp (Master) [1=ON]" = 0
set V30 bit 5 "Ramp on braking alarm/reference disable (Master) [1=ON]" = 0
set V31 bit 8 "Braking on Emergency Stop [1=Disabled]" = 1
set V31 bit 9 "Emergency Stop G75 request [1=Enabled]" = 0
set V32 bit 2 "A8: Local link" = 0
set V32 bit 11 "A52: Anti-backlash function" = 0
set V32 bit 13 "A61: Safety Module class 1" = 0
set V32 bit 14 "A62: Safety Module class 2" = 0
```

NUM-SAMX on Drive **Master** and Drives **Slave** must have the same parameter value

2) if **DRIVE** handles the emergency braking

then

on Drive **Master**

set V30 bit 4	"Acceleration-deceleration ramp (Master) [1=ON]" = 0
set V30 bit 5	"Ramp on braking alarm/reference disable (Master) [1=ON]" = 1
set V31 bit 8	"Braking on Emergency Stop [1=Disabled]" = 0
set V31 bit 9	"Emergency Stop G75 request [1=Enabled]" = 0
set V32 bit 2	"A8: Local link" = 1
set V32 bit 11	"A52: Anti-backlash function" = 1
set V32 bit 13	"A61: Safety Module class 1" = 1
set V32 bit 14	"A62: Safety Module class 2" = 1
set V91	"Acceleration/deceleration ramp" = proper value...

...you have to know it...

it should be faster than S23 declared in NUM-SAMX

on Drive **Slave**

set V31 bit 1	"Braking when torque disabled [1=Brake]" = 0
set V30 bit 4	"Acceleration-deceleration ramp (Master) [1=ON]" = 0
set V30 bit 5	"Ramp on braking alarm/reference disable (Master) [1=ON]" = 0
set V31 bit 8	"Braking on Emergency Stop [1=Disabled]" = 1
set V31 bit 9	"Emergency Stop G75 request [1=Enabled]" = 0
set V32 bit 2	"A8: Local link" = 0
set V32 bit 11	"A52: Anti-backlash function" = 0
set V32 bit 13	"A61: Safety Module class 1" = 0
set V32 bit 14	"A62: Safety Module class 2" = 0

NUM-SAMX on Drive **Master** and Drives **Slave** must have the same parameter value

Remember:

the Drives **Slave** do NEVER handles the braking !!!
it's always the Drive **Master** that handles the braking

- or committed by CNC
- or managed by drive itself.

About the NUM-SAMX Logical Input management, because the axes involved into the application, moves under the same condition, this rule must be taken into account for managing the NUM-SAMX Logical input as showed in chapter [6.6.2](#) or [6.6.3](#)

6.4.9.6 Check of the braking ramp profile (MPX1)




Fig.1

On Fig.1 we can see an example of motor speed profile (red line) and NUM-SAMX braking ramp profile (green line), we can obtain in case of NUM-SAMX safety condition disobeyed, for example the motor speed is moving over the S15 limit (Automatic Mode Speed Limit).

The braking ramp profile is made by 4 main sections:

- ① The value 0, that is the initial condition
- ② The speed value detected by NUM-SAMX when the NUM-SAMX braking ramp profile is activated and S18 delay
- ③ The NUM-SAMX braking ramp profile used to control the motor braking
- ④ The NUM-SAMX braking ramp profile end

The NUM-SAMX braking ramp profile is activate by two conditions:

case a) A NUM-SAMX safety condition disobeyed

case b) Emergency condition: NUM-SAMX Logical Input **nE-Stop** = 0

The trace showed in Fig. 1 could be obtained configuring the drive oscilloscope trigger:
as indicated in Fig. 2 in case of NUM-SAMX safety condition disobeyed
or
as indicated in Fig. 3 Emergency condition: NUM-SAMX Logical Input **nE-Stop** = 0

The transition ① → ② is the NUM-SAMX braking ramp profile activation

The duration of the section ② depends from the activation condition:

case a) the duration time of section ② is = S18

case b) the duration time of section ② is = S17

The slope of section ③ is = S23

The transition ③ → ④ is visible when the NUM-SAMX braking ramp profile is NOT disobeyed and it is the moment where the NUM-SAMX detects that the motor speed is below S16.

The value of section ④ is = S16

V34 Configuration DF1/DF2 relay [1=Open]				
Bit	Value	Description	Default	
0	☐	Alarm 2: BUS overvoltage	☐	
1	☐	Alarm 3: Motor overtemperature	☐	
2	☐	Alarm 4: Drive overtemperature	☐	
3	☐	Alarm 5: Braking resistor or PWS overtemperature	☐	
4	☐	Alarm 6: Short-circuit to earth	☐	
5	☐	Alarm 7: Auxiliary power supply	☐	
6	☐	Alarm 8: Local link	☐	
7	☐	Alarm 9: S1 sensor	☐	
8	☐	Alarm 10: Timeout	☐	
9	☐	Alarm 11: Overspeed	☐	
10	☐	Alarm 12: Drive overcurrent	☐	
11	☐	Alarm 15: Data memory checksum error	☐	
12	☐	Alarm 16: Incompatible parameters	☐	
13	☐	Alarm 18: Self-calibration	☐	
14	☐	Alarm 37: Following error	☐	
15	☐	Alarm 38: S2 sensor	☐	
16	☐	Alarm 49: I ² t	☐	
17	☐	Alarm 51: Congruence position S1-S2	☐	
18	☐	Alarm 52: Anti-backlash function	☐	
19	☐	Alarm 70: Torque duplication function	☐	

Fig.2

V328 S1 Sensor alarms handling				
Bit	▲	Value	Description	Default
0		☐	Alarms 9 Ext 248/260 exclusion [1=Excluded]	☐
1		☐	Not used	☐
2		☐	EnDat 2.2. sensor CRC error [0=Alarm 9 Ext 259] [1=Warning]	☐
3		☐	Alarms 9 Ext 230/248/254/260/261 exclusion [1=Excluded]	☐
4		☐	UGA misalignment handling [0=Alarm 9 Ext 230] [1=Warning]	☐
5		☐	Alarm 9 Ext 231 exclusion [1=Excluded]	☐
6		☐	Alarm 9 Ext 245 fault-detection signal enabling (pin 21) [1=Enabled]	☐
7		☐	Alarms 9 Ext 60 to 9 Ext 67 Endat2.2 Safety bit [1=Excluded]	☐

Fig.3

1

2

3

4

5

6

7

8

9




Fig.4

On Fig. 4 we can see the case, where the motor braking ramp, doesn't match the NUM-SAMX braking ramp profile. In this case we will receive also the drive Alarm 61 Ext 11 (or Ext 111) created by NUM-SAMX.

In this case we must verify the congruence of S23 with drive parameter V91 or other drive or NCK parameter depending on the motor braking method choosen.

To have a good view of the two slopes, remember to check the scales of the two traces, the scale of the "green line" must be 10 times the "red line", because the motor speed is showed in rpm and the NUM-SAMX braking ramp profile is showed in 0.1 rpm.





Fig.5

On Fig. 5 we can see the case, where the motor braking ramp, doesn't match the NUM-SAMX braking ramp profile. In this case we will receive also the drive Alarm 61 Ext 11 (or Ext 111) created by NUM-SAMX.

In this case we could have S18 or S17 too short.

6.4.10 Safe Stop 1 (SS1)

The SS1 function is obtained by enabling STO (by means of **TorqueEn** = 0) once the SS2 function is terminated (see chapter 6.4.8), or initiates the motor deceleration (if configured into drive parameter with V30.5 = 1) and make STO function after an application specific time delay.




Where: Speed = motor speed

6.4.11 Safe Operating Stop (SOS)

The SOS monitoring function is entered by:

- As conclusion of the SS2 monitoring function in case of **GuardClsd**= 0 and **EnablingDevice** = 0
- **GuardClsd**= 0 in standstill conditions (Speed <= S16) and **EnablingDevice** = 0.



6.4.12 Safe Torque Off (STO)

The STO function is activated by:

- **TorqueEn**=0
- Internal diagnostic failure (fail safe)
- SS2 or SOS disobeyed (Safety Failure).
- SLSn disobeyed and related S5.20 ... 23 = 1
- SOS and S5.17 =1

6.4.13 InterlockOut management

The NUM-SAMX Logical Output **InterlockOut** is set to one only in case the standstill conditions is confirmed, it means Speed < S16 (in this case also the Standstill output is set to one).

Then after opening the safety guard (NUM-SAMX Logical Input **GuardClsd** = 0) the SOS function is activated.

If the motor stays stopped the NUM-SAMX Logical Output **InterlockOut** remains set to one.

After that the Safe Limited Speed function could be activated (**GuardClsd**= 0, **EnablingDevice**= 1, **nE-Stop**= 1, **TorqueEn**= 1, **SpdLmn**= 1) and NUM-SAMX Logical Output **InterlockOut** remains set to one.

6.5 NUM-SAMX Logical Output behaviour

6.5.1 Standard mode $S5.16 = 0$ and $S5.17 = 0$

StandStill = 1 in case of:

- $|\text{motor speed}| \leq S16$

StandStill = 0 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- $|\text{motor speed}| > S16$

CutOff = 1 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- NUM-SAMX Logical Input **TorqueEn** = 0
- As consequence of Alarm 61 Ext 11 (or Ext 111) "Safe deceleration process: not enough brake ramp"
- As consequence of Alarm 61 Ext 12 (or Ext 112) "Safe Operating Stop disobeyed"

CutOff = 0 if no case of **CutOff** = 1

InterlockOut = 1 in case of:

- NUM-SAMX Logical Input **TorqueEn** = 0
- NUM-SAMX Logical Output **Standstill** = 1

InterlockOut = 0 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- NUM-SAMX Logical Output **Standstill** = 0

Speed = 1 in case of:

- $|\text{motor speed}| < S24$ and $S24 > 0$

Speed = 0 in case of:

- $|\text{motor speed}| \geq S24$
- $S24 = 0$

6.5.2 STO mode $S5.16 = 1$

StandStill = 0 always

CutOff = 1 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- NUM-SAMX Logical Input **TorqueEn** = 0

CutOff = 0 if no case of **CutOff** = 1

InterlockOut = 1 in case of:

- NUM-SAMX Logical Input **TorqueEn** = 0

InterlockOut = 0 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- NUM-SAMX Logical Input **TorqueEn** = 1

Speed = 0 always

6.5.3 V/f mode S5.17 = 1

StandStill = 0 always

CutOff = 1 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- NUM-SAMX Logical Input **TorqueEn** = 0
- As consequence of Alarm 61 Ext 11 (or Ext 111) "Safe deceleration process: not enough brake ramp"

CutOff = 0, in the other cases different from cases of **CutOff** = 1

InterlockOut = 1 in case of:

- NUM-SAMX Logical Input **TorqueEn** = 0

InterlockOut = 0 in case of:

- Alarm 63 any extension
- Alarm 64 any extension
- NUM-SAMX Logical Input **TorqueEn** = 1

Speed = 0 always

6.5.4 Not admitted mode S5.16 = 1 and S5.17 = 1

- Alarm 64 ext 31 (or 131) will be issue
- Alarm 64 with other extensions could be issue depending on the other bits selected on S5 parameter

1

2

3

4

5

6

7




8

9

6.6 Application example

6.6.1 NUM-SAMX Logical Input management with CNC duplicated or synchronized axes

???






Because the axes involved into the application, moves under the same condition, this rule must be taken into account for managing the NUM-SAMX Logical Input as showed.

This example is limited to the main NUM-SAMX Logical Input, but could be extended to all the others NUM-SAMX Logical Input required in the customer application.

The condition showed to managed the NUM-SAMX Logical Input must be adapted to the customer application, for example in case the axes duplication function is not always active, in such case the NUM-SAMX Logical Input must be managed in independent mode for each axis.

6.6.2 NUM-SAMX Logical Input management with DRIVE tandem application

???





Because the axes involved into the application, moves under the same condition, this rule must be taken into account for managing the NUM-SAMX Logical Input as showed.

This example is limited to the main NUM-SAMX Logical Input, but could be extended to all the others NUM-SAMX Logical Input required in the customer application.

The condition showed to managed the NUM-SAMX Logical Input must be adapted to the customer application.

6.6.3 NUM-SAMX Logical Input management with CNC synchronized axes and DRIVE tandem application



Because the axes involved into the application, moves under the same condition, this rule must be taken into account for managing the NUM-SAMX Logical Input as showed.

This example is limited to the main NUM-SAMX Logical Input, but could be extended to all the others NUM-SAMX Logical Input required in the customer application.

The condition showed to managed the NUM-SAMX Logical Input must be adapted to the customer application.

6.6.4 NUM-SAMX Logical Input management with DRIVE in parking

When the Drive is set in parking status (V30 bit 30 = 1) the NUM-SAMX Logical Input **TorqueEn** must be set = 0.

The "Drive in parking" status information is disposable on PLC in the bit:
FlexiumPro_NCK.RCNC.Axis[n].SAMX.DriveInParking.

1

2

3

4

5

6

7

8

9

Page deliberately empty

Summary

7	Integration in a FlexiumPro project	109
7.1	Adding and addressing devices in a FlexiumPro project.....	109
7.1.1	Adding an EtherCAT Master to the device tree	109
7.1.2	Adapting the EtherCAT Master settings	110
7.1.3	Adding an EtherCAT gateway (CTMG1100)	110
7.1.4	Adding a CTMP6900 (or CTMS1904 or CTMS2904).....	111
7.1.5	Adding a NUM-SAMX.....	112
7.1.6	Address settings of the NUM-SAMX.....	113
7.1.7	Adding other NUMSafe terminals and NUM DrivePro devices.	114
7.2	Adding a NUM-SAMX Parameters folder.....	115
7.2.1	General setting page	116
7.2.2	NUM-SAMX Device association	117
7.2.3	NUM-SAMX Parameters editor in OFFLINE mode.....	119
7.2.4	NUM-SAMX Parameters editor in ONLINE mode.....	120
7.2.5	Export NUM-SAMX Parameter to a *.samxProParam file	121
7.2.6	Import NUM-SAMX parameter from a *.samxProParam file.....	122
7.2.7	NUM-SAMX Diagnostic in ONLINE mode	123
7.2.7.1	NUM-SAMX Test points in ONLINE mode	124


Page deliberately empty

7 Integration in a FlexiumPro project

7.1 Adding and addressing devices in a FlexiumPro project

7.1.1 Adding an EtherCAT Master to the device tree


A right-click on the controller opens the context menu, from which the “Add device...” command is selected. The “EtherCAT Master” device is then selected in the following dialogue.



Inserting a EtherCAT Master

7.1.2 Adapting the EtherCAT Master settings


A double-click on the “*EtherCAT Master*” device in the device tree opens the associated editor for setting the parameters. In this example the desired network adaptor is selected and the dialogue is quit with “OK”.



Adapting EtherCAT Master settings

7.1.3 Adding an EtherCAT gateway (CTMG1100)


A right-click on the EtherCAT master opens the context menu, from which the “*Add device...*” command is selected. The “*CTMG1100*” device is then selected in the following dialogue.




Adding EtherCAT gateway CTMG1100

7.1.4 Adding a CTMP6900 (or CTMS1904 or CTMS2904)

A right-click on the NUMEtherCAT gateway (CTMG1100) opens the context menu, from which the “Add device...” command is selected. The “CTMP6900” device is then selected in the following dialogue




and added pushing “Add Device”




See manual M00033, M00034, M00035 and M00037 for more informations regarding Safe PLC and Safe I/Os installation and programming.

7.1.5 Adding a NUM-SAMX

A right-click on the EtherCAT master opens the context menu, from which the “Add device...” command is selected. The “SAMX” device (Mono-Axis or Bi-Axes or Quad-Axes) is then selected in the following dialogue





and added pushing “Add Device”



7.1.6 Address settings of the NUM-SAMX


The FSoE address must be then confirmed in the safe Logical I/Os in the following dialogue.



7.1.7 Adding other NUMSafe terminals and NUM DrivePro devices.

Using the same method applied for the CTMP6900, other NUMSafe terminals (CTMS1904 and CTMS2904) can be added as well and the FSoE address is also set in the same manner.


For more details about programming CTMP6900 programming see NUMSafe CTMP6900 Programming manual M00037.



Adding other terminals

7.2 Adding a NUM-SAMX Parameters folder


A right-click on the FlexiumPro_NCK opens the context menu, from which the “Add device...” command is selected. The drive equipped with NUM-SAMX (Mono-Axis or Bi-Axes or Quad-Axes) is then selected in the following dialogue.




Parameters folder selection

7.2.1 General setting page

A double-click on the SAMX parameter folder opens the “General settings” context menu.




NUM-SAMX device association (press Unlock), insert the default password **SAMXSAFE** and press OK.





7.2.2 NUM-SAMX Device association

Select NUM-SAMX logical device respecting the field location of the NUM-SAMX on the drive respect NUM-SAMX device on EtherCAT field.



and press “Apply”



Making “Apply” command the drive parameter V36 and NUM-SAMX parameter S2 will be automatically loaded with NUM-SAMX FSoE address.

The screenshot displays the NUM FlexumPro Tools interface, specifically the 'DigitalAxis_1' parameter editor. The left sidebar shows a project tree with 'Application' and 'PLC Logic' folders. The main window is divided into three panes:

- Parameter editor:** Shows 'DigitalAxis_1 Parameter set:0' with a list of parameters including V30, V31, V32, V33, V34, V35, V36, V37, V43, and V44. The 'V36' parameter is highlighted in yellow.
- C2 Drive configuration:** A table showing drive parameters. The 'V36' parameter is highlighted in yellow.
- C0 Device configuration:** A table showing device parameters. The 'S2' parameter is highlighted in yellow.


The 'V36' parameter is set to 30, and the 'S2' parameter is set to 00000000h. The 'Apply' button is visible at the bottom of the configuration panes.

Name	Value	Unit	Description
V30	00000000h		General drive configuration
V31	00000000h		Dynamic General drive configuration
V32	00000000h		Config. braking following alarms [1=Brake]
V33	7FFFFFFFh		Alarm reset configuration [1=Reset]
V34	00000000h		Configuration DF1/DF2 relay [1=Open]
V35	0		NCK related axis address
V36	30		FSoE address SAMX
V37	1.5	s	Delay time of power detection
V43	10.0	s	Braking Timeout on config. V31, V32


Name	Value	Unit	Description
S2	30		FSoE Address
S5	00000000h		Operational modes

7.2.3 NUM-SAMX Parameters editor in OFFLINE mode


Click on “Parameter editor” to show the parameters page:



Click “Unlock” command to enable the parameters editing.



Insert the password (default value **SAMXSAFE**) and press OK.



7.2.4 NUM-SAMX Parameters editor in ONLINE mode

Click on “Parameter editor” to show the parameters page:

SAMX_0 Unit Description Min Max Default



Name	Value	Unit	Description	Min	Max	Default
S2	30		FSOE Address	0	65535	11
S5	0008020h		Operational modes	00000000h	FFFFFFFFh	00000000h
S6	128		Period by turn (V360)	0	4294967295	128
S7	1048576		Absolute resolution by turn (V361)	0	4294967295	1048576
S8	125		MULTI Coefficient (V306)	-2147483647	2147483647	10000
S9	64		DIVI Coefficient (V307)	0	4294967295	512
S10	5		Motor pole pairs number (V257)	0	4294967295	5
S11	22000	1/10 rpm	SLS1 Speed limit	0	4294967295	1000
S12	55000	1/10 rpm	SLS2 Speed limit	0	4294967295	2000
S13	20000	1/10 rpm	SLS3 Speed limit	0	4294967295	3000
S14	50000	1/10 rpm	SLS4 Speed limit	0	4294967295	4000
S15	66000	1/10 rpm	Automatic mode speed limit	0	4294967295	10000
S16	50	1/10 rpm	Motor standstill threshold	0	4294967295	100
S17	150	ms	Ramp on ESTOP monitoring delay	0	65535	150
S18	150	ms	Ramp on alarm monitoring delay	0	65535	150
S19	0	ms	Cutoff delay	0	65535	0
S20	0		Encoder disalignment threshold	0	4294967295	0
S21	1000	CNC IU	Position disalignment threshold for SO...	0	4294967295	0
S22	0	CNC IU	Safe homing position	-2147483647	2147483647	0
S23	4000	rpm	Deceleration ramp	0	4294967295	5000
S24	1000	1/10 rpm	SSM Speed limit	0	4294967295	0

Colour Legend Clear context Parameter operations: Unlock, Change password, Align Apply Send Cancel

anonymous Last build: 0 0 0 Precompile RUN Program loaded Project user: (nobody)

7.2.5 Export NUM-SAMX Parameter to a *.samxProParam file



Click on “Export”:



7.2.6

Import NUM-SAMX parameter from a *.samxProParam file

Click on “Import”:



7.2.7 NUM-SAMX Diagnostic in ONLINE mode

Click on “Diagnostic” to show the status of the NUM-SAMX FSoE I/Os and NUM-SAMX states.
The map size of the FSoE I/Os depend from the NUM-SAMX revision chosen into the project:

SAMX_5

General settings

Parameter editor

Test Points

Online

Status

Information

True	Torque enable	Stand still	True
True	E-Stop	Cut off	False
True	Guard closed	Interlock out	True
False	Enabling device	Speed	False
False	Speed limit 1	Safe position acti	False
False	Speed limit 2	Test required	False
False	Speed limit 3	Safe homing done	False
False	Speed limit 4	Safe cam 0	False
False	Safe position 0	Safe cam 1	False
False	Safe homing pos.	Safe cam 2	False
False	Safe direction +	Safe cam 3	False
False	Safe direction -	Safe cam 4	False
False	Safe position 1	Safe cam 5	False
False	Safe position 2	Safe cam 6	False
False	Safe position 3	Safe cam 7	False
False	Safe position 4	Safe cam 8	False
False	Safe position 5	Safe cam 9	False
False	Safe position 6	Safe cam 10	False
False	Safe position 7	Safe cam 11	False
False	Safe position 8	Safe cam 12	False
False	Safe position 9	Safe cam 13	False
False	Safe position 10	Safe cam 14	False
False	Safe position 11	Safe cam 15	False
False	Safe position 12		
False	Safe position 13		
False	Safe position 14		
False	Safe position 15		

SAMX states

SAMX state

Automatic mode

SAMX FSoE state



FSoE invalid

7.2.7.1 NUM-SAMX Test points in ONLINE mode

Click on “Test points” to show the Test points page. The test point could be chosen only in ONLINE mode, but the selection remain stored into the NUM-SAMX configuration.

The value took from the NUM-SAMX test point is visible via NUM DrivePro **MP401 and MP402**.

NUM-SAMX has two CPUs so we have to choose the CPU and then the MPX:



Page deliberately empty

1
2
3
4
5
6
7
8
9

Page deliberately empty

Summary

8	NUM-SAMX Measure point MPX list.....	129
8.1	MPX21 meanings	130

1

2

3

4

5

6

7

8

9

Page deliberately empty

8 NUM-SAMX Measure point MPX list

MPX	Description	Unit	Utilisation
MPX0	Motor speed	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	Motor speed calculated by NUM-SAMX based on encoder data.
MPX1	Brake ramp	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	Braking ramp profile generated by NUM-SAMX, starting from the configuration parameters (S23 and (S18 or S17)).
MPX2	Brake ramp starting speed	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	
MPX3	Feedback diagnostic	$\square$	Feedback diagnostic on cutoff lines.
MPX4	Samx state	$\square$	NUM-SAMX state related to its internal state machine.
MPX5	Drive state	$\square$	
MPX6	Encoder disalignment max	$\square$	
MPX7	Encoder disalignment	$\square$	
MPX8	Position	CNC IU	Position in CNC increments calculated by NUM-SAMX based on encoder data.
MPX9	SOS position window	CNC IU	
MPX10	Brake space	CNC IU	Brake space calculated dynamically by the NUM-SAMX when the axis is moving with the Safe Homing procedure done to check if the movement can cause the axis to exceed Safe Position's limits with not enough space to brake.
MPX11	Encoder count	$\square$	
MPX12	Safe position state	$\square$	
MPX13	Safe homing registered position	CNC IU	
MPX14	Safe homing active upper limit	CNC IU	
MPX15	Safe homing active lower limit	CNC IU	
MPX16	Posturn	$\square$	
MPX17	Drive's posturn speed	$\square$	
MPX18	Drive's safe posturn received	$\square$	
MPX19	Posturn difference	$\square$	
MPX20	Device die temperature	Celsius	
MPX21	Failure reason	$\square$	See chapter 8.1

8.1 MPX21 meanings

MPX21 is used to store a value that could be used to better understand the root cause of an occurred Safety Alarm. Its contents and related unit measure depends from the triggered alarm. The contents is cleared when a drive alarm reset is requested, via NCK reset (FlexiumPro_NCK.WCNC.General.Reset).

The description stay valid also for the alarms with Extension higher then 100.

This depend from which NUM-SAMX CPU detects the alarm.

Example:

Alarm 61 Ext 1 is detected by CPU1 and Alarm 61 Ext 101 is the same but detected by CPU2.

The value can be read from the CPU 1 or 2 to which the Alarm belong.

Alarm	Units	Description
61 Ext 1	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	First speed value that exceeded the threshold S15 (Automatic mode)
61 Ext 2	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	First speed value that exceeded the threshold S11... S14 (SLS 1/2/3/4)
61 Ext 3	CNC IU	Safe limited position - lower limit exceeded
61 Ext 4	CNC IU	Safe limited position - upper limit exceeded
61 Ext 5	CNC IU	Position value that is found outside the Safe Position limits
61 Ext 11	$\left[\frac{\text{rpm}}{\text{s}} \right]$ or $\left[\frac{2 \cdot \text{Polepitch}}{\text{min} \cdot \text{s}} \right]$	Safe deceleration - not enough brake ramp
61 Ext 12	CNC IU	Safe operational stop disobeyed - axis exceeded parameter. (S21)
62 Ext 1	[]	CPU1: safe limited speed - invalid SLS selection The showed value is the status of the SLS selection bits
62 Ext 3	°C	System temperature - too high
62 Ext 4	°C	System temperature - too low
63 Ext 1	1/65536 turn	Value greater than S20, that issues the alarm (for synchronous motor S5.1 = 0).
63 Ext 2	$\left[\frac{1}{10} \text{ rpm} \right]$ or $\left[\frac{1}{10} \frac{2 \cdot \text{Polepitch}}{\text{min}} \right]$	Value greater than S20, that issues the alarm (for asynchronous motor S5.1 = 1 and / or for Sensorless V/f motors S5.17=1).
64 Ext 1	V	Hardware error - 3.3V undervoltage/overvoltage
64 Ext 2	V	Hardware error - 5V undervoltage/overvoltage
64 Ext 3	V	Hardware error - 7.5V undervoltage/overvoltage
64 Ext 4	V	CPU1: hardware error - +15V undervoltage/overvoltage
64 Ext 5	V	Hardware error - VDD undervoltage/overvoltage
64 Ext 6	V	Hardware error - VDD_flash undervoltage/overvoltage
64 Ext 8	V	Cutoff feedbacks error - invalid analog value
64 Ext 9	V	Cutoff feedbacks error - invalid logical state
64 Ext 20	[]	CPU1: system error - outputs mismatch CPU1-CPU2 (- 500ms) The showed value is the XOR of the SAMX output bits

Page deliberately empty

1

2

3

4

5

6

7

8

9

Page deliberately empty

Summary

9	Diagnostics and Maintenance	135
9.1	Status of EtherCAT connector S8, S9 LEDs	135
9.2	NUM-SAMX alarms and alarms extension and trouble shooting.....	136
	Alarm 60 Safety Module class 0	136
	Alarm 61 Safety Module class 1	137
	Alarm 62 Safety Module class 2	139
	Alarm 63 Safety Module class 3	140
	Alarm 64 Safety Module class 4	141
9.3	Fault reaction and Response time	144
9.3.1	PDS fault reaction.....	144
9.4	State of being maintained.....	145
9.4.1	Maintenance	145
9.5	Service life	145

1

2

3

4

5

6

7

8

9

Page deliberately empty

9 Diagnostics and Maintenance

9.1 Status of EtherCAT connector S8, S9 LEDs

LEDs EtherCAT status “Yellow LEDs” on both EtherCAT connectors (S8/S9)

LEDs Status	SAMX status	Description
OFF	INITIALIZATION	The SAMX module is in state INIT
Blinking	PRE-OPERATIONAL	The SAMX module is in PRE-OPERATIONAL state
Single Flash	SAFE-OPERATIONAL	The SAMX module is in SAFE-OPERATIONAL state
ON	OPERATIONAL	The SAMX module is in OPERATIONAL state

LEDs Link Ethernet active “Green LEDs” on both EtherCAT connectors (S8/S9)

LEDs Status	Ethernet activitystatus	Description
ON	No link	Ethernet cable unconnected
Single Flash	Link without activity	Ethernet cable connected but without any activity
Blinking	Link and activity	Ethernet cable connected with activity

9.2 NUM-SAMX alarms and alarms extension and trouble shooting

- Safety Class 60 alarms are originated by the NUM DrivePro.
- Safety Class 61, 62, 63, 64 alarms are originated by the NUM-SAMX.

Alarm 60 Safety Module class 0

These alarms are issued by the NUM DrivePro and they are related to the NUM-SAMX Safety board.

This class of alarms are mainly related to setup (Parameterization of NUM DrivePro and NUM-SAMX) and operating conditions.

The Fault reaction is generally STO.

Alarm 60 extension		Trouble shooting
255	NUM-SAMX communication - Togglebit FrameRF does not toggle	NUM-SAMX-SW Error, reboot NUM DrivePro.
256	NUM-SAMX communication - Wrong communication checksum	
259	NUM-SAMX requested by control board but not detected	HW Failure: exchange the NUM DrivePro.
260	NUM-SAMX detected but not requested by control board	Invalid NUM DrivePro Configuration (exchange the NUM DrivePro).
261	NUM-SAMX doesn't communicate	Reboot NUM DrivePro (remove and apply Aux Power) and if the error is still present: SW of NUM-SAMX not working. (Exchange of NUM DrivePro necessary)
262	FSoE address NUM-SAMX doesn't match with the parameter V36	Align the parameters V36 of NUM DrivePro to S2 of NUM-SAMX.
263	NUM-SAMX alarm code not defined	Wrong Alarm Class. (SW error of NUM-SAMX)
300	PWM disabled while axis in Operational state	
301	NUM-SAMX communication - locked: missing msgId increment	
302	NUM-SAMX communication - failure: SAMX receives wrong CRC	
324	NUM-SAMX Safe Homing - timeout writing Safe Homing position	
325	NUM-SAMX Safe Homing - abort writing Safe Homing position	
326	NUM-SAMX Safe Homing - unable to write Safe Homing position	

Alarm 61 Safety Module class 1

These alarms are issued by the NUM DrivePro and they are related to the NUM-SAMX Safety board. This class of alarms are mainly related to wrong parameterization of NUM DrivePro and/or NUM-SAMX and invalid operating conditions.

The Fault reaction is generally SS2.

Alarm 61 extension		Trouble shooting
0	CPU1: class 1 error forced	Undetected fault condition.
1	CPU1: automatic mode speed exceeded (S15) See chapter 8.1	
2	CPU1: SLS mode speed exceeded (S11...S14) See chapter 8.1	
3	CPU1: safe limited position - lower limit exceeded. See chapter 8.1 This alarm is issued if the NUM-SAMX detects a movement (direction and speed related) that will take the position outside the lower limit.	
4	CPU1: safe limited position - upper limit exceeded. See Chapter 8.1 This alarm is issued if the NUM-SAMX detects a movement (direction and speed related) that will take the position outside the upper limit.	
5	CPU1: safe limited position - activated while out of bounds. See chapter 8.1 This alarm is issued if the NUM-SAMX detects a position (axis stopped) outside the position limits.	
6	CPU1: safe direction plus disobeyed	
7	CPU1: safe direction minus disobeyed	
8	CPU1: safe direction invalid - double selection	
9	CPU1: safe homing invalid - position doesn't match parameter (S22)	
10	CPU1: guard closed disobeyed in automatic mode.	
11	CPU1: safe deceleration - not enough brake ramp. See chapter 8.1	
12	CPU1: safe operational stop disobeyed - axis exceeded parameter. (S21). See chapter 8.1	
14	CPU1: STO MODE - SLS speed limit selected while STO mode is active	
15	CPU1: STO or sensorless mode - safe homing requested while STO mode or sensorless mode are active	
16	CPU1: STO MODE - guards closed disobeyed while STO mode is active	
17	CPU1: STO or sensorless mode - safe direction selected while STO mode or sensorless mode are active	
18	CPU1: STO MODE - E-Stop pressed while STO mode is active	
20	CPU1: safe position 0 - limits invalid (S32 - S33)	
21	CPU1: safe position 1 - limits invalid (S34 - S35)	
22	CPU1: safe position 2 - limits invalid (S36 - S37)	
23	CPU1: safe position 3 - limits invalid (S38 - S39)	
24	CPU1: safe position 4 - limits invalid (S40 - S41)	
25	CPU1: safe position 5 - limits invalid (S42 - S43)	
26	CPU1: safe position 6 - limits invalid (S44 - S45)	
27	CPU1: safe position 7 - limits invalid (S46 - S47)	
28	CPU1: safe position 8 - limits invalid (S48 - S49)	
29	CPU1: safe position 9 - limits invalid (S50 - S51)	
30	CPU1: safe position 10 - limits invalid (S52 - S53)	
31	CPU1: safe position 11 - limits invalid (S54 - S55)	
32	CPU1: safe position 12 - limits invalid (S56 - S57)	
33	CPU1: safe position 13 - limits invalid (S58 - S59)	
34	CPU1: safe position 14 - limits invalid (S60 - S61)	
35	CPU1: safe position 15 - limits invalid (S62 - S63)	
100	CPU2: class 1 error forced	Undetected fault condition.
101	CPU2: automatic mode speed exceeded (S15). See chapter 8.1	All the following Alarms are referred to invalid operating conditions or wrong parameterization.
102	CPU2: SLS mode speed exceeded (S11...S14) See chapter 8.1	

Alarm 61 extension		Trouble shooting
103	CPU2: safe limited position - lower limit exceeded. This alarm is issued if the NUM-SAMX detects a movement (direction and speed related) that will take the position outside the lower limit. See chapter 8.1	
104	CPU2: safe limited position - upper limit exceeded. This alarm is issued if the NUM-SAMX detects a movement (direction and speed related) that will take the position outside the upper limit. See chapter 8.1	
105	CPU2: safe limited position - activated while out of bounds See chapter 8.1 This alarm is issued if the NUM-SAMX detects a position (axis stopped) outside the position limits.	
106	CPU2: safe direction plus disobeyed	
107	CPU2: safe direction minus disobeyed	
108	CPU2: safe direction invalid - double selection	
109	CPU2: safe homing invalid - position doesn't match parameter (S22)	
110	CPU2: guard closed disobeyed in automatic mode.	
111	CPU2: safe deceleration - not enough brake ramp. See chapter 8.1	
112	CPU2: safe operational stop disobeyed - axis exceeded parameter (S21). See chapter 8.1	
114	CPU2: STO MODE - SLS speed limit selected while STO mode is active See chapter 8.1	
115	CPU2: STO or sensorless mode - safe homing requested while STO mode or sensorless mode are active	
116	CPU2: STO MODE - guards closed disobeyed while STO mode is active	
117	CPU2: STO or sensorless mode - safe direction selected while STO mode or sensorless mode are active	
118	CPU2: STO MODE - E-Stop pressed while STO mode is active See chapter 8.1	
120	CPU2: safe position 0 - limits invalid (S32 - S33)	
121	CPU2: safe position 1 - limits invalid (S34 - S35)	
122	CPU2: safe position 2 - limits invalid (S36 - S37)	
123	CPU2: safe position 3 - limits invalid (S38 - S39)	
124	CPU2: Safe position 4 - limits invalid (S40 - S41)	
125	CPU2: safe position 5 - limits invalid (S42 - S43)	
126	CPU2: safe position 6 - limits invalid (S44 - S45)	
127	CPU2: Safe position 7 - limits invalid (S46 - S47)	
128	CPU2: safe position 8 - limits invalid (S48 - S49)	
129	CPU2: safe position 9 - limits invalid (S50 - S51)	
130	CPU2: safe position 10 - limits invalid (S52 - S53)	
131	CPU2: safe position 11 - limits invalid (S54 - S55)	
132	CPU2: safe position 12 - limits invalid (S56 - S57)	
133	CPU2: safe position 13 - limits invalid (S58 - S59)	
134	CPU2: safe position 14 - limits invalid (S60 - S61)	
135	CPU2: safe position 15 - limits invalid (S62 - S63)	

Alarm 62 Safety Module class 2

These alarms are issued by the NUM DrivePro and they are related to the NUM-SAMX Safety board.

This class of alarms are mainly related to setup (Parameterization of NUM DrivePro and NUM-SAMX) and operating conditions.

The Fault reaction is generally SS2.

Alarm 62 extension		Trouble shooting
0	CPU1: class 2 error forced	Undetected fault condition.
1	CPU1: safe limited speed - invalid SLS selection See chapter 8.1	The Safe PLC Input Speed selector have an invalid combination.
2	CPU1: system temperature - sensor failure	NUM-SAMX HW Error. (Exchange the NUM DrivePro)
3	CPU1: system temperature - too high. See chapter 8.1	Invalid operating condition. (Control air conditioner of cabinet)
4	CPU1: system temperature - too low. See chapter 8.1	Invalid operating conditions. (Pullover for NUM-SAMX needed)
100	CPU2: class 2 error forced	Undetected fault condition.
101	CPU2: safe limited speed - invalid SLS selection See chapter 8.1	The Safe PLC Input Speed selector have an invalid combination.
102	CPU2: system temperature - sensor failure	NUM-SAMX HW Error. (Exchange the NUM DrivePro)
103	CPU2: system temperature - too high. See chapter 8.1	Invalid operating condition. (Control air conditioner of cabinet)
104	CPU2: system temperature - too low. See chapter 8.1	Invalid operating conditions. (Pullover for NUM-SAMX needed)

1

2

3

4

5

6

7

8

9

Alarm 63 Safety Module class 3

These alarms are issued by the NUM DrivePro and they are related to the NUM-SAMX Safety board.

This class of alarms are mainly related to either invalid Setup conditions (Parameters) or dynamic errors. Generally the motor is moving during the occurrence.

The Fault reaction is STO.

All the NUM-SAMX Logical Output are put = 0 except **CutOff** = 1.

Alarm 63 extension		Trouble shooting
0	CPU1: class 3 error forced	Undetected fault condition.
1	CPU1: system error - encoder disalignment with drive (S20) See chapter 8.1	Encoder Counter mismatch between NUM DrivePro and NUM-SAMX: Align S6/S7 to V360/V361 parameters. Control S20: if the Error appears at high speed increase S20.
2	CPU1: system error - speed disalignment with drive (S20) See chapter 8.1	Chek S6 and S7 values. If the error happens with high accelleration ramp, increase S20 value.
100	CPU2: class 3 error forced	Undetected fault condition.
101	CPU2: system error - encoder disalignment with drive (S20) See chapter 8.1	Encoder Counter mismatch between NUM DrivePro and NUM-SAMX: Align S6/S7 to V360/V361 parameters. Control S20: if the Error appears at high speed increase S20.
102	CPU2: system error - speed disalignment with drive (S20) See chapter 8.1	Chek S6 and S7 values. If the error happens with high accelleration ramp, increase S20 value.

Alarm 64 Safety Module class 4

These alarms are issued by the NUM DrivePro and they are related to the NUM-SAMX Safety board. This class of alarms are related to the result of HW and SW diagnostic tests.

The Fault reaction is STO.

All the NUM-SAMX Logical Output are put = 0 except **CutOff** = 1.

Alarm 64 extension		Trouble shooting
0	CPU1: class 4 error forced	Undetected fault condition.
1	CPU1: hardware error - 3.3V undervoltage/overvoltage See chapter 8.1	HW Error.(Exchange the NUM DrivePro)
2	CPU1: hardware error - 5V undervoltage/overvoltage See chapter 8.1	
3	CPU1: hardware error - 7.5V undervoltage/overvoltage See chapter 8.1	
4	CPU1: hardware error - +15V undervoltage/overvoltage See chapter 8.1	
5	CPU1: hardware error - VDD undervoltage/overvoltage See chapter 8.1	
6	CPU1: hardware error - VDD_flash undervoltage/overvoltage See chapter 8.1	
7	CPU1: communication error - CPU1-CPU2	
8	CPU1: cutoff feedbacks error - invalid analog value See chapter 8.1	
9	CPU1: cutoff feedbacks error - invalid logical state See chapter 8.1	
10	CPU1: system error - serial number mismatch with drive, default parameters reloaded	Change the Parameter File or at least one parameter and reset the alarm.
11	CPU1: system error - parameters' CRC mismatch CPU1-CPU2	The Checksum of the User Parameter file is different. Since it is not possible to know what parameters does not match: 1. Save parameter file to HD. 2. Reload the Parameter file. 3. Reset the Error.
12	CPU1: system critical error - stack overflow	SW Error: Control SW Release and known bug list (if any).
13	CPU1: system critical error - instruction memory corruption	HW Error. (Exchange the NUM DrivePro)
14	CPU1: system critical error - flash data memory corruption	Reload Application SW and FW.
15	CPU1: system error - parameters' CRC invalid	Reload Parameter file.
16	CPU1: system critical error - L1 cache corruption	HW Error. (Exchange the NUM DrivePro)
17	CPU1: communication error - drive's CRC invalid	Electrical noise if the error occurs sometimes) or HW error if the error is present even with drive disabled.
18	CPU1: system critical error - SAMX model not coherent with drive	Invalid NUM-SAMX SW (Mono-Axis instead of Bi-Axis or viceversa) or invalid Ethercat EEPROM content. Control SW Version: - 3.xx.yyyy Mono-Axis - 4.xx.yyyy Bi-Axes If Sw version is ok download XML through Ethercat into EEPROM of Ethercat-IP.
19	CPU1: system critical error - Arithmetic Logic Unit failure	Mismatch in pulse counting: noise or HW Error if persistent.
20	CPU1: system error - outputs mismatch CPU1-CPU2 (- 500ms) See chapter 8.1	Invalid operating condition or SW error or dynamic incongruency.

Alarm 64 extension		Trouble shooting
21	CPU1: system critical error - oscillator frequency mismatch CPU1-CPU2	HW Error: Replace the NUM DrivePro.
22	CPU1: system error - encoder count mismatch CPU1-CPU2	
23	CPU1: cutoff feedbacks error - cutoff dynamic test not passed	Download compatible FW release. (076XYY000001.xlv)
25	CPU1: hipurface DSL protocol error - communication KO	NUM-SAMX HW Failure. (Exchange the NUM DrivePro)
26	CPU1: hipurface DSL protocol error - communication CRC invalid	Check S5 bit 8 set to 1 for DSL Encoder with Hipurface protocol. If the used encoder is coherent to the safe parameter, an HW failure is detected. (Exchange the NUM DrivePro module or Encoder)
27	CPU1: hipurface DSL protocol error - communication FIX2 pattern invalid	
30	CPU1: system config error - sensorless can be activated only on motor M1	
32	CPU1: system config error - sensorless monitoring speed active too low	
33	CPU1: system config error - STO mode and sensorless mode do not allow standstill function, S16 must be set to zero	
40	CPU1: system config error - STO mode does not allow speed monitoring, S15 must be set to zero	
70	CPU1: system config error - invalid motor type selection	See note (1) chapter 6.3.3
71	CPU1: system config error - invalid encoder type selection	See note (2) chapter 6.3.3
72	CPU1: system config error - invalid operational mode selection	See note (3) chapter 6.3.3
100	CPU2: class 4 error forced	Undetected fault condition.
101	CPU2: hardware error - 3.3V undervoltage/overvoltage See chapter 8.1	HW Error. (Exchange the NUM DrivePro)
102	CPU2: hardware error - 5V undervoltage/overvoltage See chapter 8.1	
103	CPU2: hardware error - 7.5V undervoltage/overvoltage See chapter 8.1	
104	CPU2: hardware error - +15V undervoltage/overvoltage See chapter 8.1	
105	CPU2: hardware error - VDD undervoltage/overvoltage See chapter 8.1	
106	CPU2: hardware error - VDD_flash undervoltage/overvoltage See chapter 8.1	
107	CPU2: communication error - CPU1-CPU2	
108	CPU2: cutoff feedbacks error - invalid analog value See chapter 8.1	
109	CPU2: cutoff feedbacks error - invalid logical state See chapter 8.1	
110	CPU2: system error - serial number mismatch with drive, default parameters reloaded	Change the Parameter File or at least one parameter and reset the alarm.
111	CPU2: system error - parameters' CRC mismatch CPU1-CPU2	The Checksum of the User Parameter file is different. Since it is not possible to know what parameters does not match: 1. Save parameter file to HD. 2. Reload the Parameter file. 3. Reset the Error.
112	CPU2: system critical error - stack overflow	SW Error: Control SW Release and known bug list (if any).
113	CPU2: system critical error - instruction memory corruption	HW Error. (Exchange the NUM DrivePro)
114	CPU2: system critical error - flash data memory corruption	Reload Application SW and FW.
115	CPU2: system error - parameters' CRC invalid	Reload Parameter file.
116	CPU2: system critical error - L1 cache corruption	HW Error.(Exchange the NUM DrivePro)

Alarm 64 extension		Trouble shooting
117	CPU2: communication error - drive's CRC invalid	Electrical noise if the error occurs sometimes) or HW error if the error is present even with drive disabled.
118	CPU2: system critical error - SAMX model not coherent with drive	Invalid NUM-SAMX SW (Mono-Axis instead of Bi-Axis or viceversa) or invalid Ethercat EEPROM content. Control SW Version: - 3.xx.yyyy Mono-Axis - 4.xx.yyyy Bi-Axes If Sw version is OK download XML through Ethercat into EEPROM of Ethercat-IP.
119	CPU2: system critical error - Arithmetic Logic Unit failure	Mismatch in Pulse Counting: noise or HW Error if persistent.
120	CPU2: system error - outputs mismatch CPU1-CPU2 (- 500ms) See chapter 8.1	Invalid Operating Condition or SW Error or dynamic incongruously.
121	CPU2: system critical error - oscillator frequency mismatch CPU1-CPU2	HW Error: Replace the NUM DrivePro.
122	CPU2: system error - encoder count mismatch CPU1-CPU2	
123	CPU2: cutoff feedbacks error - cutoff dynamic test not passed	Download compatible FW release. (076XYY000001.xlv)
125	CPU2: hipurface DSL protocol error - communication KO	NUM-SAMX HW Failure. (Exchange the NUM DrivePro)
126	CPU2: hipurface DSL protocol error - communication CRC invalid	Check S5 bit 8 set to 1 for DSL Encoder with Hipurface protocol. If the used encoder is coherent to the safe parameter, an HW failure is detected. (Exchange the NUM DrivePro module or Encoder).
127	CPU2: hipurface DSL protocol error - communication FIX2 pattern invalid	
130	CPU2: system config error - sensorless can be activated only on motor M1	
132	CPU2: system config error - sensorless monitoring speed active too low	
133	CPU2: system config error - STO mode and sensorless mode do not allow standstill function, S16 must be set to zero	
140	CPU2: system config error - STO mode does not allow speed monitoring, S15 must be set to zero	
170	CPU2: system config error - invalid motor type selection	See note (1) chapter 6.3.3
171	CPU2: system config error - invalid encoder type selection	See note (2) chapter 6.3.3
172	CPU2: system config error - invalid operational mode selection	See note (3) chapter 6.3.3



Diagnostic tests and fault reaction functions are realized inside of the NUM-SAMX board.

Therefore no external feedbacks should be used by external device.

9.3 Fault reaction and Response time

9.3.1 PDS fault reaction

NUM-SAMX triggers four Safety Failure classes (61, 62, 63, 64), see chapter 8.1 for details, the PDS reaction depends on the fault family and depends on drive setting.

Safety Failure classes 61 and 62:

- NUM-SAMX generate an alarm and start the SS2 monitoring function.
- NUM DrivePro reacts to such alarm in functions of the drive parameter V32, V30 and V31.
- The Safety Failure classes 61 and 62 are triggered in case the safety thresholds are disobeyed (when corresponding safety mode is active).

The NUM DrivePro reaction is as follows:

- *Safety Failure class 61:* with the drive parameter V32 bit 13 it's possible to define whether to remove the power to the motor or start braking.
(See NUM DrivePro parameter manual M00066)
- *Safety Failure class 62:* with the drive parameter V32 bit 14 it's possible to define whether to remove the power to the motor or start braking.
(See NUM DrivePro parameter manual M00066)
- In case the drive parameter V32 is set to start braking the V30 bit 5 defines how to brake: with drive ramps or with maximum current. The deceleration ramps are defined in the drive parameter V91 (see NUM DrivePro parameter manual M00066)
- In case the drive parameter V31 bit 9 is set, the E-Stop request is sent to the FlexiumPro in order to activate the G75 retraction function (see FlexiumPro Programming manual M00073 for G75 definition / managing).

Safety Failure classes 63 and 64:

- NUM-SAMX generate an alarm and activate the STO function (power removal).
- The Safety Failure classes 63 and 64 are triggered in case of internal diagnostic failure.
(NUM SAMX faults that can be due to hardware, software, noise etc.)

Fault reaction and Response time

CNC alarm display	Fault reaction	Response time
60 Safety Module class 0	STO	< 50µs
61 Safety Module class 1	SS2	< 10ms
62 Safety Module class 2	SS2	< 10ms
63 Safety Module class 3	STO	< 50µs
64 Safety Module class 4	STO	< Diagnostic Interval/Procedure Duration + 50µs

9.4 State of being maintained

9.4.1 Maintenance

The NUM-SAMX safety module are maintenance-free!



Observe the specified environmental conditions!

Please ensure that the NUM-SAMX safety module are only stored and operated under the specified conditions (see technical data).

If the terminal is operated outside the permitted temperature range it will switch to Global Fault state, see the chapter Diagnosis.

Cleaning

Protect the NUM-SAMX safety module from unacceptable soiling during operation and storage!

If the NUMSafe Bus Terminal were subjected to unacceptable soiling they may no longer be operated!



Have soiled terminals checked!

Cleaning of the NUM-SAMX safety module by the user is not permitted!

Please send soiled terminals to the manufacturer for inspection and cleaning.

9.5 Service life

The NUM-SAMX safety module are designed for a service life of 20 years.

Due to the high diagnostic coverage within the life cycle no special proof tests are required.

Page deliberately empty

Published by NUM Spa

Via F. Somma 62
20012 Cuggiono (MI) (Italy)
Tel. : +39 02 979 691
website: www.num.com

Printed 01.2026